


USER MANUAL



CONTENTS

ATTENTION	1
BASIC FUNCTION	2
RADIO	4
BLUETOOTH	5
PHONELINK	6
USB	8
AUX	9
EQ SETTINGS	9
SYSTEM SETTINGS	10
WIRING DIAGRAM	12
INSTALLATION	13

ATTENTION

Please try not to watch videos and operate machines while driving for your safety. When sailing, please adjust the volume to hear outside sounds clearly. Before starting operation, please read this manual and other manuals of the system in detail to understand the relevant safety tips and warning signs in this manual and the machine. After reading, please keep it for reference at any time.

- ✧ First of all, please pay attention to safety when sailing.
- ✧ If you encounter difficulties operating this system, please park the boat in a safe place before operating.
- ✧ Do not allow children to operate this machine to avoid personal injury or machine damage.
- ✧ Please follow the rules of the sailing when using the screen projection function.
- ✧ Please do not use it in places where the use of electronic equipment or open flames is strictly prohibited, such as gas stations, wineries, areas with strong electromagnetic interference, etc. Otherwise, it may cause danger.
- ✧ Do not maintain or install this machine by yourself. Do not install or repair this machine while the power is on. It is extremely dangerous to install and repair this machine by persons who have not been trained or experienced in installing electronic equipment or vehicle accessories.
- ✧ Do not scratch the screen with sharp objects, and do not press the screen with hard objects, otherwise, the touch screen may be damaged.


BASIC FUNCTION

1. Power on/off

- ✧ When the ACC power is on, click the “” button on the panel to turn on the power;
- ✧ Insert the USB disk into the USB port, the machine will automatically turn on and enter the main page.

2. Panel function

1. “” Short press to mute / long press to turn off
2. “” Main menu
3. “” Back
4. “+ ” Volume adjustment



3. Main menu

Main menu Back Day / night / off screen mode
 Volume display Radio Bluetooth call PhoneLink
 USB play AUX Time display Playing status



EQ settings Bluetooth Music Setup
 Boot LOGO setting



4. Radio

 FM band switching  Search for radio stations  Radio stations
browsing  Local / DX switch  EQ settings

 P1-P6 radio station storage, a total of 18 radio stations can be stored

 Press: Single step back; Hold: Up Search


 Press: Single step forward; Hold: Down search



5. Bluetooth Call Menu



Search the Bluetooth device name on your phone: CarPlay BT. When connecting, the phone will prompt you to enter the PIN code. Enter the corresponding PIN code, such as "0000". After connecting, the yellow Bluetooth icon displayed in the upper right corner of the screen will light up.

 Bluetooth dialing  Call records  Contacts  Bluetooth device name:
CarPlay BT (PIN code: 0000)  Bluetooth music



6. Phone Link

When the mobile phone is connected to the machine through the machine's USB port, the mobile phone screen can be mirrored onto the machine screen.

- (1)  iPhone enters CarPlay mode  iPhone enters MirrorLink mode(wired only)  iPhone default mode selection (CarPlay mode, MirrorLink mode, OFF)
- (2)  Android phone enters Android Auto mode  Android phone enters MirrorLink mode (wired only)  Android phone connection default mode selection (Auto mode, MirrorLink mode, OFF)



1. For iPhone:

- (1) Mirror iPhone to the unit with wire

Connect your iPhone to the USB port of the unit using the original USB cable of your iPhone, the unit will automatically enter CarPlay mode.

- (2) Mirror iPhone to the unit without wire

Turn on the iPhone's Bluetooth and find the device name (CarPlay BT). After connecting, the unit will automatically enter CarPlay mode.

2. For Android phone:


(1) Mirror Android phone to the unit with wire

Connect your Android Phone to the USB port of the unit using the original USB cable of your Phone, the unit will automatically enter Android Auto mode.


(2) Mirror Android phone to the unit without wire

Turn on the Android Phone's Bluetooth and find the device name (CarPlay BT). After connecting, the unit will automatically enter Android Auto mode.


As shown below after mirroring phone



You can control your iPhone on the unit



You can control your Android Phone on the unit




Note: This function requires the Android phone to download and install the Android Auto APP on Google Play.


7. USB Play

 Previous/ Next
  Pause/ Play
  Repeat all/ Close repeat/ Repeat a song/ Repeat folder
  Play sequentially/ randomly
  Playlist
  EQ settings



 Playlist
  Movie list
  Image list
  Folder display

 Play music list status




8. EQ Settings

 5 Preset EQs :Jazz/Classic/Rock/Pop/Soft


 Loudness switch

 Front and rear speaker balance settings

 Restore settings




9. AUX



10. System Settings


1. Basic Setup

Beep/ Reverse Mute/ Driving Ban Video/ Front Camera/ Color lamp mode/
Color lamp interval/ Touch Calibration/ Restore Factory



2. Steering Wheel Control

- (1) Find the positive wire of the boat steering wheel and connect it to the KEY wire of the unit. Find the negative wire of the steering wheel and connect it to the black GND wire of the unit.
- (2) Click Wheel setting to enter the learning page. For the first time learning, please click "Reset" to reset all SWC functions. Please follow the steps below to set the button function: 1. Press and hold the steering wheel button and corresponding function button on the screen at the same time. 2. When the button on the screen turns yellow, it means learning is successful. Release the button and repeat the steps to learn the next button. Click "Save" after learning all the buttons.




3. Factory Setting


If you need the password of the factory setting, please contact us. (It is not recommended to change the content in the factory setting, as incorrect changes may cause the product to become inoperable.)

4. Video setting


Brightness, contrast, hue, saturation, reset.




5. Wallpaper settings & Language settings



6. Time setting & Device version display



11. Wiring Diagram



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


FCC ID: 2BV2G- F8826

12. Installation



1. Some boats originally have a hole. If not, an 80mm hole needs to be drilled.

2. Take out the bracket from the package and screw on the M4*40 screws, then tighten the nuts.



3. Take out the 4 screws(3*16) from the package and screw them on, then put on the decorative frame.

4. After installing the bracket and tightening the screws, as shown in the picture above.