Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's Date Code in the back of the manual (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference. 25f

CENTRAL™ MACHINERY

24" WALL-MOUNT FAN



71403

Visit our website at: https://www.harborfreight.com
Email our technical support at: productsupport@harborfreight.com

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-800-444-3353 as soon as possible.

Copyright© 2025 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.
Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein.
Tools required for assembly and service may not be included.

⚠WARNING

Read this material before using this product.
Failure to do so can result in serious injury.
SAVE THIS MANUAL.

WARNING SYMBOLS AND DEFINITIONS	
⚠	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
⚠DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
⚠WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
⚠CAUTION	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE CAUTION	Addresses practices not related to personal injury.

CENTRAL™ MACHINERY

⚠ **READ AND SAVE THESE INSTRUCTIONS.**

IMPORTANT SAFETY INFORMATION

1. **WARNING! To reduce the risk of fire or electric shock, do not use this Fan with any solid-state speed control device.**
2. **WARNING! TO PREVENT SERIOUS INJURY: To reduce the risk of fire or electric shock do not use with an extension cord.**
3. **After servicing, any safety device shall be reinstalled or remounted as previously installed.**
4. **Do not leave Fan running while unattended.**
5. **Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.**
6. **Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.**
7. Never insert fingers, pencils, or any other object through Front or Rear Blade Guards.
8. Disconnect Fan before removing grills for cleaning.
9. Be sure fan is mounted securely.
10. DO NOT mount fan near a window. Rain may create electrical hazard.
11. Maintain labels and nameplates on the fan. If unreadable or missing, contact Harbor Freight Tools for a replacement.
12. Use only in dry areas. Do not use in bathrooms, laundry area, near sinks or other sources of water.
13. This fan is not a toy. Keep it out of reach of children.
14. People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
15. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all conditions and situations that may occur. It must be understood by operator that common sense and caution are factors which cannot be built into this fan, but must be supplied by operator.

Specifications

Electrical Rating	120VAC / 60Hz / 2.35A
Speed	Low 7150 CFM / High 7600 CFM

Suitable for Commercial Use Only
Dry Location, Indoor Use Only

Mounting Instructions

Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Wood Stud

WARNING! TO PREVENT SERIOUS INJURY: MOUNT FAN SO THAT BOTTOM OF BRACKET IS AT LEAST 4 FT. FROM FLOOR IN AREA WHERE SMALL CHILDREN MAY BE PRESENT.

WARNING! TO PREVENT SERIOUS INJURY: DO NOT MOUNT FAN IN CORNER, ONLY MOUNT IN WOOD STUD VERTICALLY.


1. Use a stud finder (sold separately) to find stud and mark its location.

WARNING! TO PREVENT SERIOUS INJURY: Verify that mounting surface has no hidden utility lines before drilling or driving screws.

2. Set Bracket/Fan against wall where stud is marked. Mark locations of three mounting holes.
3. Drill three mounting holes with a 7.5mm drill bit (sold separately).

CAUTION! Only mount Bracket to wood stud. Do not mount Bracket/Fan to drywall or plaster.

4. Using three included Washers and Bolts attach Bracket/Fan to wood stud.




Concrete

WARNING! TO PREVENT SERIOUS INJURY: MOUNT FAN SO THAT BOTTOM OF BRACKET IS AT LEAST 4 FT. FROM FLOOR IN AREA WHERE SMALL CHILDREN MAY BE PRESENT.


Wall Mount

1. Set Bracket/Fan against wall. Mark locations of the three mounting holes.
2. Drill three mounting holes with a 12mm carbide tip masonry drill bit (sold separately).
3. Insert three Anchors into wall and use a hammer (sold separately) to tap flush with wall.

CAUTION! TO PREVENT INJURY: Wall anchors must be set firmly into concrete.




4. Using three included Washers and Bolts attach Bracket/Fan to wall.




1. Set Bracket/Fan against wall. Mark locations of the four outer mounting holes.
2. Drill four mounting holes with a 12mm carbide tip masonry drill bit (sold separately).
3. Insert four Anchors into wall and use a hammer (sold separately) to tap flush with wall.

CAUTION! TO PREVENT INJURY: Wall anchors must be set firmly into concrete.



4. Using four included Washers and Bolts attach Bracket/Fan to corner.



Operating Instructions

WARNING! Always make sure the Power Cord is unplugged from its electrical outlet prior to making any adjustments to the fan.

WARNING! To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.

1. Plug in Power Cord.
2. Pull Chain to set to LOW, pull Chain again to set to HIGH.
3. When finished, pull Chain until Switch turns OFF.
4. To prevent accidents, turn off fan and unplug it after use.
5. Clean fan according to “Inspection and Maintenance” on page 6.

CENTRAL™ MACHINERY

Inspection and Maintenance

⚠ DANGER **AUTOMATIC RESET SAFETY DEVICE IN MOTOR. TO REDUCE RISK OF INJURY DISCONNECT POWER SUPPLY BEFORE SERVICING.**

⚠WARNING **TO PREVENT SERIOUS INJURY FROM ACCIDENTAL OPERATION OR ELECTRIC SHOCK: Before appliance inspection or maintenance, make sure the appliance's switch is turned off, the power cord is unplugged, and the unit has cooled completely.**

TO PREVENT SERIOUS INJURY FROM APPLIANCE FAILURE:
Do not use damaged appliances. If abnormal noise or vibration occurs, have the problem corrected before further use.

1. **BEFORE EACH USE,** inspect the general condition of the fan. Check for:
   - loose hardware
   - misalignment or binding of moving parts
   - cracked or broken parts
   - damaged electrical wiring
   - any other condition that may affect its safe operation.
2. Clean regularly to prevent dust from accumulating on Blade. Use damp cloth during cleaning and dry before use.
3. **⚠WARNING! TO PREVENT SERIOUS INJURY: If the supply cord of this fan is damaged, it must be replaced only by a qualified service technician**

Record Date Code Here:_____

Note: If fan has no Date Code, record month and year of purchase instead.

Note: Replacement parts may be available for this item.
Visit **harborfreight.com/parts** for a list of in-stock parts. Reference UPC 193175581020.

CENTRAL™ MACHINERY

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

CENTRAL™
MACHINERY

26677 Agoura Road • Calabasas, CA 91302 • 1-800-444-3353