


USER MANUAL

X19



V2.1 2025.11.11

Packing List

Earphones ×1 Pair

Charging Case ×1

Type-C Charging Cable ×1

Ear Tips ×4 Pairs

User Manual ×1

Specification

- Product Name: ANC Wireless Sport Earphone
- Model Name: X19
- Bluetooth Version: V5.3
- Support: AAC/A2DP/HFP/HSP/AVRCP
- Transmission Range: 33 feet(without obstacle)
- FCC ID: 2ATJ2-X19
- Input: 5V ⎓ 500mA
- Charging Time: about 2H
- Headphones Battery Capacity: 3.7V 50mAh/0.185Wh
- Charging Case Battery Capacity: 3.7V 600mAh/2.22Wh

Product Overview

Reset Button

Charging Case Power Display

Charging Pins

Earbud LED Light/
Built-in Mic

Volume +/-
Button

Multi-function
Button(MFB)

Type-C
Charging Port

Earbud
Power Display

Charging
Contact

Ear Tips

Flexible
Ear Hook

* Please kindly note that the wireless charging area is on the bottom of the charging case.

Multi-function Operations

MFB Button

MFB Button

Play/Pause

Next Track

Last Song

Volume+

Volume-

Click MFB Button Once on L/R Earbud

Click "+" once on L/R Earbud

Click "-" once on L/R Earbud

Long Press "+" Button on L/R Earbud

Long Press "-" Button on L/R Earbud

Noise Cancelling Control

ANC mode /Normal / Transparency mode

(*) The voice prompt "ANC Off" signals normal mode activation.)

Voice Assistance (Non-Playing and Non-Calling)

Siri

Double-click MFB Button on L/R Earbud

For Call

Answer/End Call

Reject Call

Click MFB Button Once on L/R Earbud

Long Press MFB Button 2s on L/R Earbud

Caution

1. Please remove the protective film before use, otherwise the headphone will not be able to start and charge.

Tear off the protective film

How to Charge ?

Type-C Charging

Place earbuds into charging case properly, then use the included USB-C charging cable to connect the charging case, and plug the other end into power supply with a 5V/1A adapter (not included), they will start charging.

LED Power Display

Show the remaining battery percentage of charging case from 0-100. "0" means charging case need charging while "100" means the charging case is fully charged.

Flash down and up when earbud is charging; Stop flashing when earbud is fully charged.

Earbud's LED light: Red light up means "being charged", Red light go off means "fully charged".

How to power on/off & pair?

Automatically Power on/off & Pairing

(Make sure the earbuds and charging case have power)

1. Take out earbuds from the charging case, the earbuds will auto power on and enter pairing mode.

2. For first time pairing: Activate Bluetooth setting on your phone, search and connect "X19".

For the second time use, when you take out the earbuds from the charging case, they will connect to your device automatically.

3. Put the earbuds back into the charging case, the earbuds will disconnect & power off automatically.

Manually Power on/off

If the earbuds are out of the charging case and power off, just press & hold then (both earbuds) for 2s, they will power on.

Disconnect the bluetooth on your device, press & hold either earbud for 5s, both earbuds will power off at the same time.

Pair with Other Device

X19 Sports Headphones have memory connect function, they always auto connect to the last paired device.

Thus, if you want to pair them with other device, you should disconnected "X19" from the last paired device, then search and connect "X19" on your new device, it will work properly.

Single Mode

You can leave one earbud in the charging case and use one earbud alone.

Only take one earbud out of the charging case, then search & connect "X19" on your device.

When in Dual mode, put one earbud into the charging case.

Factory Restore Setting

When should I reset?

When only one side play music

When you can't find "X19" on your device

Occur connection issues.

How to reset?

1. Delete all "X19" on your phone and deactivate the bluetooth setting.

2. Put the two earbuds in the charging case, keep them in the charging statu.

3. Long press the Reset Button on the charging case for about 10s, the LED display flash 3 times and the earbuds flash red and green alternately, which means both earbuds have reset completely.

4. Now, pick up the earbuds to turn them on, activate the bluetooth setting on your device and select "X19" to connect, it should work properly.

If not, please put the earbuds back to the charging case and repeat the steps above.

How to sync volume on Android?

To protect users from potential hearing damage, Android's limit on max volume is quite low for Bluetooth audio devices.

If you feel the volume is too low, please access developer options and enable absolute volume, so you 'll able to max the volume at your own volition and to the full capabilities of your Bluetooth earphones.

(Scan this QR code to watch a video to learn more details.)

Battery Warning

Using the wrong battery can cause fire and other hazards (for example, in the case of some lithium battery types)

1. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion

2. Do not leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

3. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference,and

(2) This device must accept any interference received,including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that

ISED Warning

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélec-trique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance.

Caution

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

The symbol indicates DC voltage

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environ-ment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

This product can be used across EU member states.

The device is low power device, it can meet the requirement of the RF exposure.

NOTES:

1. High Sound Pressure

2. Hearing Damage Risk

3. Do not listen at high volume levels for long periods.

CE

Made in China

M

X19说明书

尺寸:82*96mm

材料:108g铜版纸, 不过膜