


## 接口说明



- 1.电源键: 长按3秒开/关机
- 2.音量+键: 短按音量+, 长按2秒上一曲
- 3.音量-键: 短按音量-, 长按2秒下一曲
- 4.ANC键: 短按可在通透模式、打开降噪和关闭降噪循环切换, 双击切换游戏/音乐模式
- 5.指示灯: 指示工作状态
- 6.Type-C充电口: 接入5V充电器进行充电
- 7.MIC孔: 麦克风孔

## 功能操作说明

### 开关机

长按电源键3秒开/关机。

### 蓝牙配对

- ①出厂首次开机或清除配对信息后开机, 自动进入配对状态。
- ②有配对过, 开机自动回连15秒, 如未回连成功自动进入配对状态。
- ③关机状态下, 长按电源键5秒开机进入强制配对状态。
- ④连接状态下, 同时按住音量+/-键2秒清除所有配对信息。



## 快速入门指南 Quick Start Guide

## ANYTIME

### 调节音量

短按音量+键增加一级音量, 短按音量-键减小一级音量。

### 音乐换曲

长按2秒音量+键切换上一曲, 长按2秒音量-键切换下一曲。

### 播放/暂停

在播放状态下, 短按电源键将暂停; 在暂停状态下, 短按电源键将播放。

### 通透模式、降噪打开/关闭

短按ANC键可在通透模式、打开降噪和关闭降噪之间切换。

### 游戏模式/音乐模式

在连接蓝牙状态下, 双击ANC键将打开游戏模式; 在打开游戏模式状态下, 双击ANC键将打开音乐模式。

### 语音助手打开/关闭

在关闭语音助手时, 双击电源键将打开; 在打开语音助手时, 双击电源键将关闭。

### 电话接听、拒接与挂断

来电时, 短按电源键接听, 长按2秒电源键拒接; 通话时, 短按电源键挂断。

## 指示灯说明

开机	白灯亮1秒后红白灯交替闪烁
关机	红灯闪烁3次
配对中	红白灯交替闪烁
低电量提示	红色灯每5秒闪烁一次
低电关机	红灯闪烁3次
充电中	红灯常亮
充满电	红灯熄灭
通透模式/降噪打开	绿灯常亮

### ★Please do not use or place the device in an enclosed high-temperature environment, such as in a car.

★Please do not put the battery in a high-temperature environment. The battery is prohibited from use if it is soaked in water.

★Please do not disassemble, hit, crush, or puncture the battery, and do not put it on fire.

## To Learn More

To learn more about the product, please visit our website: <https://www.fiio.com/supports>

Scan the QR code below to visit:



FIIO website



FIIO facebook

•Due to continuous improvement, each specification and design are subject to change at any time without further notice.

## 注意事项

★请使用标准的USB电源适配器进行充电。

★当长期不使用本产品时, 需定期对本产品进行充电, 以避免电池损坏。

★使用本产品时请确认合适的音量, 以保护听力。

★请勿将本产品接触液体溶液, 以防止造成设备严重损坏。

★请勿将设备置于温度过高或过低 (45°C以上或0°C以下) 的环境中或使用或存放。

★请勿将设备置于汽车内等密闭高温环境中使用或存放。

★请勿将电池置于高温环境中, 电池浸水后禁止使用。

★禁止拆解、撞击、挤压、刺破电池或将电池投入火中。

## 了解更多

了解产品详细使用说明请访问:

<https://www.fiio.com/supports>

欢迎扫描二维码访问:



飞傲官方网站



飞傲官方公众号

•由于产品不断改进, 各项规格及设计随时更改, 恕不另行通知。

## 环保材料说明

部件名称	产品中有害物质的名称及含量					
	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr,VI)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
PCB	X	0	0	0	0	0
PCBA 焊点	X	0	0	0	0	0
元器件	X	0	0	0	0	0
显示屏*	X	0	0	0	0	0
电池*	X	0	0	0	0	0
外观件	0	0	0	0	0	0
配件*	X	0	0	0	0	0

注: 表中标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。带\*号部件表示如果在您所购买的产品中无该部件, 请忽略表中该部件信息。  
O: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572-2011规定的限量要求以下。  
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572-2011规定的限量要求。

根据中国电子行业标准SJ/T 11364-2014 和相关的中国政府法规, 本产品及其某些内部或外部组件上可能带有环保使用期限标识。取决于组件和组件制造商, 产品及其组件上的使用期限标识可能有所不同。组件上的使用期限标识优先于产品上任何与之相冲突的或不同的环保使用期限标识。


此环保使用期限只适用于产品在规定的条件下工作

### FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

## Buttons and Ports Labeled



1. Power button: Long press for 3 seconds to power on/off.
2. Volume up button: Short press to increase volume; long press for 2 seconds to switch to the previous track.
3. Volume down button: Short press to decrease volume; long press for 2 seconds to switch to the next track.
4. ANC button: Short press to cycle through Ambient mode, ANC on, and ANC off. Double press to switch between Game mode and Music mode.
5. Indicator light: Indicates the working status.
6. Type-C charging port: Connect to a 5V charger for charging.
7. MIC hole: Microphone hole.

## Operation Instructions

### Power on/off

Long press the power button for 3 seconds to power on/off.

### Bluetooth pairing

- ①The first time the device is powered on or powered on after clearing pairing records, it will automatically enter pairing mode.

## 广州飞傲电子科技有限公司

Guangzhou FIIO Electronics Technology Co., Ltd.