


size:85x120mm

4-In-1 Wireless Charging Speaker

Instruction Manual

Item Number: MU03047




Contents:

1(One) 4-In-1 Wireless Charging Speaker  
1(One) USB Type-C Charging Cable  
1(One) Instruction Manual

Product Specification:

Bluetooth® Version: 5.3  
Bluetooth Range: 32 feet  
Speaker Output: 5W  
FM Radio Mode  
Alarm Clock  
Night Light With Brightness Adjustment  
Color-changing Light  
Charging Input: 5V  $\bar{\equiv}$  2A/9V  $\bar{\equiv}$  2A  
Wireless Charger Output: 5W/7.5W/10W/15W(Max)  
Power supply by USB C-C cable  
USB C-C Charging Cable Rating : 9V  $\bar{\equiv}$  2.0A Max. 20W  
FCCID:2A6QJMU03047



① Wireless charging area  
② Indicator light  
③ Clock button  
④ Alarm clock button  
⑤ Previous song/Volume down  
⑥ Next song/Volume up  
⑦ Play / Pause button  
⑧ ON / OFF / Mode button  
⑨ Light control

How To Use:

• Power on/off:

Connect the speaker to the power adapter using the supplied Type-C charging cable.  
Please use power adaptor in 15W or above to boost the speaker.  
Press and hold "⏻" to turn on / off the unit.

• Bluetooth® Mode / FM Mode Changing:

Press "⏻" once to switch between Bluetooth® and FM mode.

• Connect to Bluetooth®

① Switch to Bluetooth® mode.

② Search the pairing name "4 in 1 Charging Speaker" from the list of Bluetooth® devices found. Pair the speaker with your phone.

③ You will hear a prompt sound when it is successfully paired.

Note:

The device automatically synchronizes its time with your phone when Bluetooth® is connected.

• Bluetooth® Music Playback:

- Press "⏮" once to play / pause the music.

- Press "⏮" once to play the previous song. Press and hold "⏮" to reduce the volume.

- Press "⏭" once to play the next song. Press and hold "⏭" to increase the volume.

• FM Radio Mode:

① Switch to FM radio mode by pressing the "⏻" button once.

② Press and hold "⏮" button to scan and save the radio stations with strong signals. The first scanned station will then be played.

③ Press "⏭" button to play the next station. Press "⏮" button to play the previous station.

• Light Setting:

① Press "⚙" once to adjust the brightness of the warm white light.

② Press and hold "⚙" to enter RGB light mode. Press "⚙" once to change to different light colors.

③ Press "⚙" twice to turn on/off the light mode.

• TWS function:(Requires 2 Speakers)

Prepare 2 speakers and turn on, press one of speaker "⚙" twice to connect TWS. When you hear the tone, that means the TWS connection is successful.

At this time, your phone will only show one Bluetooth® name, pair it, then you can hear two speakers playing music at the same time.

Press "⚙" twice again to disconnect TWS.

• Clock Setting:

① Press and hold the "⌚" to enter the clock adjustment mode. The hour display will start flashing. Use the volume button to gradually set the desired hour; Press and hold the button for quicker adjustment.

② Press "⚙" once again to enter the minute setting, then use the volume button to gradually set the desired minute; Press and hold the button for quicker adjustment.

Finally, press "⌚" once to complete the clock setting.

Note:

1. Press and hold "⌚" to turn on / off clock display. This operation can only be performed under Bluetooth® mode. 2. Press "⚙" twice to toggle between 12-hour and 24-hour modes.

Front

•Alarm Mode:

① Press and hold "⌚" to enter the alarm adjustment mode. The hour display will start flashing. Use the volume button to gradually set the desired hour; Press and hold the button for quicker adjustment.

② Press "⚙" once again to enter the minute setting, then use the volume button to gradually set the desired minute; Press and hold the button for quicker adjustment. Then the display area shows ON/OFF, use the volume button to select ON or OFF ( the alarm status indicator is always on after the alarm is turned on).

Finally, press "⌚" once to complete the alarm setting.

Note:

-Without any operation in about 10 seconds, it will exit the setting mode, and all setting values are saved.

-At alarm time, press random button once will stop the alarm.

If you don't stop the alarm, the alarm sound will play for 1 minute.

• Use of Wireless Charger

Put the mobile phone that supports wireless charging function on the wireless charging area to charge.

Green LED light: Standby.

Green LED light flashing slowly: Normal charging.

Green LED light flashing fast: Abnormal charging.

The following situation can cause failures, like charging slowly, stop charging, over-temperature for charging position:

1. The adapter is not run to standard (No PD USB output power supply).

2. The charging cable is not up to standard.

3. The phone case is too thick (within 2mm thickness phone case recommended).

4. The built-in wireless charging receiver position is not coincided with wireless charger coil position.

5. There is metal/magnet on the back of cell phone or phone case.

Smartphone does not support wireless charging function.

Note:

1. Make sure your phone supports wireless charging.

2. Please do not place metal/magnet/credit cards on the mobile phone or phone case, it will block the wireless charging.

3. Do not use a mobile phone case that is more than 6mm thick, otherwise it will lead to the inability to magnetically attract and charge.

This wireless charging pad is compatible compatible with all Qi wireless charging standard smartphones.

⚠ WARNING:

• Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.

• To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.

• To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.

• Do not pull the speaker charging cable. Damage may result to the cable.

• Keep out of reach of children. This is not a toy.

• Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.

• Retain these instructions as they contain important information.

• Do not short circuit the input terminals of the speaker.

• Do not drop, place heavy weight or allow heavy impact to the speaker.

• PCB of battery should not be crushed and twisted.

• Battery body should not be bended.

• Do not disassemble and Do not dispose of in fire.

This device complies with part 18 of the FCC Rules.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Bluetooth®

The Bluetooth word mark and logos are owned by the Bluetooth SIG. All other trademarks appearing herein are the property of their respective owners. Depends upon third party device compatibility.

⚠ CAUTION:

FOR YOUR SAFETY, the charging cable included with this item is intended for use with this product only.

Distributed By:

1616 Holdings, Inc  
701 Market Street, Suite 200,  
Philadelphia, PA 19106  
Made in China

Back

M