

FUEL INJECTOR

User Manual

Sharing valuable products to those who need them

TECHNICAL SUPPORT SERVICE TEAM

Supporting Contact us Immediately After Purchasing to Get

"2-year Factory Warranty"

"2-year Free Replacement"

"2-year Technical Support"

"Repeat Purchase Welfare Plan"

"Recommend a friend Welfare Plan"

If you don't understand what it means, please contact us immediately.

E-mail: S-upport-Aut-1@outlook.com

Contents

1.Product Specifications

2.Installation Guide

3.After-Sales Service

1

PRODUCT SPECIFICATIONS	
Brand:	Yazhidianf
Product:	Fuel Injectors
Manufacturer:	Yazhidianf
Terminal Type:	Blade
Lifespan:	5 Year
Driving Kilometers:	40000-60000
System Type:	Top Feed
New or Reman:	New

4.User instructions :


- ① Please purchase the product through official channels , otherwise we won't provide after-sales service .
- ② As the product has small sharp parts , please keep it away from children .
- ③ After receiving the product , please carefully check whether it is damaged or any part is missing . If there is any problem , please contact Customer Service
- ④ After receiving the product , please carefully check whether it is damaged or any part is missing . If there is any problem , please contact Customer Service

2


3

INSTALLATION INSTRUCTIONS

- 1.Ensure the engine is turned off and the key is removed from the ignition.
- 2.Wear appropriate safety gear, including gloves and eye protection.
- 3.Locate the existing fuel injector on your engine and disconnect the electrical connector.
- 4.Carefully remove the old injector and any associated O-rings.
- 5.Install the New Injector



3 : Lift Up On Rail



4 : Remove Old Fuel Injector




1 . Remove Connector



2 : Remove Fuel Rail



5 : Fuel Injector O Ring




6 . Install Fuel Injector

4


5



7 : Push Down On Rail



8 : Reinstall Bolts



9 : Reconnect Electrical

6

7