

尺寸:140*108mm
材质及工艺:
封面/封底200g双铜+单黑印刷+防刮花哑膜
内页128g双铜+单黑印刷
骑马钉(左右翻页)

140 mm

108 mm

T7

WIRELESS ESPORTS HEADSET

QUICK START GUIDE

crocricis

封面

Connection

Bluetooth Mode

- Select the "BT" button on your headphones.
- Turn on Bluetooth on your device. Find "Crocricis T7" in the Bluetooth device list and connect.

Adapter Mode

- Select the "T2.4S" button on the headphones.
- Connect the 2.4G wireless adapter to the device's port.

Dual Mode

- Select the "BT" button on your headphones.
- Turn on Bluetooth on your device. Find "Crocricis T7" in the Bluetooth device list and connect.

Wired Mode

- With the device powered on, press and hold the power button and microphone mute button simultaneously for 3 seconds to restore factory settings.

Buttons Controls

Reset Settings

- With the device powered on, press and hold the power button and microphone mute button simultaneously for 3 seconds to restore factory settings.

Install the Microphone

- Insert the detachable microphone into the headset.

Specifications

Headphone

- Driver: 50 mm
- Frequency response: 20 Hz ~ 20 kHz
- Sensitivity: 97 ± 3 dB
- Impedance: 32 Ω ± 10%

Microphone

- Microphone type: Dynamic
- Microphone size: 17 x 5 mm
- Microphone frequency response: 100 Hz ~ 5 kHz

Battery & Charging

- Bluetooth mode battery life: Up to 120 hours
- Dual mode battery life: Up to 100 hours

Contents

- English 2-7
- Deutsch 7-8
- Fransis 8-10
- Español 10-11
- Italiano 11-13
- Thai 13-14
- 日本語 14-15
- 한국어 15-16
- Русский 16-18
- Português 18-19
- हिंदी 19-21
- فارسی 21-22

Overview

- USB-C to USB-A Adapter
- Detachable Microphone
- Microphone Mute Button
- Microphone LED
- Sound Mode Button
- Mode Switch

Function Operation

Sound Mode Button	Icon	Action	Description
Power On	🔊	🔊	EPS Mode / EPS (Enhancement Mode) / Music Mode
Power Off	🔊	🔊	Green LED on for 1s
AI Noise Cancellation	🔊	🔊	Red LED on for 1s
Microphone Mute	🔊	🔊	ENC On (Default) / Off
Volume Control	🔊	🔊	Muted (Red Light On) / Unmuted

Wearing

Microphone Placement

Connection

Bluetooth Mode

- Select the "BT" button on your headphones.
- Turn on Bluetooth on your device. Find "Crocricis T7" in the Bluetooth device list and connect.

Adapter Mode

- Select the "T2.4S" button on the headphones.
- Connect the 2.4G wireless adapter to the device's port.

Dual Mode

- Select the "BT" button on your headphones.
- Turn on Bluetooth on your device. Find "Crocricis T7" in the Bluetooth device list and connect.

Wired Mode

- With the device powered on, press and hold the power button and microphone mute button simultaneously for 3 seconds to restore factory settings.

Buttons Controls

Reset Settings

- With the device powered on, press and hold the power button and microphone mute button simultaneously for 3 seconds to restore factory settings.

Install the Microphone

- Insert the detachable microphone into the headset.

Specifications

Headphone

- Driver: 50 mm
- Frequency response: 20 Hz ~ 20 kHz
- Sensitivity: 97 ± 3 dB
- Impedance: 32 Ω ± 10%

Microphone

- Microphone type: Dynamic
- Microphone size: 17 x 5 mm
- Microphone frequency response: 100 Hz ~ 5 kHz

Battery & Charging

- Bluetooth mode battery life: Up to 120 hours
- Dual mode battery life: Up to 100 hours

Contents

- English 2-7
- Deutsch 7-8
- Fransis 8-10
- Español 10-11
- Italiano 11-13
- Thai 13-14
- 日本語 14-15
- 한국어 15-16
- Русский 16-18
- Português 18-19
- हिंदी 19-21
- فارسی 21-22

Overview

- USB-C to USB-A Adapter
- Detachable Microphone
- Microphone Mute Button
- Microphone LED
- Sound Mode Button
- Mode Switch

Function Operation

Sound Mode Button	Icon	Action	Description
Power On	🔊	🔊	EPS Mode / EPS (Enhancement Mode) / Music Mode
Power Off	🔊	🔊	Green LED on for 1s
AI Noise Cancellation	🔊	🔊	Red LED on for 1s
Microphone Mute	🔊	🔊	ENC On (Default) / Off
Volume Control	🔊	🔊	Muted (Red Light On) / Unmuted

Wearing

Microphone Placement

Connection

Bluetooth Mode

- Select the "BT" button on your headphones.
- Turn on Bluetooth on your device. Find "Crocricis T7" in the Bluetooth device list and connect.

Adapter Mode

- Select the "T2.4S" button on the headphones.
- Connect the 2.4G wireless adapter to the device's port.

Dual Mode

- Select the "BT" button on your headphones.
- Turn on Bluetooth on your device. Find "Crocricis T7" in the Bluetooth device list and connect.

Wired Mode

- With the device powered on, press and hold the power button and microphone mute button simultaneously for 3 seconds to restore factory settings.

Buttons Controls

Reset Settings

- With the device powered on, press and hold the power button and microphone mute button simultaneously for 3 seconds to restore factory settings.

Install the Microphone

- Insert the detachable microphone into the headset.

Specifications

Headphone

- Driver: 50 mm
- Frequency response: 20 Hz ~ 20 kHz
- Sensitivity: 97 ± 3 dB
- Impedance: 32 Ω ± 10%

Microphone

- Microphone type: Dynamic
- Microphone size: 17 x 5 mm
- Microphone frequency response: 100 Hz ~ 5 kHz

Battery & Charging

- Bluetooth mode battery life: Up to 120 hours
- Dual mode battery life: Up to 100 hours

Contents

- English 2-7
- Deutsch 7-8
- Fransis 8-10
- Español 10-11
- Italiano 11-13
- Thai 13-14
- 日本語 14-15
- 한국어 15-16
- Русский 16-18
- Português 18-19
- हिंदी 19-21
- فارسی 21-22

Overview

- USB-C to USB-A Adapter
- Detachable Microphone
- Microphone Mute Button
- Microphone LED
- Sound Mode Button
- Mode Switch

Function Operation

Sound Mode Button	Icon	Action	Description
Power On	🔊	🔊	EPS Mode / EPS (Enhancement Mode) / Music Mode
Power Off	🔊	🔊	Green LED on for 1s
AI Noise Cancellation	🔊	🔊	Red LED on for 1s
Microphone Mute	🔊	🔊	ENC On (Default) / Off
Volume Control	🔊	🔊	Muted (Red Light On) / Unmuted

Wearing

Microphone Placement

Connection

Bluetooth Mode

- Select the "BT" button on your headphones.
- Turn on Bluetooth on your device. Find "Crocricis T7" in the Bluetooth device list and connect.

Adapter Mode

- Select the "T2.4S" button on the headphones.
- Connect the 2.4G wireless adapter to the device's port.

Dual Mode

- Select the "BT" button on your headphones.
- Turn on Bluetooth on your device. Find "Crocricis T7" in the Bluetooth device list and connect.

Wired Mode

- With the device powered on, press and hold the power button and microphone mute button simultaneously for 3 seconds to restore factory settings.

Buttons Controls

Reset Settings

- With the device powered on, press and hold the power button and microphone mute button simultaneously for 3 seconds to restore factory settings.

Install the Microphone

- Insert the detachable microphone into the headset.

Specifications

Headphone

- Driver: 50 mm
- Frequency response: 20 Hz ~ 20 kHz
- Sensitivity: 97 ± 3 dB
- Impedance: 32 Ω ± 10%

Microphone

- Microphone type: Dynamic
- Microphone size: 17 x 5 mm
- Microphone frequency response: 100 Hz ~ 5 kHz

Battery & Charging

- Bluetooth mode battery life: Up to 120 hours
- Dual mode battery life: Up to 100 hours

Contents

- English 2-7
- Deutsch 7-8
- Fransis 8-10
- Español 10-11
- Italiano 11-13
- Thai 13-14
- 日本語 14-15
- 한국어 15-16
- Русский 16-18
- Português 18-19
- हिंदी 19-21
- فارسی 21-22

Overview

- USB-C to USB-A Adapter
- Detachable Microphone
- Microphone Mute Button
- Microphone LED
- Sound Mode Button
- Mode Switch

Function Operation

Sound Mode Button	Icon	Action	Description
Power On	🔊	🔊	EPS Mode / EPS (Enhancement Mode) / Music Mode
Power Off	🔊	🔊	Green LED on for 1s
AI Noise Cancellation	🔊	🔊	Red LED on for 1s
Microphone Mute	🔊	🔊	ENC On (Default) / Off
Volume Control	🔊	🔊	Muted (Red Light On) / Unmuted

Wearing

Microphone Placement

封底