



INSTRUCTION MANUAL

PROFESSIONAL TILE VIBRATION TOOL MODEL NO. TVT-01

21 V POWER VOLTAGE | 145 mm SUCTION CUP DIAMETER | 110lb
50Kg STRONG VERTICAL SUCTION



ANTIVE

www.antivetools.com

Please read carefully the instruction manual before use!



TABLE OF CONTENT

Professional Tile Vibration Tool Specifications	03
Operation instructions	04
Charging instructions and Working notes	05
General Safety Precautions	06
Battery & charger safety instructions	07
Certificate of Warranty	08

ANTIVE

Professional Tile Vibration Tool Specifications



CONFIGURATION PARAMETERS

- **Suction Cup Diameter:** 145 mm
- **Battery Capacity:** 1.5 mAh
- **Battery Voltage:** 21 V
- **Charging Current:** 1 A
- **Vertical Gravity Load:** 110 lbs. (50 kg)
- **Material Composition:** Nylon + Aluminum

ANTIVE

info@antivetools.com

03

Operation instructions

Step 1. Install the battery pack

- Attach the battery pack securely to the tool as shown in Pic 1.
- Check the battery display when the tool is activated.



Step 2. Prepare the suction mechanism

- Press the suction cup trigger.
- Ensure the lock button fits snugly into the aluminum shell groove (see Pic 2).
- Once the tile is securely held, **lift it to the desired laying position.**



Step 3. Release the tiles into place

- **Pull a bit** on the suction cup trigger; this will release the lock button from the shell groove. (see Pic 3)



Step 4. Activating Tool

- **Press and hold** the **ON/OFF** button for **3 seconds** to activate the tool (see Pic 4).
- **Adjust the vibration speed** by pressing the same button; switch from 1 (gentle vibration) to 9 (strong vibration).



Step 5. Start Vibrations

- **Activate Vibrations** by pressing and holding the Vibration start switch (see Pic 5).
- **Press and hold** the **ON/OFF** button for **3 seconds** to switch off the tool when finished.



ANTIIVE

Charging instructions

- Insert the battery pack into the dedicated charger to begin charging.
- The charger will display a **red light** to indicate the battery is charging. The light **will turn green** once the battery is fully charged.
- **The normal charging time is approximately 2 hours.**

WORKING NOTES



- **Operate rhythmically**
 - During the tiling process, avoid holding the switch continuously. A rhythmic approach ensures better results.
- **Store in a dry location**
 - Always store the machine in a dry place to prevent contact with liquids that may damage it.
- **Clean after use**
 - Remove mud and dust from the machine's surface promptly after each use to maintain its performance and longevity.
- **Charge the battery regularly**
 - Recharge the battery promptly when the power is low.
 - If the machine is not used for an extended period, charge the battery at least once a month to maintain its functionality.

General Safety Precautions

- **Keep your workplace clean and organized.** A cluttered workspace increases the risk of accidents.
- **Avoid hazardous environments.**
 - Do not use power tools or chargers in damp or wet areas.
 - Always ensure the workspace is well-lit.
 - Avoid using power tools and chargers near flammable or explosive substances, or in areas where flammable liquids or gases are stored.
- **Restrict access to children and the infirm.**
- **Store tools and chargers properly.**
 - When not in use, store tools and chargers in a dry, secure, and locked location to prevent unauthorized access.
 - Keep tools and chargers in an environment with a temperature below 104°F (40°C).
- **Do not overwork the tools.**
- **Select tools appropriate for the job.** Avoid using small tools or accessories for heavy-duty tasks.
- **Dress appropriately for safety.**
- **Wear safety gear.**
- **Handle cords with care.**
- **Maintain your tools.**
 - Keep tools clean, and in good condition for optimal performance and safety.
- **Disconnect chargers when not in use.**
- **Remove tools and accessories before use.**
- **Use only the specified chargers.**
- **Avoid touching moving parts.**
- **Charge properly indoors.**
- **Replace damaged cords promptly.**

Battery & charger safety instructions

Please dispose of worn-out battery packs responsibly and in an environmentally friendly manner.

- **Read all instructions carefully.** Before using the charger and battery, review all safety instructions and precautions printed on the battery product.
- **Do not disassemble the battery and charger.**
- **Discontinue use if performance declines.** If the battery's operating time significantly shortens, stop using it immediately.
- **Store batteries and the charger properly.** Do not store the battery in areas where temperatures may reach or exceed 122°F (50°C).
- **Avoid short circuits.**
 - Do not allow the battery terminals to contact conductive materials.
 - Do not store the battery in containers with nails, coins, or other metal objects.
 - Avoid exposing the battery and charger to rain or water. A short circuit can result in excessive current flow, leading to overheating, combustion, or device breakage.
- **Do not incinerate batteries.**
- **Handle with care.**
- **Monitor charging temperatures.** Charging is only permitted when the battery temperature is between 32°F to 113°F (0°C and 45°C).
- **Use only the original charger and batteries.**
- **Handle cords with care.**
- **Avoid flammable environments.**



ANTIVE

Certificate of Warranty

This Certificate is provided on behalf of Antive Enterprise to customers who purchase the 'PROFESSIONAL TILE VIBRATION TOOL'. The standard warranty covers 2 years for household use, starting from the day of purchase. For tools used in commercial, business, or industrial settings, the warranty is limited to 1 year, due to the higher levels of wear and tear experienced in these environments.

The batteries, charger, and all included extra parts are also covered by the warranty, provided they are from Antive and not third-party brands.

If any manufacturing defects, material issues, or workmanship problems arise within the warranty period, Antive will repair or replace the tool free of charge, as long as it has been used and maintained according to our safety and operating instructions.

Please refer to the user manual for details on proper operation, and feel free to contact us if you require assistance. Be aware that Antive reserves the right to modify the terms and conditions of the warranty policy without prior notice, so we encourage you to review the most current information on our website.

The Antive warranty covers 2 years for household use and 1 year for commercial use. However, the warranty does not cover:

- Any damage caused by misuse, neglect in usage or maintenance, accidents, exposure to extreme temperatures, acids, water, unsuitable storage, excessive impact, or transport damages.
- Any damage caused by improper use or exceeding workforce.
- Defects caused by spare parts, accessories, or components not made by Antive or not authorized by Antive.
- Normal wear and tear items such as batteries with more than 300 charges or power cable deterioration.

Certificate of Warranty

- Antive Tools that have been modified, repaired, or attempted to be repaired by anyone other than Antive-authorized service centers, or tools that have been partly or completely disassembled.
- Parts repaired or replaced by an Antive-authorized service center during the warranty period will carry the remaining warranty duration. Warranty repairs do not extend or renew the original warranty period of the tool.

No entity other than Antive has the authority to change, extend, or add to the given warranty terms and conditions.

These warranty terms shall be governed and interpreted in accordance with the laws of the United States, excluding the law and decree on the international sale of goods. Consumers may have additional statutory rights in their own countries, which are not restricted by these warranty terms. The warranty does not cover compensations for downtime, production loss, injuries, or property damage.

SUBMITTING A WARRANTY CLAIM

To submit a warranty repair claim, don't hesitate to contact us by email, phone, or site. (info@antivetools.com, +1 321 300 4061, www.antivetools.com) Tools returned for warranty repair must be accompanied by a valid order ID, full name, and address of shipment.

A warranty claim must be submitted with as short a delay as possible.
A warranty claim must be submitted within the warranty period.





**JUST REGISTER YOUR PRODUCT BY FOLLOWING THE
INSTRUCTIONS INCLUDED ON THE CARD YOU RECEIVED
IN YOUR PACKAGE.
AND DON'T HESITATE TO CONTACT US FOR ANY
SUPPORT OR INQUIRIES.**

ANTIVE


info@antivetools.com

09

CONTACT INFORMATION

 antive_tools  Antive  antive_tools  antive_tools

 www.antivetools.com  info@antivetools.com

 +1 321 300 4061



ANTIVE