


QUICK START GUIDE

Wireless Speaker Q8


WHAT'S IN THE BOX?



QUICK START GUIDE


Wireless Speaker QB

FIRST USAGE



CONTROLS


- x 1 Press Once
- x 2 Press Twice
- x 3 Press Triple
- >2S Press and hold for 2 seconds



- EQ**
 - x 1 EQ Switch among Bass and Vocal as well as Standard
- M**
 - >3S Disconnect Bluetooth in Bluetooth mode
- 
 - >2S Power On/Off
TWS Connected / Disconnected
 - x 3 Light Mode Switch
- 
 - x 1 Volume Up
 - >2S Next Track
- 
 - x 1 Volume Down
 - >2S Previous Track
- 
 - x 1 Music Play / Pause
Calling Answer / End
 - >2S Calling Decline



Redial the last dialed number when connected to a phone via Bluetooth.

TWS CONNECTION



More details operation, please read the notice for TWS connection.

CHARGING



SPECIFICATION

Model: Q8

Wireless Version: V5.4

Input: 5V / 2A

Frequency Response: 40Hz-20KHz

SNR: 80dB

Operation Frequency: 2402 - 2480MHz

Wireless Transmission Distance: 10 meters

Charging Time: 4 Hours

Playback Time: 18 Hours at 50% volume

Weight: 714 Grams

Dimensions: 82.40*77.45*205.50mm

Notice for TWS Connection

If you have two pieces Q8, you can use TWS to achieve wireless stereo combined playing music.

Note: Before TWS pairing, make sure the two Q8 speakers are not connected over Bluetooth.

1. Press  for 2 seconds to power on both speakers.
2. After you turn on the device, you should make sure neither is connected to any Bluetooth since both will automatically reconnect to your previous device. So you should disconnect existing device first or just turn off Bluetooth on your devices.
3. Press  twice on either speaker, a beep will be heard once TWS is connected.
4. Then make connection with mobile phone.

Resetting & Force shutdown

1. Press and hold  for 8 seconds to reset to factory settings in Bluetooth mode.
2. Press and hold  for 8 seconds to force a shutdown when the speaker is frozen.

Important Notice for Charging

- Before charging, be sure the speaker is at room temperature, between 46° F (8° C) and 102° F (39° C).
- Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., UL, CSA, VDE, CCC).
- Use included charging cable to charge the speaker.
- For the first use, please fully charge the product.

1. Connect the type C end of the included charging cable to the charging port on your speaker. Then plug the other end of the USB charging cable into a suitable USB port on your computer (or with a standard cell phone charger) to recharge your speaker's internal rechargeable battery.
2. Please charge the speaker in the earliest convenience when the lighting flashes red. The speaker will power off automatically when the battery runs out.
- 3. It may take several minutes for your speaker to begin charging when it's drained. The battery needs to charge to a minimum voltage before the system can boot up.**
4. It's recommended to turn the speaker off while it is charging. Please don't play audio until the speaker has been charged for 30 minutes at least. It will help to prolong the battery's life and protect the speaker well.

Care and Maintenance

Before using this product, carefully read these instructions and keep the user manual for future reference.



This logo means the prohibition of the naked flame sources such as a lighted candle on or near the device.

1. The electrical and electronic equipment are part of a separate collection. Do not throw electrical or electronic equipment away with unsorted municipal waste, but ensure that it is collected separately. Collection systems and locations (sorting centers, rubbish dumps) are provided for you by local councils and retailers. By entrusting your end-of-life product to the proper recycling process, you are helping to protect the environment and your health.

2. Use the product in temperate climates only.
3. This product is not a toy — never allow children to play with the appliance. Always store the product out of reach of children and pets.
4. Always unplug the device before cleaning it.
5. Clean the speaker with a soft dry cloth only. Never use solvents.
6. Attention should be drawn to the environmental aspects of battery disposal.
7. The battery (batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.
8. Stop using the device immediately in case of an abnormality or failure.
9. Avoid dropping. Dropping or hitting the device may damage it.
10. Do not tamper with the product. Never attempt to service, dismantle the product yourself, or push objects of any kind into the products, as this may result in fire, electric shock, or equipment damage and will also invalidate the warranty.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Electromagnetic Compatibility Regulations 2016.
Electrical Equipment (Safety) Regulations 2016.



Operation of this equipment is subject to the following two conditions:
(1) this equipment or device may not cause harmful interference, and (2) this equipment or device must accept any interference, including interference that may cause undesired operation.



FCC ID: 2AWG3-M18P

MADE IN CHINA

