



Customer Service

Email: service@boloxa.ltd Web: www.boloxa.ltd
 Phone Call: +1 (857) 666-8575 (Mon. - Fri., 11AM - 8PM EDT)


Packing List

Wireless Earbud *1 pair	Carry Bag*1 piece
Ear Tips *3 pairs	User Manual *1 piece
Wire Clamp *1 piece	Type-C Charging Cable *1 piece

Product Specification

Model Name: U81
 Battery Capacity: 3.7V 100mAh, 0.37Wh
 Input: 5V 100mA
 FCC ID: 2A6SW-U81
 Charging Time: about 2 hours
 Transmission Rang: 33 feet(without obstacle)

Product Overview



Multi-Function Operations

"R" Earbud

For Call


Answer Call: Press MFB button once
 End Call: Press MFB button once
 Reject Call: Long Press MFB button 2s

Voice Assistance

Voice assistants: Press MFB button twice
 (* You will hear a "Du" sound to activate the voice assistant of headphones.)

For music


Play/Pause: Press MFB button once
 Volume +: Press "+" button once
 Volume -: Press "-" button once
 Next Track: Long Press "+" button 2s
 Previous Song: Long Press "-" button 2s



How to Wear the Headphones Correctly?


1-Identify the right and left headphones.
 2-Choose best-fit ear tips, gently push the headphones into your ears and adjust them to get a comfortable fit.

(* Usually the medium ones are suitable for 75% of people)




Power On/Off

Power on: Press and hold the MFB button for 2s.
 (LED indicator flashes blue for 1s)



Power off: Press and hold the MFB button for 3s when the headphones are on. (LED indicator flashes red for 2s)



Bluetooth Connection

First Time Pairing

Step 1- Turn on the headphones when they are in shutdown state and they will enter pairing mode. (LED indicator flashes red and blue alternately)

Step 2- Activate the Bluetooth setting on your phone, search and connect "U81". (Once connected, the LED indicator goes off.)



* Enter "0000" or "1234" if your device asks a code to pair.
 * When the headphones are on but are not paired with any device, they will be automatically off within 5 mins.

For Second Time Use

If the headphones have already connected with your device, and the Bluetooth setting of this device is on, in the second time using, when you turn on U81, they will connect with your device automatically within 10s.

Pair with Other Device

U81 sports headphones have memory function, they usually auto connect with the last paired device. Thus, if you want to connect the headphones with other devices, there are three methods as below:

- (1) Delete "U81" on the Bluetooth list of the previous connected device.
- (2) Before they connect to other devices, please turn of the Bluetooth of the previous connected device.
- (3) Reset the headphones.

Factory Restore Settings

When should I reset?

- 1) Only one earbud plays music.
- 2) Both headphones can not work with together.
- 3) Occur connection issues.


How to reset?

- 1-Turn off the headphones first and clear the Bluetooth U8I connection history on the device.
 - 2-It is recommended to wear the left headphone on the ear to listen to the prompt sound, and the right earphone is used to observe the indicator light.
 - 3-In the state of shutdown, press and hold the MFB button for 10s. (You will hear the "power on" sound first and then hear the "pairing" sound; keep holding the MFB button and then you hear 3 tones; the headphones are on.)
 - 4-Restart the Bluetooth on the device, then click U8I to connect.
- * If not, please repeat the steps above.

07

Earbuds Charging

- 1)Open the hinged door on the bottom of the right headphone.
- 2)Plug the type-C cable into the charging port of the headphone.
- 3)Plug the other end into a USB wall charger or computer (DC 5V) that is powered on.



- * The LED indicator stays **red** during charging and turns **blue** when the headphones are fully charged.
- * The LED indicator flashes **red**, and the voice reminder prompts "battery low" when the headphones are in low battery.

08

How to Sync Volume on Android?

To protect users from potential hearing damage, Android's limit on max volume is quite low for Bluetooth audio devices.

If you feel the volume is too low, please access developer options and enable absolute volume, so you'll be able to max the volume at your own volition and to the full capabilities of your Bluetooth headphones.

(Please scan this QR code to watch a video to learn more details.)



Safety Attention

1. Do not use the headphones while driving a car, operating machinery or performing other activities that require hearing surrounding sounds.
2. Using headphones at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at times for your safety.
3. Please avoid use in thundering and raining days to prevent damage or electrical shock.

09

4. Please keep the headphones out of extreme heat or humidity, do not use any corrosive cleaner/oil to clean the headphones.
5. Please avoid disassemble/reassemble the product in case of failure or fire accident.
6. Please keep beyond the reach of kids or pets.
7. Please stop using the device if it causes any discomfort or pain.
8. As the Bluetooth signal cannot transmit in water it is not suitable for swimming or diving. If submerged in water, do not turn the headphones on until completely dried.

FAQ

- Q** Can I use the headphones during charging?
- A** No, you can't use U8I during charging.

- Q** What should I do when my headphones will not switch on?
- A** 1-Please recharge the headphones and make sure they have enough battery power.
- 2-If they still nothing happens after fully charged or if you fail to charge them, please contact our after-sale email for further help.

10

Q How to contact us?

A Email: service@boloxa.ltd
Web: www.boloxa.ltd

Thank you very much for your purchase!

If there is any issue with your U8I, please don't hesitate to contact us, we will reply within 24 hours and solve your problem 100%.

FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

11

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

12

Caution

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

— The symbol indicates DC voltage



This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE).

This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY

NOTES:

1. High Sound Pressure
2. Hearing Damage Risk
3. Do not listen at high volume levels for long periods.

FCC ID: 2A6SW-U8I



13

