

Getting Started - MX Ergo S

Setup

1. Turn on your MX Ergo S Trackball.
2. Choose how you want to connect your mouse — Bluetooth or the Logi Bolt receiver:

- **Bluetooth**


Press and hold the Easy-Switch button at the top of the mouse below the scroll wheel for three seconds. This will put your mouse in pairing mode and the LED light will start blinking fast.

Open the Bluetooth settings on your computer to complete the pairing.

- **Logi Bolt receiver**

Plug the Logi Bolt receiver into the USB port of your computer.

3. Download the Logi Options+ app to get the most out of your MX Ergo S Trackball experience. To download and learn more, go to logi.com/optionsplus.



Product Overview



Features:

1. **USB-C charging port**
2. **Adjustable angle**
3. **Backward and Forward buttons**
4. **DPI button**

Instantly change your cursor speed and accuracy for optimal control with the press of a button. An LED light illuminates when precision is activated.

5. **Precision scroll wheel with tilt**

Use the precision scroll wheel with tilt and middle click for convenient controls and quick access to your favorite shortcuts.

6. **Easy-Switch and connect button**

Two-channel Easy-Switch capabilities let you switch between two devices without re-pairing.

7. **Power LED**

Rechargeable battery:

A fast rechargeable battery holds power for up to four months on a full charge. Quick, one-minute charge gives you a full day of usage.

Flow-enabled:

Easily copy/paste text, images and files between computers thanks to Logitech Flow technology