




User Manual

MULTIFUNCTION BLUETOOTH

SPEAKER CLOCK WITH WIRELESS CHARGER

Model: CL9002



Thank you for purchasing our product! We truly appreciate your trust and choice. This manual is designed to help you get the most out of your new device. Please read it in detail before use and keep it for future reference.

Should you have any questions, please contact our customer service team. Customer Service Email: WallarGe@outlook.com.





PACKAGE CONTENTS

- Multifunction Clock
- Adapter
- User Manual


POWER ADAPTER WARNING

This product requires a 12V/3A power adapter (Output: 12VDC 3000mA) to operate properly. Using a third-party adapter with a lower power rating may result in insufficient power, causing the device to malfunction or fail to start. For optimal performance, please use only the included adapter or a compatible replacement with the exact same specifications.

PRODUCT OVERVIEW



BUTTON FUNCTIONS



- [**12/24H TIME SET**]: Press to switch time format; Hold to enter the time setting mode.
 - [**▶▶ / +**]: In setting mode: Adjust the value (hour/minute); In normal mode (Bluetooth connected): Skip to next track.
 - [**◀◀ / -**]: In setting mode: Adjust the value (hour/minute); In normal mode (Bluetooth connected): Skip to previous track.
 - [**▲ON/OFF ALARM SET**]: Press to turn on/off the alarm; Hold to enter the alarm setting mode.
 - [**DISPLAY DIMMER**]: Press to adjust the brightness of display.
 - [**BT**]: Press to turn on Bluetooth and enter pairing mode;
- WHEN CONNECTED**
- Press to pause or resume playback;
Double-press to disconnect the current device;
Press and hold to turn off Bluetooth.

- [**LIGHT DIMMER**]: Press to adjust the brightness of night light; Hold to turn off the night light.
- [**LIGHT COLOR**]: Press to change the color of night light; Hold to turn off the night light.
- [**▶**]: Decrease the Bluetooth audio volume.
- [**▶▶**]: Increase the Bluetooth audio volume.
- [**SLEEP SNOOZE**]: Press to set the sleep timer (when Bluetooth is connected or night light is on); Press to activate snooze (when the alarm sounds).

TIME SETTING INSTRUCTIONS

This device offers two ways to set the time: Automatic Sync

(recommended) and Manual Setting.

Automatic Time Sync via Bluetooth

When you connect the device to your phone via Bluetooth, the device will automatically sync and set the time to match your phone's current time.

Manual Setting

If you prefer to set the time manually, please follow the steps below.

- Press and Hold [**12/24H TIME SET**] button until the hour digits start flashing to enter time setting mode.
- Press [**▶▶ / +**] or [**◀◀ / -**] to adjust the hour.
- Short press the [**12/24H TIME SET**] button once, the minute digits will start flashing, press [**▶▶ / +**] or [**◀◀ / -**] to adjust.
- Short press the [**12/24H TIME SET**] button once more to confirm and exit, the digits will stop flashing and the time is saved.

Switch Time Format

In clock display mode, briefly press the [**12/24H TIME SET**] button to switch between the 12-hour and 24-hour display formats.

ALARM SETTING INSTRUCTIONS

Alarm Setting

- Press and Hold [**▲ON/OFF ALARM SET**] button until the hour digits start flashing to enter alarm setting mode, press [**▶▶ / +**] or [**◀◀ / -**] to adjust the hour.
- Short press the [**▲ON/OFF ALARM SET**] button once, the minute digits will start flashing, press [**▶▶ / +**] or [**◀◀ / -**] to adjust.
- Short press the [**▲ON/OFF ALARM SET**] button once more, the alarm volume level will start flashing, press [**▶▶ / +**] or [**◀◀ / -**] to adjust.
- Short press the [**▲ON/OFF ALARM SET**] button once more to confirm and exit.

Snooze Function

When the alarm sounds, press the [**SLEEP SNOOZE**] button to activate the 9-minute snooze function.

Stopping the Alarm for the Current Day

When the alarm sounds, press any button to stop the alarm for the current day. The alarm will sound again at the set time on the next day.

Turning off the Alarm Permanently

To turn off the alarm permanently, press the [**▲ON/OFF ALARM SET**] button when the alarm is not sounding. When the alarm is turned off, the alarm icon will no longer be displayed.

BLUETOOTH OPERATION

For First-Time Connection

1: Press the [**BT**] button once to turn on Bluetooth.

2: Enable Bluetooth on your mobile phone and search for **CL9002**.

Tap **CL9002** to connect. After the first successful connection, when you press the [**BT**] button to turn on Bluetooth again, the product will automatically search for and reconnect to the most recently connected device.

Bluetooth Controls (After Bluetooth is connected)

- Press the [**BT**] button once to play or pause music.
- Double-press the [**BT**] button to disconnect the currently connected device.
- Press and hold the [**BT**] button to turn off Bluetooth.
- Press the [**▶▶ / +**] button to play the next track.
- Press the [**◀◀ / -**] button to play the previous track.
- Press [**▶▶**] or [**◀◀**] to adjust the Bluetooth audio volume.

NIGHT LIGHT OPERATION

Adjusting Brightness

Press the [**LIGHT DIMMER**] to adjust the display brightness. Each press changes the brightness by one level.

The brightness cycles in the following order:

Level 5 → Level 4 → Level 3 → Level 2 → Level 1 → OFF → Level 1 →

Level 2 → Level 3 → Level 4 → Level 5

Changing Light Color

Press the [**LIGHT COLOR**] button repeatedly to change the night light color.

DISPLAY BRIGHTNESS

Adjusting Brightness

Press the [] to adjust the display brightness. Each press changes the brightness by one level.

The brightness cycles in the following order:

Level 5 →Level 4 → Level 3 → Level 2 → Level 1 → OFF → Level 1 →

Level 2 → Level 3→ Level 4 → Level 5

Temporary Display Wake-up

When the display brightness is set to OFF, press any button to temporarily turn on the display at Level 1 brightness for 10 seconds, allowing you to briefly check the time.

After 10 seconds of inactivity, the display will turn off again without changing the brightness setting.

SLEEP TIMER OPERATION

The Sleep Timer can be activated when at least one of the following conditions is met:

- Bluetooth is connected;
- The night light is turned on.

How to Use Sleep Timer

Press the [] button repeatedly to select the sleep timer duration:

Once a duration is selected, the sleep mode icon  will be displayed and the countdown will begin.

-  **Countdown Ends**
-  h audio will stop playing automatically; and/or

- The night light will turn off automatically.
- The sleep mode icon  will disappear from the display.

Turning off the Sleep Timer Manually

To turn off the Sleep Timer before the countdown ends, press and hold the [] button. The countdown will be cancelled, and the sleep icon  will disappear.

WIRELESS CHARGING

The wireless charging areas are designed for:

- Smartphone
- Smart watch
- Wireless earbuds

Place each compatible device in its designated charging area to begin charging. Please make sure the devices are properly aligned with the wireless charging areas for stable charging performance.

Foldable Stand

The smartphone charging area is equipped with a foldable stand to help position different phone models properly and align them with the wireless charging area.

Since charging coil positions may vary by phone model, adjust the stand as needed to find the best alignment for stable charging.

Charging Status Indicators

Each wireless charging area has its own corresponding indicator light.

The indicator light status is as follows:

- **Solid On:** The device is charging normally.
- **Flashing:** Charging is abnormal.

- **Light Off:** The device is fully charged or no device is detected.

If the indicator light flashes, please check whether the device is properly placed, whether there is any metal object on the charging area, or whether the device supports wireless charging.

Important Notes for Wireless Charging

- Use only devices that support wireless charging.
- Remove thick phone cases, metal objects, magnetic accessories, or cards before charging.
- Make sure the device is placed correctly in the charging area.
- Wireless charging performance may be affected by improper alignment, thick cases, metal objects, or magnetic accessories.
- If charging is unstable, reposition the device until the indicator light shows normal charging status.

USB CHARGING PORT

The product is equipped with a USB output port, which can be used to power or charge other compatible devices with a USB cable. Please use a suitable charging cable for your device.

BATTERY BACKUP FUNCTION

The device requires 2 x AAA batteries (not included) to enable the battery backup function. In the event of a power outage, the backup batteries will preserve your current settings, including the time, alarm, and brightness preferences. When power is restored, the device will resume normal operation with the saved settings intact, so there is no need to reset the clock or other settings.

Please note: The batteries are for backup purposes only and will not power the device for normal use.

Tip: For best performance, replace the backup batteries periodically to ensure they are ready when needed.

TROUBLESHOOTING

If you encounter any issues, please review the possible causes and solutions below. Most problems can be resolved with a few simple checks.

If the problem persists, feel free to contact our customer service team. We're always here to help.

✉ Customer Service: WallarGe@outlook.com

1: The device does not turn on.

- Check that the power adapter is securely connected to the device and the power outlet.

- Make sure the power outlet is working properly.

- Press the [] / [] button to adjust the brightness (the display or light may be set to OFF).

2: Bluetooth cannot be connected.

- Press the [**BT**] button to turn on Bluetooth.
- If needed, double-press the [**BT**] button to disconnect the current device, then reconnect.

3: No sound during Bluetooth playback.

- Check the Bluetooth connection and press the [**BT**] button to resume playback.
- Adjust the volume using the [] button.

4: The wireless charging indicator is flashing.

- Check whether the device is properly placed.
- Make sure there is no metal object on the charging area.
- Ensure your device supports wireless charging.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20 cm (8 inches) during normal operation.

WARRANTY

30-Day Money-Back Guarantee

Within 30 days of purchase, the product may be returned undamaged in its original packaging for a full refund. No reason is required.

12-Month Manufacturer’s Warranty

For 12 months from the date of purchase, the product is covered against quality-related issues under normal use. A replacement will be arranged for eligible cases. Please note that items purchased from unauthorized resellers are not covered.

Free User Support

Have a question? We’re here to help — just drop us an email. You’ll hear back from us within 1 business day, and usually even sooner.

Contact Us

WallarGe@outlook.com

We'd love to hear from you!