User Manual

WONDERLIT
Beyond Lighting

GOAL BEAT

Bluetooth



WIRELESS SPEAKER
WITH MULTICOLOR LED LIGHTS

Model Number: WL-SCBSPK-BLK FCC ID: 2BBPLWLSCBSPK

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. The device shall be operated and installed without restriction.

WONDERLIT© COPYRIGHT ALL RIGHTS RESERVED. WONDERLIT© is an innovative brand of Truststone Group LLC. No portion of this design may be reproduced without express written permission. Other trademarks and trade names are those of their respective owners. All rights reserved. Distributed by Truststone Group LLC, 1359 Broadway, New York, NY 10018

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

TRUSTSTONE GROUP FC Bluetooth

Made In China 08/26

Please read all safety instructions before using the device to ensure safe and proper operation.

· Only use manufacturer-approved batteries, chargers, accessories, and supplies.
· This device is not a toy. Do not allow children or pets to use or play with the device.
· Do not disassemble, modify, or attempt to repair the device.
· Do not expose the device to extreme temperatures, open flames, humid environments, or wet conditions.
· Do not submerge the device in water.
· Low battery power may cause unstable Bluetooth connections or sound distortion.
· Do not overcharge the battery.
· When using a USB adapter, ensure the adapter is in good condition and not damaged.
· Keep the USB port and the connectors of the supplied USB cable free from
dust, water, or conductive materials such as liquids or metallic powders.
· The speaker contain built-in batteries and must not be disposed of with regular household waste. Please follow local regulations for proper disposal and recycling of electronic devices and batteries.

In The Box:


- Soccer Wireless Speaker
- Base
- Charging Cable
- User Manual

Specifications:


- Functions: BT, TF, USB, TWS, LED, IPX5
- Speaker: 10W
- Battery: 3.7V 1500mAh

A CLOSE LOOK AT YOUR GOAL BEAT SPEAKER

Front of Speaker



1. Power / Mode Button
Press and Hold to power ON/OFF the speaker
Press to change input modes between BT, USB and TF mode
2. Play / Pause / LED Button
Press to play or pause the track
Press and Hold to change LED modes
3. Prev / Decrease Vol Button
Press to skip to previous track
Press and Hold to decrease volume
4. Next / Increase Vol Button
Press to skip to next track
Press and Hold to increase volume



Back of Speaker

CHARGING THE SPEAKER

Plug the USB Type-C connector of the included charging cable into the USB Type-C charging (DC5V INPUT) port on the back of the speaker. Plug the USB Type-A (large USB) connector into a USB power source such as the USB port on a computer, or a 5V USB wall adapter (not included).
Note:
During low battery, you will hear a tone, indicating that your speaker needs to be charged.
The LED indicator will turn solid RED when charging.
After being fully charged, the LED indicator will turn OFF.

BLUETOOTH PAIRING

1. Power the speaker ON. A tone will be heard and the speaker will enter Bluetooth pairing mode, The LED indicator will quickly flash BLUE.
2. Set your mobile device to search for Bluetooth devices. When the list appears,select **WL-SCBSPK** from the found devices.
3. After a successful pairing, a tone will be heard. When play music, the LED indicator will turn solid BLUE.

CHANGING INPUT MODES

Press the [⟲] button to change input modes (BT/TF/USB). A tone will be heard during each mode.
Note: A TF card or USB device must be inserted when you select TF or USB mode.

CHANGING LED MODES

Press and hold the [⏻] button to change LED modes and turn ON or OFF the LED lights.

TWS PAIRING MODE

If you have two **WL-SCBSPK**, you can enjoy both at the same time. Power ON both speakers, double press the [⏻] button of either speaker to wireless connect with the other one. Once being paired successfully, you will hear a tone. Go to the Bluetooth settings menu on your phone. Connect to the device listed as **WL-SCBSPK**.
To disconnect TWS pairing mode, please doulbe press the [⏻] button of either speaker, you will hear a tone to indicate the two speakers have been disconnected with other.

70x110mm