



LED UNDER CABINET LIGHT

Model Numbers: 0025-0022 and 0025-0021



Questions, problems, missing parts?
Before returning to your retailer, call our customer service at
1-800-285-8051 Monday – Friday 8:00 a.m. – 5:00 p.m. CST

PACKAGE CONTENTS

A



C



B



D



E



PART	DESCRIPTION	QUANTITY
A	LED Under Cabinet Light	1
B	4 ft power cord	1
C	12 in. linking cable	1
D	Cord clip	3
E	Captive mounting screw	2

Note: Hardware not shown to actual size.



SAFETY INFORMATION

WARNING: These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with these instructions, current electrical codes, and/or the current National Electric Code (NEC). Disconnect power to the unit prior to installation.

WARNING: To reduce risk of fire, electric shock, or injury to persons,

- Always be sure that power supply is turned off at fuse box or circuit breaker before installing, cleaning, or servicing the fixture.
- Do not turn on fixture with missing or damaged lens.
- There are no serviceable parts inside the fixture.
- If attached to a movable cabinet, route and secure cords so that they will not be pinched or damaged when the cabinet is pushed to the wall.
- Not intended for recessed installations in ceilings or soffits.
- Suitable for indoor dry locations only.
- Not intended for surface installation inside built-in furnishings such as kitchen cabinets, china cabinets, or trophy cases.
- The National Electric Code (NEC) does not permit cords to be concealed where damage to the cord's insulation may go unnoticed. To prevent fire damage, do not run cord behind walls, ceilings, soffits, or cabinets where it may be inaccessible for examination. Cords should be visually examined periodically and immediately replace when any damage is noted.
- Do not alter cords in any manner.
- Do not touch hot lens.
- Keep fixtures away from curtains and other combustible materials.

WARNING: Injury to persons and damage to the fixture and/or mounting surface may result if the fixture is pulled from the surface. To reduce the likelihood of such injury or damage, mount to a surface that is mechanically sound. The mounting surface must be at least 1/2 inch thick.

SAVE THESE INSTRUCTIONS. For safest operation, read and become familiar with complete installation instructions prior to use. Pay close attention to this manual and stay within its guidelines when using this product.

CAUTION:

- If you have any doubts about how to install this lighting fixture, or if the fixture fails to operate completely, contact a qualified licensed electrical contractor.
- All parts must be used as indicated in this manual. Do not substitute any parts, leave parts out, or use parts that are worn out or broken. Failure to obey this instruction could invalidate the ETL certification.
- This fixture has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.
- Not for use in dimming circuits.
- Use only the plastic clips provided to secure the cords.
- Not for use with plastic furniture.
- Do not mount over a sink or stove.
- LEDs emit bright light. Avoid looking directly at the light source.
- These models (Patriot Lighting® 346-0701 and 346-0700) are compatible only with each other.
- The maximum number of fixtures per run cannot exceed any the following: 12 of the 18 inch fixtures (Patriot Lighting® 346-0701); 8 of the 24 inch fixtures (Patriot Lighting® 346-0700); nor the combined fixture wattage of 120W where 346-0701 = 9 watts and 346-0700 = 15 watts.


PREPARATION

Before beginning assembly, installation, or operation of product, make sure all parts are present. Compare parts with package and hardware contents list on page 1. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.


Tools Required for Assembly (not included): Philips screwdriver or screwgun with Philips bit, measuring tape and safety glasses. Estimated assembly time: 10 minutes

INSTALLATION INSTRUCTIONS

1. Determine the desired location, keeping in mind the distance to the nearest receptacle. When determining placement, note that the power cord can be attached to either end of the fixture. Use a Philips screwdriver (or screwgun with a Philips bit) to secure fixture (A) to mounting surface using the captive mounting screws (E) included. Mounting surface must be at least 1/2 in. thick. For installation of a single fixture, skip to step 3.




2. Repeat step 1 for all fixtures to be linked to one power cord. Be sure to locate fixtures (A) such that the linking cable (C) can reach the power ports on the ends of the fixtures and make a secure connection. Leave a minimum of 2-1/2 in. clearance between fixtures for linking.




3. Attach the power cord (B) to the end of the fixture that is closest to the receptacle to be used. Plug other end of power cord into receptacle.

Use rocker switch on the fixture for high/low control.



4. Peel backing off cord clips (D) and affix to desired locations to help keep cords out of sight.

Use roll switch on the power cord for on/off control.



CARE AND MAINTENANCE

- Use only a mild soap and/or water with a soft cloth to clean the fixture. Harsh chemicals will damage the fixture. Do not wipe the fixture with a rough cloth that may scratch the finish or the lens.

TROUBLESHOOTING

- 1) The light does not come on at all:
 - a) Advance roll switch on power cord one time to turn on fixture.
 - b) If outlet is on a switched circuit, make sure the wall switch and circuit breaker are on.

If neither a) nor b) fixes this issue, please consult a certified electrician.

FIVE-YEAR LIMITED WARRANTY

If, during normal use, this PATRIOT LIGHTING® lighting fixture breaks or fails due to a defect in material and workmanship within five (5) years from the date of original purchase, simply bring this lighting fixture with your original sales receipt back to your nearest MENARDS® retail store. At its discretion, PATRIOT LIGHTING® agrees to have the product or any defective part(s) repaired or replaced with the same or similar PATRIOT LIGHTING® product free of charge, within the stated warranty period, when returned by the original purchaser with original sales receipt. This warranty; (1) excludes expendable parts including but not limited to light bulbs; (2) does not cover damage that has resulted from abuse or misuse; and (3) does not cover any losses, labor, injuries to persons/property or costs. This warranty does give you specific legal rights and you may have other rights, which vary from state to state.



Questions, problems, missing parts?
Before returning to your retailer, call our customer service at
1-800-285-8051 Monday – Friday 8:00 a.m. – 5:00 p.m. CST