

Bluetooth®

AQUABOOST BOOM

Wireless Bluetooth Speaker



tzumi®

FEATURES

Get all the bass you need in this portable, versatile Bluetooth speaker. The Aquaboot Boom Speaker features an easy to control interface, hands-free chatting via your mobile phone, and the ability to play music via micro-SD cards and USB flash drives. Let the music flow!


- Crystal clear audio and rich bass
- Play music via Bluetooth, micro-SD or USB
- Hands-free chatting via Bluetooth
- 3-4 hours of playback time
- Play up to 33ft away

WHAT'S INCLUDED

1. Wireless Bluetooth Speaker
2. Micro-USB Charging Cable
3. User Guide

PRODUCT OVERVIEW

1. Power
2. TWS/Play/Pause/Hands-Free
3. Volume Down/Previous Track
 - a. Volume Down: Long Press
 - b. Previous Track: Click
4. Volume Up/Next Track
 - a. Volume Up: Long Press
 - b. Next Track: Click
5. Micro-SD Card Port
6. USB Port
7. Micro-USB Charging Port
8. LED Indicator



PAIRING THE SPEAKER TO A BLUETOOTH DEVICE

1. Press and hold the power button for 3 seconds to turn the speaker on.
2. Open your device Bluetooth menu and select "Aquaboot Boom".
3. You will hear a tone to confirm that your device has successfully paired to the speaker.
4. You are now ready to go. Be sure to turn the speaker OFF when you are done to conserve battery life.

CHARGING THE SPEAKER

1. Use the included Micro-USB charging cable to connect the speaker to a USB power source.
 - A LED indicator light will turn solid red while charging.
2. The LED indicator light will turn off once fully charged.
3. Be sure to disconnect the cable when charging is finished.

USING THE SPEAKER

1. After pairing to a Bluetooth device, inserting a Micro-Sd card or attaching a USB flash drive, the speaker will automatically detect the music source and will be ready to play.
2. If there is more than one music source available, press the Power button to choose between sources.
3. Press the play button to play/pause.
4. Press the '+' button to go to the next song/track, or the '-' button to retract to the previous song/track.
5. Press and hold the '+' or '-' buttons to increase or decrease the speaker volume.

FM MODE

1. To use the FM radio mode, plug in the USB charging cable to be used as the receiving antenna.
2. Press the Power button to switch to FM mode.
3. Press the M button to scan all available radio stations, once the scan is completed, press '+' or '-' to go to the next/previous station.

HANDS-FREE PHONE CALL

1. When you have an incoming call, you will hear a ring tone through the speaker.
2. Press the Play/Pause button to answer the call.
3. When finished, press the Play/Pause button again to end the call.
4. Press and hold the Play/Pause button to reject an incoming call.

TWS MODE

1. This speaker can be linked to a second speaker to create a stereo sound system.
2. To use this function, you must have a second speaker the same model as this (8226).
3. Before pairing the speaker to a device, press and hold the M button on both speakers to link them to each other.
4. Once linked, proceed with 'PAIRING THE SPEAKER TO A BLUETOOTH DEVICE' section.

GENERAL TIPS

- The micro-SD card port reads micro-SD cards to play music.
- The USB Port reads USB flash drives to play music.
- The speaker will reconnect automatically once turned on if your device has previously been paired.
- It should take about 3 hours to fully charge the speaker.

SPECIFICATIONS

Playback Time: 3-4 hours
Music Playback: MP3, WMA, WAV
Charge Time: ~3 hours
Charging Type: Micro-USB
Output Power: 5W
Working Distance: 33ft
Battery: 1200mAh Lithium (rechargeable)
Weight: 15 ounces

PRECAUTIONS

- Keep away from liquids.
- Do not take apart.

If you have any other questions or issues with product use or care, please contact tzumi Technical Support at: **1-855-GO-TZUMI or support@tzumi.com**

tzumi®
live awesome.



tzumi® AquaBoost Boom. Distributed by tzumi® Inc. NY, NY 10016
©Copyright 2021 tzumi All Rights Reserved. Product subject to change without prior notice. Made In China.