


设计版本号	产品名称 Product name	比例 scale	日期 Date	设计师 Designer	审核 Audit
Rev_V0_EN	DR-HTF028S_美规UG	1: 1	20260817	Dove	Joan
Hesung innovation 和生创新	材质印刷与 技术要求 材质: 157G铜版纸双面覆哑膜 印刷要求: 双面彩色印刷, 图稿清晰、不开裂、不发皱。 对折要求: 上下风琴折页 色值要求: 蓝 C90 M70 Y0 K0 		字体 Fonts	Manrope	尺寸 Size 单页尺寸: 160*130 mm 总长: 390MM

图纸设计禁止修改，尺寸以实际刀模图为准



IMPORTANT SAFETY INSTRUCTIONS




General Safety

- Read all instructions before using the appliance.
 Do not use the appliance if you are ill or if you are pregnant. Do not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
 The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and/or knowledge, unless they have been given personal instruction concerning use of the appliance and are made responsible for their safety.
Operation Safety
 1. Place the appliance on a flat, dry surface before use.
 2. Do not immerse in water or any other liquids.
 3. Do not use the appliance until the base is installed.
 4. Do not touch your fingers, penicils, or any other objects to the grill while in operation.
 5. Do not attempt to repair or modify any electrical or mechanical functions on the appliance. All servicing should be performed by qualified persons only.

Electricity Safety

- [illegible]

折页压痕线



Cleaning Instructions


1. Always turn off and unplug the appliance before cleaning.
2. Gently wipe off the dust with a soft, dry cloth.
3. Use a soft, dry cloth or a cotton-tipped swab to remove any dust from the air inlet.
4. DO NOT use cleaning agents.
5. DO NOT use abrasive scrubbers.
6. Fire or electrical shock hazard. DO NOT immerse the main unit in water. Never allow water to get inside the appliance.
7. Except for cleaning, any servicing should be performed by an authorized service representative.
8. Store in a cool, dry area and keep the cable out of high-traffic areas to avoid tripping hazards.

**FOR HOUSEHOLD USE ONLY
READ AND SAVE THESE INSTRUCTIONS**

Battery Replacement

1. Remove the battery cover in the


3. Push the battery cover back into place.



User Servicing Instructions (Fuse)

This appliance features a fused safety plug that protects against overload or short-circuit situations. If the fuse blows, please cut off power and follow the below instructions or consult a qualified electrician.

1. Grasp plug and remove from the reospace or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
3. Remove fuse carefully. Push the fuse from the other side to remove the fuse.
4. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse.
5. Close fuse cover. Slide closed the fuse access cover on top of attachment plug.



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation emission limits suitable for use in an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20




Devises 6

-  **Power**
 - Touch to turn the fan on or off.
-  **Mode**
 - Switch between Normal/Natural/Sleep/Auto mode.
 - Long press for 3 seconds to multi/unmute.
-  **Increase**
 - Increase fan speed (1-12 levels).
-  **Decrease**
 - Decrease fan speed (1-12 levels).
-  **Timer**
 - Select to set a timer (0-12h).
-  **Oscillation / Wi-Fi Connection**
 - Sweep airflow horizontally (80°).
 - Long press for 3 seconds to start network settings and device pairing.

Note: Long press  and  for 10 seconds to restore factory settings.

Working Modes

- Normal Mode**
The fan runs at a fixed speed.
- Natural Mode**
Fan speed goes up and down intermittently to replicate the natural breeze.



 Customize the fan speed to your preference.



- 1 Launch the DREO app and sign in or create an account.
Tip: Verify your email address to continue.
 - 2 Hold  for 5 seconds to start Wi-Fi connection settings.
Tip: The icon  will keep flashing when pairing.
 - 3 Tap  and select **Smart Tower Fan 562S (2nd Gen.)**.
Tip: Enable Bluetooth and plug in the appliance.
- Now you can control the appliance on your app!
Tip: To restart network setup, hold  again for 5 seconds.
- *To learn more, please visit www.dreo.com

DREO CUSTOMER CARE

[illegible]

Warranty Limitations and Exclusions

[illegible]

Reach out to us, it's easy!

 (888) 290-1688 (Mon-Fri, 9:00am-6:00pm PST/PDT)
 support@dreco.com
 www.dreco.com
 DRECO PTE. LTD.
 1 COLEMAN STREET, #05-05, THE ADELPHI, SINGAPORE 179803

	裁切线	图层使用规范： 1、备注信息图层为非印刷区域，展示印刷物料基础信息。 2、刀板线、备注工艺、尺寸层展示印刷工艺部分。 3、画面信息层展示印刷展示图片与文字。 *电子文档为Adobe Illustrator制作
	正折线	
	反折线	
	出血位	
	粘胶区域	

10					
草稿 检查事项 会签以“√”形式确认 (负责部门/功能确认)					
审稿检查事项 商标规范 字符高度 工艺材质 颜色标识 产品文案 条码检查 厂址 全成分 警告标语 执行标准 产品尺寸 外/内箱尺寸 OEM信息* 产品包装信息					
请相关部门确认产品、包装等信息！ *OEM信息： 委托方及被委托方信息（名称、地址、邮编、电话、生产许可证、卫生许可证）					
设计师		审核	产品负责人	法规	采购