
英语【English】

Smart Projector



HY300ATV

※Quick Installation Guide※

Attention

Please read this manual carefully before use and keep it for future reference.

1.The projector is non dustproof or waterproof.

2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.

3.Please use the original power adapter. The projector should work under specified rated power supply.

4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.

5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.

6.Regularly clean projector vents, or dust may cause cooling malfunction.

7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.


8.Please handle with care during daily use.


9.Please cut off the power if the projector is out of use for long time.

10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.


Structure description

This manual is for reference only. It is subject to change without prior notice. This company reserves the right of final interpretation.






Remote Component and Functions




Bluetooth remote controller pairing




Press the power button on the remote control to turn on the device. It will automatically pair, eliminating the need for manual pairing.

Language Setting

Select your desired language and press the OK button.



Skip



Wi-Fi

To choose the network and type the password that you want to connect to.




Sign In Google




Google Play Store

Apps - Open Google Play Store, In the Google Play Store, applications can be installed with one click, and they can be used directly after installation.




Networking Settings

Settings - Network & Intemet, WIFI “ON”,select objective WIFI ID and input password to connect internet.




About Settings

Settings - Device Preferences - About, enter to setup projection mode, System update, Factory reset.




Date & Time Settings

Settings - Device Preferences - Date & Time Setting, enter to Set time zone and Use 24-hour format.




Language Settings

Settings - Device Preferences - Language Setting, enter to setup language and select input method.




Display & Sound Settings

Settings - Device Preferences - Display & Sound Setting, enter to Screen resolution, Screen position, Sound Settings.




Screen saver Settings

Settings - Device Preferences - Screen saver Setting, Screen saver time setting (The projector will enter the screen saver mode after the set time elapses when there is no operation or playback). When the projector enters the screen saver mode, you can exit it by pressing any key.




Accessibility Settings

Settings - Device Preferences - Accessibility Setting, enter to Captions,High-contrast text,Text to speech,Accessibility shortcut.




Press "Projector Settings" on the remote control, Enter to Settings

Enter to Picture, Sound, Display, Input, System settings.




Picture Settings

Settings - Picture , Enter Picture Mode and Color Temperature for setting.




Sound Settings

Settings - Sound , Enter Sound Mode and Bluetooth Speaker for setting.




Display Settings

Settings - Display , Enter Projection Mode, Auto Keystone, Manual Keystone, Keystone Reset, Auto Focus, Scale Mode, Screen Zoom, Advanced Settings.




HDMI™ Signal

Press "Source" on the remote control, Enter to HDMI.
After connecting projector to other output device, enter HDMI or Audio/Video.




USB Signal

Press "Source" on the remote control, Enter to USB.



Google Cast Settings

This function can only be used if the device supports the Google Cast protocol.



Safety instructions

• Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.

• Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.

• Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations) ,etc. Strong ambient light (avoid direct sunlight), etc.

• Do not cover projector vents.

• Please use the original power adapter.

• Keep adequate ventilation and make sure vents are not covered to avoid projector overheating

• When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.

• Do not bend or drag the power cord.

• Do not put power cord under projector or any heavy objects.

• Do not cover other soft materials on power cord.

• Do not heat the power cord.

• Avoid touching power adaptor with wet hands.

Disclaim

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.



Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm toyour eyes. Kids should use the projector under thesupervision of adults.

Thanks for purchasing! Need help?
Please send email inclose item name to our BrandSupport Team (support@magcubic.com)in order to get better experience, promptreply and further assistance