


Automatic Pet Feeder



User Manual

Model: APF03

Thank you for purchasing our product.

For more latest products, parts and accessories,
please contact: Betterlifemast@gmail.com
For any assistance please contact us.



Betterlifemast@gmail.com



Facebook

Use the iPhone camera or GoogleChrome
to scan the QR code above.

Table of Contents

- Introduction
- Safety Precautions
- Product Overview
- Assembly Instructions
- Operating Instructions
- Maintenance and Cleaning
- Troubleshooting
- Warranty Information
- Contact Information

Introduction

Thank you for purchasing the Automatic Pet Feeder. This device is designed to provide a convenient and reliable way to feed your pets, ensuring they receive the right amount of food at the scheduled times. Please read this manual thoroughly before using the product to ensure its proper use and maintenance.

Safety and Usage Guidelines

- Water Exposure:

Do not immerse the control panel in water. The base unit should never be submerged, as this may damage electronic components.

- Keep Clear:

Do not place anything on top of the pet feeder. The unit starts automatically.

- Proper Disposal:

Dispose of all packaging materials responsibly. Some items may be packed in polybags, which can cause suffocation; keep these away from children and pets.

- Child Safety:

Do not allow small children to play with, in, or around the pet feeder. Close supervision is necessary when any appliance is used by or near children.

- **Intended Use:**

This feeder is designed for use with dogs or cats only. Do not use with puppies, kittens, or pets with physical disabilities that prevent them from reaching the food tray.

- **Indoor Use Only:**

Use indoors only. Check operation frequently to ensure proper dispensing. The feeder is for dry food use only—do not use wet, canned, or moist food.

- **Placement:**

Always place the feeder on a level surface. Before leaving for an extended period, replace batteries with new ones.

- **Foreign Objects:**

Do not place any foreign objects in the feeder. Do not disassemble the feeder, except as instructed in the operating guide.

- **Electric Shock Prevention:**

If using a power cord, keep it and the plug dry. Do not unplug by pulling on the cord; grasp the plug instead.

- **Damaged Parts:**

If the power cord or plug is damaged, or if the feeder is malfunctioning or damaged, contact the Customer Care Center immediately. Do not attempt repairs yourself.

- **Portable Appliance Safety:**

To reduce the risk of electrical shock, do not place or store the appliance where it can fall into water (e.g., a tub or sink).

- **Unplug When Not in Use:**

Always unplug the appliance when not in use, before adding or removing parts, and when cleaning. Do not unplug by pulling on the power cord.

- **Proper Use:**

Use the pet feeder only as intended. Do not modify the feeder or use attachments not recommended by the manufacturer.

- **Weather Exposure:**

Do not install or store the feeder in locations exposed to weather or temperatures below 40°F.

- **Carrying the Feeder:**

Lift and carry the feeder using both hands, holding the food tank base, while keeping the unit upright. Do not lift by the lid, food tank, bowl, or bowl holder.

- **Power Cord Safety:**

Keep the power cord positioned out of the way of foot traffic to avoid tripping. If you are concerned about pets chewing on the cord, use a cord conduit for protection.

- **Wet Plug:**

If the plug gets wet, turn off the electricity to that wall outlet immediately. Do not attempt to unplug the device.

- **Extension Cords:**

If an extension cord is necessary, use one with a proper rating.

- **Final Inspection:**

After installation, examine the appliance. Do not plug it in if there is water on the power cord or plug.

- **Read All Notices:**

Read and observe all important notices listed on the pet feeder and in the packaging.



Product Overview

Package Contents

- 1 x Automatic Pet Feeder
- 2 x Removable Stainless Steel Bowl
- 1 x 5V Power Adapter & Cord
- 1 x Desiccant Bag
- 2 x Feeding tray
- 1 x User Manual

Product Diagram

- ① Desiccant Carrier
- ② Lid Finger Grips
- ③ Food Tank Lid
- ④ Food Tank
- ⑤ Control Button
- ⑥ Indicator Light
- ⑦ Food Outlet
- ⑧ Removable Stainless Steel Bowl
- ⑨ Base Unit
- ⑩ Feeding Tray
- ⑪ Power Socket
- ⑫ Battery Compartment Cover




LCD Screen and Control Pannel

Indicator status:

Blinking red, waiting for connection

Solid red, disconnected


Solid green, connected



Assembly Instructions

Unpack the Feeder: Carefully remove all components from the packaging.


Assembling the Feeding Tray



- Install the food tank into the base. (**Attach the Hopper:** Securely attach the hopper to the base unit.)
- Put the removable stainless steel bowl into the feeding tray. **Install the Feeding Tray:** Slide the feeding tray into the designated slot on the base unit.

Note:

- Please empty and remove the tray before moving the feeder.
- Hold the base instead of any other parts when lifting the feeder.




Placing the Desiccant Bag

Open the food tank lid and put the desiccant bag (included, 1 bag) into the desiccant carrier.

Note:

- 1 . It is recommended to use and replace the desiccant bag once every half month.
- 2 . Please remove the desiccant bag before cleaning the food tank lid.



Connecting Power

- Use the included power adapter to connect the feeder to a power source. The feeder enters the connection state and the red light flashes
- Open the battery compartment cover at the bottom of the base, and install 3 alkaline D batteries (not included).


Important Battery Installation Notice

Please ensure that the battery is installed in the pet feeder.

Without the battery, a power failure will cause the machine to lose its settings and restore to the factory default settings.

Note:

- Batteries are not included.
- Before connecting to the power source, make sure all parts are clean and completely dry.
- The icon on the screen blinks when the battery is too low (<10%)
- Change the batteries every 6 months if the feeder is not in use for a long time.
- It is recommended to use both the battery and adapter in case of any power cut-off.
- When the power cord is unplugged, the battery will last for approximately 20 days.



Filling the Food Tank

- Fill the food tank(Hopper) with dry pet food.

Note:

- Do not use canned, wet, or moist pet food.
- Recommended kibble size is 0.07-0.48 inches / 2-12 mm in diameter.

Maintenance and Cleaning

- **Cleaning the Hopper and Tray:** Detach the hopper and tray from the unit and wash with warm soapy water. Rinse thoroughly and dry completely before reassembling.
- **Cleaning the Base Unit:** Wipe the base unit with a damp cloth. Do not submerge in water or use harsh chemicals.

Troubleshooting

Common Issues:

If Problems Persist:

Contact Customer Support at **Betterlifemast@gmail.com** for further assistance.

Warranty Information

This product comes with a 12-month warranty covering both parts and labor, valid from the date of original purchase.

If any problems occur, please contact Betterlifemast@gmail.com immediately to launch a warranty claim. Specify the model number and your Amazon order number. Our customer service representative will respond within 1 business day, advise you on how to correct the problem yourself, or instruct you on how to return the defective unit to us for repair or replacement.

We can only provide after-sales service for products sold by brand-authorized retailers and distributors. If you have purchased your unit from a different place, please contact your seller for return and warranty issues.

Contact Information

For assistance or warranty service, please contact our customer support team:

- Email: Betterlifemast@gmail.com

INSTRUCTAPP IONS

(1)DownloadtheApp

Download [Tuya](#) Smart App from the App Store (IOS devices) or Google Play (Android devices)



(2)Signuptheaccount

Create your account and follow the set up instructions in the [Tuya](#) app



APP INSTRUCTIONS

(3) Add the Feeder to Your APP


A. Before Connecting the App, Please Verify the Current Status of Your Feeder :

The indicator light is flashing red and the feeder is in pairing mode.

B. Take out your phone, turn on WiFi, and start pairing the feeder.

C. The app will automatically pop up after detecting the feeder device.


Click "add" and Select Wi-Fi, enter the password, and click Confirm to complete the addition.



APP INSTRUCTIONS

If the feeder does not pop up or the device is not detected, click "Add Device" and add the feeder on the next page. You can also add it manually by searching the directory.

Directory: Small Home Appliances → Pet → Pet Feeder (Wi-Fi)



APP INSTRUCTIONS

Feeding Plan & Manual Feeding

A. Manual Feeding

1. Tap the "+" or "-" button to adjust the number of portions.
2. Tap "Feed" to dispense food manually.

B. Setting a Feeding Plan

1. Tap "Meal Plan" to open the settings page, then tap "Add" to create a new feeding plan.
2. Set the feeding time, feeding date, and number of portions (up to 30).
Tap "Save" to confirm.
3. Repeat by tapping "Add" again to create additional feeding plans.


C. Viewing Feeding Records

Tap "Feed Record" to check the feeding history and ensure your pet is being fed on schedule.

Note:


1. You can create up to 10 feeding schedules.
2. Each feeding can dispense up to 30 servings.
3. Short-press the Feed button on the device to manually feed once.
4. Long-press the WiFi button for 5 seconds to restore factory settings.
You will then need to re-add the feeder to the Tuya app (previous feeding schedules will not be lost).

5. The feeder requires a power cord to operate. It is battery-only, to maximize battery life, the feeder will disconnect from the internet and cannot be controlled from your phone, but feeding schedules will continue normally.



More Settings

Tap the Settings button to customize the feeder name, Share device, Set the device network, Offline Notification & Message notification Setting



FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Klein Blue Home Inc
Betterlifemast@gmail.com
136-61 41St Ave Unit 167, Flushing NY 11355

