


User manual

Speaker WP-03D



Operation Instructions



- **Power on/off:** Long press the button for 3 seconds.
- **Light switching/off:** Press briefly in sequence to switch the color of the ambient lights or turn them off.
- **Call back:** Double click the button.
- **Reset:** Soft switch machine crashes, long press the power button for 8 seconds to reset and shut down.



- **Play/Pause:** Short press the button.
- **Next song:** Double-click the button.
- **Previous song:** Triple-click the button.
- **Answering/hanging up calls:** Short press the button.
- **Mode switching:** Press and hold for 2 seconds in sequence to switch to BT/Micro SD/FM mode.



- **Volume +:** Press and hold the button to rapidly increase the volume.
- **Volume +:** Press the button continuously to increase the volume step by step.



- **Volume -:** Press and hold the button to rapidly reduce the volume.
- **Volume -:** Press the button continuously to reduce the volume step by step.



- **TWS connected or disconnected :** Press the button briefly.

FM

Plug the TYPE-C interface into the power cord and use it as an FM external antenna.

- * In FM mode, tap the ► button to search for channels.
- * Press ► button twice in a row to go to the next channel.
- * Press ► button three times in a row to go to the previous channel.

Connection

Micro SD card: Insert Micro SD card (MP3, WAV audio only).

Type-c port: Charging.

Connect the USB cable to the PC/ power bank/adaptor to obtain power. When the indicator light shows red, it indicates that charging is in progress. The light going out indicates that it is full.

Wireless connection

Turn on the speaker and connect the phone BT to "WP-03D"

Note: Before wireless connection, the blue light blinks, and once paired, it will automatically connect when used again.

TWS stereo mode Settings

1. Turn on two identical speakers and do not connect them to your phone for the moment.
2. Press the  button on either speaker briefly. When you hear "du du", release it. After 3 to 4 seconds, you will hear a "ding ding" sound, indicating that the TWS connection is successful. Connect your phone's BT to the "WP-03D" device. The two speakers will play music in sync, creating a surround sound effect.

3. In TWS connection mode, the left and right channel devices can be operated synchronously: play/pause, next song/previous song, volume up/volume down, etc.
4. When restarting, the TWS will reconnect automatically.
5. To disconnect TWS: Press the  button briefly. When you hear "din", the connection is disconnected.
6. When the main speaker is turned off, the secondary speaker will also turn off simultaneously. To restart, you need to turn on both speakers separately.

The application of TWS technology makes the left and right channels of the speaker independent of each other and generally without physical connection, forming a stereo channel to provide users with a better hearing experience.

Specifications

Model	WP-03D
BT	BT5.3
Micro SD card	Support MP3, WAV
TWS	Support
BT receiving distance	Straight line accessibility ≥ 10 meters
Charging Voltage	DC 5V/1A
Battery Life	2.5-12hours(subject to playback content and volume)
Charging time	About 2 hours
Battery Capacity	1000mA3.7Wh
Channel system	Mono
Light control	RGB iridescent lights
Frequency	60Hz-20KHz
Radio	87-108MHz
Waterproof performance	IPX5
Ambient temperature	-0°C ~ +60°C
Storage temperature and humidity	Working: 0~40°C, working humidity <70%, storage humidity <70%

Warnings and precautions when using the product

- Do not use corrosive cleaning agents to clean the product.
- Do not allow this product to be heated or close to fire.
- Do not allow this product to be exposed to direct sunlight for a long time.
- Do not dispose of this product in the fire to avoid explosion.
- Do not attempt to remove this product for any modification.
- If you do not use this product for a long time, please store it in a dry environment, and charge the speaker at least once every 2 months to extend the life and avoid extreme temperature and dust.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.