


TIANNOYA

Space Heater



III. Before Use

1. Transportation and Storage

Handle the product with care during loading and transit. Do not throw, drop, roll, or drag it. Protect it from direct sunlight and rain.


The storage area must be well-ventilated, free of corrosive gases, and maintain a relative humidity of no more than 85%.

Do not place heavy objects on top of the packaging, store it outdoors, or stack more than six cartons high.

IV. Installation Options

This heater is designed for freestanding installation only.

★ FREESTANDING



Align the base of the heater with the mounting holes on its underside, then secure it with screws.


Insert the caster wheels into the holes on the base and tighten the screws firmly.

Tiannoya Space Heater

Tiannoya Space Heater

★ WALL MOUNTED

(Available for selected models only)



Measure the distance between the mounting holes and mark their positions on the wall. Use a spirit level to ensure accurate alignment.

Drill holes at the marked points and insert the expansion bolts.


After the expansion bolts are securely fixed, hang the heater onto them through its mounting holes. Then slide the unit downward to lock the bolt heads into the keyhole slots, preventing accidental dislodgement.

For optimal performance, install the heater as close to the floor as possible. However, the bottom of the unit must be at least 20 cm (8 inches) above the ground. Ensure no obstructions are within 50 cm (20 inches) above or on either side of the heater. The maximum installation height must not exceed 180 cm (71 inches).


Tiannoya Space Heater

Tiannoya Space Heater

SAFETY INSTRUCTIONS




Do not place or cover items (e.g., clothing) on top of the heater.




Do not use power strips or extension cords, as they may overheat or damage the plug due to excessive power draw.




Keep children and pets away from the unit to prevent injury or tipping.



Avoid overloading electrical circuits. Do not plug multiple high-wattage devices into the same circuit.



Maintain a minimum distance of 1 meter from flammable materials such as curtains, blankets, paper, and fibers.




When the unit is not in use, store it properly and protect it with a dust cover. Do not allow any foreign objects to enter the heater openings.

Tiannoya Space Heater

Tiannoya Space Heater



APP FUNCTION



Tiannoya Space Heater

Tiannoya Space Heater




APP FUNCTION



Tiannoya Space Heater

Tiannoya Space Heater


SMART LIFE OPERATING METHODS



Tiannoya Space Heater

Tiannoya Space Heater

OPERATING INSTRUCTIONS



Tiannoya Space Heater

Tiannoya Space Heater

! SAFETY WARNINGS

- Before use, always ensure the power cord is fully uncoiled and kept away from the heater body, to prevent the insulation from weakening or splitting.
- Always switch the appliance off before unplugging it from the power socket.
- Keep the appliance and its power cord away from hot surfaces. Do not route the cord under furniture or other appliances.
- Arrange the cord so that it does not create a trip hazard.
- Do not place the appliance near a radiant heat source.
- Do not insert or allow foreign objects to enter any ventilation or exhaust openings, as this may cause electric shock, fire, or damage to the appliance.
- This heater contains internal components that are hot, arcing, or sparking. It must NOT be used in potentially dangerous locations, such as areas with flammable, explosive, chemical-laden, or wet atmospheres. This heater is intended for general use only.
- Do not use this appliance near bathtubs, showers, swimming pools, or other containers of liquid.
- If the appliance fails to operate correctly, contact the Tiannoya Customer Service Team.

Tiannoya Space Heater

Tiannoya Space Heater

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.
- DO NOT cover this heater. Covering the appliance may cause overheating or create a fire hazard.
 - Extreme caution is required when this heater is used by or near children or individuals requiring supervision, especially when left operating unattended.
 - To reduce the risk of fire, keep textiles, curtains, and any other flammable materials at a minimum distance of 1 meter from the air outlet.
 - Plug this appliance directly into a wall socket. Power strips and extension cords are not designed to handle the high wattage of this heater.
 - This heater becomes hot during use. To avoid burns, do not allow bare skin to touch hot surfaces. Always use the handle when moving the unit.
 - Always unplug the heater when not in use.
 - Operate this appliance only at the voltage specified on its rating label.
 - For indoor use only.
 - Use this appliance only as described in this manual.
 - Ensure hands are dry before touching the plug or the appliance.
 - Place the appliance on a flat, stable, and heat-resistant surface.
 - Regularly inspect the power cord to ensure it is not damaged.

Tiannoya Space Heater

Tiannoya Space Heater