

Erste Paarung



Entfernen Sie die Schutzkappen



Setzen Sie die Ohrkammern in die
Leertastlöcher und schließen Sie das
Gerät.



Öffnen Sie den Deckel, setzen Sie die Ohrhörer auf, und
wählen Sie "Trafalax" zur Verbindung.



Empfohlen



Kopfhörer-Anzeiger

1. Öffnen Sie den Ladekasten und blaue LED der Kopfhörer blinkt, um den Paarungsmodus einzuschalten. Wenn das Licht ausgeht, ist die Paarung erfolgreich.

3. Paar
unten

Schallausgang

Basic Operations

	Steuerung	Links	Rechts
Musikwiedergabe	Wiederholungs-Pause	Zentraler Joystick (rechter Bereich)	
	Nächster Song	Drehschalter (rechter Bereich)	
	Verändern des Liedes/Laufzeit	Lang drücken (rechter Bereich)	
	Laufzeit ändern	Lang drücken + 1 Klick von der Station	
Anrufe	Gehe zu den Telefon	Zentraler Joystick (auf einer beliebigen Seite)	
	Ordnung festlegen	Zentraler Joystick (auf einer beliebigen Seite)	
	Anruf annehmen	2 Sekunden gedrückt halten (auf einer beliebigen Seite)	
	Sprechanschluss (Sitz und Gonge) verlassen	Drehschalter (links)	

Chirpster-Verbindungsanweisung:

1. Öffnen Sie den Deckel des Ladegeräts, schalten sich die Chirpster automatisch aus, werden als Batterie, Chirpster links und rechts Lichter blinken.
2. Nachdem die Chirpster gekoppelt sind, blinken die roten und blauen Lichter an einer der Chirpster.
3. Nach dem Koppeln mit dem Handy erscheinen die Anzeigerlichter.

LED-Arbeitsleuchte

1. Ziffern blinken: La


2. Anzeige 100: Akk

Fehlerbehebungsanhandbuch

Wenn die Öhrhörer nicht verbunden oder nur eine Seite einordnungsgefunktional, folgen Sie bitte diesen Schritten:

1. Leichen Sie als Bluetooth-Eintrag für [TunePlusB12] oder [TunePlusB13] in der Bluetooth-Liste und verbinden Sie die Öhrhörer aus.
2. Legen Sie die Öhrhörer in die Ladebox, schließen Sie den Deckel und warten Sie 5 Sekunden.
3. Wenn die Öhrhörer nach der Trennung und dem Zurücklegen in die Ladebox immer noch kein Verbindung herstellen können Sie prüfen, ob die Ladeboxschlüssel durch Schmutz verstopft sind.
4. Wenn die Öhrhörer automatisch verbunden werden? Die Öhrhörer verbinden sich automatisch mit dem zuletzt verbundenen Gerät.
5. Wenn die Öhrhörer nicht verbunden, trennen Sie bitte die Bluetooth-Verbindung mit dem vorherigen Gerät(s).

Hinweise zur Ladung der Öhrhörer



1. Wenn sich ein Ladestationskabel der Öhrhörer Wasserfest, Schweiß oder andere Verunreinigungen verunreinigen, reinigen Sie die Öhrhörer mit einem weichen, trockenen Tuch.
2. Setzen Sie die Öhrhörer in eine vollständig geladene Ladebox und schließen Sie den Deckel. Die Öhrhörer beginnen automatisch mit der Ladung.

Warnhinweise und Hinweise zur Nutzung des Produkts

Bitte vermeiden Sie jegliche chemische Reinigungsmittel zum Reinigen dieses Produkts.

Halten Sie dieses Produkt nicht auf oder bringen Sie es in die Nähe von Feuerquellen, wie z. B. einem Kachelofen.

Lesen Sie dieses Produkt nicht lange Zeit direkter Sonneneinstrahlung ausgesetzt.

Wurden diese Komponenten nicht in der Feuer- oder Explosionszone verwendet, ist das Produkt nicht für den Einsatz in diesen Bereichen geeignet.

Wenden Sie dieses Produkt nicht an, um es zu modifizieren, da es bei falscher Reparatur Komponenten enthält.

Bitte vermeiden Sie das Gehen auf dem Boden.

Wenn Sie dieses Produkt über einen langen Zeitraum nicht verwenden, legen Sie es in einer trockenen, gut belüfteten und kalten Umgebung ab, um die Gefahr von Schäden durch Feuchtigkeit zu verringern.

Hersteller: HONGKONG BAYTONG LIMITED

Address: RM 4C, 1/F TUNG LING BUILDING 60 LAL YIP ST
KOWIN TUNG BUILDING HONGKONG
hongkong@baytong.com

TuneFlux

Kurzanleitung

Offene-Ohren Kopfhörer




FIRST-TIME PAIRING




Remove the protective films.



Place the ear clips in the charging case and close the lid.



Insert the earbuds into your ears.



Place the earbuds in the charging case and close the lid.



Insert the earbuds into your ears.



Place the earbuds in the charging case and close the lid.

RECOMME

Headphone Indicator

1. Open the charging case, and blue LED of the headphone blinks to enter pairing mode. The light goes out, the pairing is successful.

3. Adjust the volume.

sound outlet

A diagram of a mouse head in profile. A grey rectangular box labeled "TOUGH AREA" has a line pointing to the snout area.

Basic Operations

	Control	Left	Right
Music playback	Play/pause	tap (seventeenth size)	
	Next song		tap three times
	Lower the volume	Long press + touch (per second)	
	Increase the volume	Long press + touch (per second)	
Convenience	Answer the call	tap (seventeenth size)	
	Call ended	tap (seventeenth size)	
	Repeat the call	Press and hold for 2 seconds (after 10s)	
	Voice assistant (Siri and Google Assistant)	tap three times	

Headset Connection Indicator Light

Open the charging case lid, the earphones will turn on automatically with red and blue lights flashing on both sides.

After the earphones are paired, the red and blue lights on one earphone will flash.

After pairing with the phone, the indicator lights will turn off.

The diagram shows a rectangular LCD screen with a black border. Inside the screen, there are ten small, white, oval-shaped segments arranged in a horizontal row. The number '100' is displayed in the center of the screen. Below the screen, there is a label 'LCD indicator' with a line pointing to the screen.

TROUBLESHOOTING GUIDE

If the earbuds fail to connect or only one side works properly, please follow these steps:

1. Select all (Push/Fx) 612: Bluetooth records from your phone and turn off Bluetooth.
2. Place the earbuds into the charging case. Close the lid, and wait for 5 seconds.
3. If the earbuds still fail to connect after disconnection and being put back into the charging case, you can check whether the charging ports are clogged with dirt.

Will the earphones automatically reconnect?

The earphones will automatically reconnect to the last connected device. (Please disconnection with Bluetooth connection with the previously paired device before connecting to a new one.)

Headphone Charging Precautions



1. If there are water stains, sweat or other impurities on the charging inlet contacts of the earbuds, wipe them clean before charging to avoid poor contact.

2. Place the earbuds into a fully charged charging case and close the lid; the earbuds will start charging automatically.

Product Use Warnings and Precautions

Do not use corrosion cleaning agents on this product.

Do not heat this product or place it near a fire source, such as a cooking stove.

Do not expose this product to direct sunlight for a long time.

Do not clean this product in fire or any explosive.

Do not attempt to disassemble this product to make any modifications, as it does not contain any repair components.

Do not use this product in the rain.

If you do not use this product for a long time, please store it in a dry environment and change the headphones at least once a month to extend its dry lifespan. Avoid storing headphones and accessories in a humid environment.

Manufacturer: HONGKONG RAYOTUNG LIMITED
Address: RM 4C, TUNG LEE INDUSTRIAL BLDG 5 LIAI YAT ST
KOWIN TUNG 68667 HONGKONG
info@rayotung.com

A graphic for the 'TuneFlux Quick Start Guide' for 'Open-Ear Headphones'. It features the brand name 'TuneFlux' in a stylized font, followed by 'Quick Start Guide' in a large, bold, sans-serif font. Below this, the text 'Open-Ear Headphones' is written in a smaller font. A line drawing of the headphones is shown, with the number '100' printed on the side of the ear cup.

FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.