

50*70mm(折后尺寸) 120g双铜)

正反印刷,风琴折


FCC Warning:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.



User Manual

wireless headset

Instructions



Product Specifications

Bluetooth version: V5.4
Distance: 10M
Charging voltage: 5V
Battery capacity: 110mAh (Lithium battery)
Charging time: about 40 minutes
Talking time: Up to 12 H
Music time: Up to 16 H
Standby time: Up to 200 H
Product size: 64,5×28,9×16,6mm
Charging port: Type-C

Using Guide

Charging the headset

1.When using the headset first time, please fully charge it. During charging, indicator light will be red; when it is fully charged, indicator light will be blue light is on for 3 seconds and then goes off. And please remember to unplug it from charger after charging is finished.

2.If the headset has not been used for a long time, in order to extend the battery life, please charge the headset once every month.

3.If the headset has not been used for a long time, when powered on again,indicator light will be delayed for a few seconds to light on.

Indicator light	
Power on/pairing	The blue light is on for 2 seconds, then the red and blue lights flash alternately
Power off	The red light is on for 2 seconds and then goes out
Charging	Red light is always on and shows the power level
Fully charged	Blue light is on for 3 seconds and then goes off
Low power	Red light comes on every 20 seconds

Using Guide

Power on

Press and hold the MFB button for 2 seconds in the shutdown state;

Power on power broadcast / LED power digital display

After power on the earpiece has a power broadcast tone, headset digital screen power digital display 5 seconds

Power off

In any state , press and hold the multi-function key for about 5 seconds , accompanied by a "power off" tone and vibration alert.

First connection of earphone

1.Turn on the Bluetooth function of your phone
2.Long press the MFB button for about 5 seconds the power off state,until the red light and blue light flash alternately.When the switch is released,the handset will hear"pairing"voice prompts(some mobile phones have no prompt sound).
3.Search for the headset model in the Bluetooth pairing interface of the phone and click to connect it.Then "connected"voice prompt will be heard.

Reconnect the phone :

Headset will connect with last mobile phone automatically.

Using Guide

Answering the call

When the call is coming, the phone number will be reported . And click MFB to answer the call.

Hang on the call

Click the MFB to end the call during the talking.

Call rejection

On an incoming call , double-click the multi-function key

Last number redial

In the connection standby state,double-click the MFB button,and click MFB again to cancel the redial:

Three-Way Calling

Answering three-way calls :
When the first call is connected, double-click the multi-function button. Dial the second call at this time (the first call is on hold) ; Double click again to hold the second call and pick up the first call.
Rejecting three-way calls :
When the first call is answered, press and hold the multi-function key for 2 seconds to reject the second call.

Volume+

Click the volume button"+"

Using Guide

Volume-

Click the volume button"-"

Previous song

Long press the volume*-"for about 2 seconds

Next song

Long press the volume*+"for about 2 seconds

Music play/pause:

Click MFB

Multipoint Connection

Paring with 2 mobile phones simultaneously

1.Pair the headset with the first mobile phone;
2.Power off the bluetooth headset and power off the bluetooth function of first mobile phone;
3.Pair the headset with the second mobile phone;
4.Power on the bluetooth function of the first mobile phone;
5.The headset will automatically reconnect with the first mobile phone; (If the phone does not have the function of automatic connection back, then you need to connect manually)

Using Guide

Battery display

Remaining power will be showed on iOS and part of Android system

Language switching(Chinese and English switching)

In pairing mode, press and hold the volume +/- keys at the same time for 2 seconds, there is a beep

Reset

In pairing mode, press and hold the multi-function button and the volume*-"key for 5 seconds at the same time, hear the beep and the red and blue lights flash 5 times at the same time

Voice dialing:

1-second press MFB in standby mode,(Precondition is that mobile phone can support voice dialing)

Supports converting stereo output

Plug the sub earbud cable into the TYPE-C connector and convert the headset to stereo output

(* headset default monaural, secondary ear belongs to optional accessories)

● Monaural (Mono)

○ Binaural (for binaural stereo sound)



Using Guide

①. After accidentally touching the retractable button, the intensity of retracting the earbud may cause certain injuries. When retracting the earbud, please pay attention to keeping your face and the earphones at a safe distance.

②. When not in use, please store the headset in a room temperature, dry, and out of reach of children. Exposure to the sun, fire, and contact with corrosive chemicals are strictly prohibited.

③. Please do not put the earphones in water soaked or humid environment.

④. When cleaning the earphones, please wipe it with a dry soft cloth. It is strictly forbidden to clean the earphones with corrosive cleaning agents.

⑤. Don't let the earphone come into contact with sharp objects to prevent it from being scratched or damaged.

⑥. Except for the normal pulling and pulling of the earphone cable, please do not pull it violently.

⑦. Please pay attention to the instructions of some specific places, such as restrictions on electronic use and dangerous places, which require turning off electronic equipment.

Turn off the headset.

⑧. Do not try to open the headset and change the battery privately, so as to avoid unpredictable danger.

⑨. Please use a quality-guaranteed travel charger to charge the headset.

⑩. There is a battery in the earphone, which should be disposed of in accordance with local regulations and should not be thrown away as daily rubbish.

Warranty Declaration

Thank you for purchasing our products. To ensure your legal rights, please read the contents of this manual carefully and keep it in a safe place.

* Disclaimers. :

This User's Manual makes no warranties, expressions of position or other implication of any kind. The products, specifications and information mentioned in this User's Manual are for reference only and may be updated on the website at any time without notice.

* Warranty Statement. :

Within the warranty period of twelve months from the date of purchase, any damage due to quality problems under normal use will be repaired free after confirmation by the manufacturer.

* The above warranty does not apply to the following.

- ①. No valid proof of purchase
- ②. Product code does not match with the product body
- ③. Beyond the scope of the product warranty
- ④. Any damage caused by human beings
- ⑤. Because of improper use caused by burning, corrosion or water diffusion signs of the product
- ⑥. Damage caused by man-made dismantling
- ⑦. Packaging and accessories are not covered by the warranty