

Portable Locator Device USER GUIDE	Find My Operating Instructions 1. Device Power On Press and hold the button for 3 seconds to turn on, accompanied by a prompt sound 2. Bind Device 2.1 Open the built-in 'Find My' app on your Apple device 2.2 Bring the device close to your iPhone, tap the "Items" tab, and select "Add" to add other supported items. 2.3 Select the item with the name 'OC TAG' and tap 'Connect' 2.4 Enter a 'Custom Name' to name your device and choose an emoji. 2.5 Agree to register the device to your Apple ID 2.6 Tap 'Done' to complete the binding successfully 3. Enable 'Lost Mode' 3.1 Open the Apple-built 'Find My' app, tap 'Items' at the bottom of the screen, and then tap the name of the item.	3.2 Under 'Lost Mode', click Enable. 3.3 Follow the on-screen instructions and click 'Continue' to enter your phone number or email. 3.4 After clicking 'Next' to verify the information, please click 'Enable' again to complete the setup. 4. Delete Device 4.1 Open the Apple-built 'Find My' app, tap 'Items' at the bottom of the screen, and then tap the item name. 4.2 Scroll to the bottom of the list, tap 'Remove Item,' and then tap 'Remove' to complete the action. 4.3 Instructions: After deleting the device, the device will emit a prompt sound, but it will not turn off and will be in pairing mode. If no device connects within ten minutes, the device will exit pairing mode, and it cannot be paired at this time. If you need to pair it, press the button once, and after the device makes a 'di' sound, it will enter pairing mode again, allowing you to pair it anew.	5. Battery Replacement: 5.1Unscrew or use the 'disassembly tab' included in the packaging to open the battery cover 5.2Carefully remove the battery and pay attention to the other components 5.3Replace with a new battery 5.4Tighten or secure the battery cover Note: Please pay attention to the other components of the product during this process, and ensure not to disassemble or forcefully tamper with them. 6. Battery Instructions: This product contains a coin-shaped battery. During the product's lifespan, the battery may need to be replaced. By observing the correct connection of the negative and positive terminals, only a battery of the same model and rated value (CR2032) can be used for replacement. 7. Important Matters: This product contains precise electronic components, including a battery. To avoid damage, loss of functionality, or other potential hazards, do not drop, hit, pierce, crush, or disassemble it forcefully,and avoid exposure to high temperatures, liquids, or areas with high concentrations of chemicals.	Find Hub User Manual 1. Power on the device Press  and hold the device button for 3 seconds to turn on the device. 2. Bind the device - Open the Google mobile system's built-in app: Find Hub; - After the pop-up window appears, select Connect; - Choice: Agree and continue; - After naming, you can connect and use the device function: click to play sound, and the device will emit music. - Remove device: You can choose to remove the product. 3. Restore factory settings: After the device is powered on, press the button 5 times consecutively. It will emit continuous beeps and reset to factory settings. 4. Shutdown: After the device is turned on, Press and hold for more than 3 seconds. The device will emit a prompt sound and enter the shutdown sleep mode. 5. Open recognition mode: When the device is powered on, pressing the button makes a 'di' sound.	 WARNING:Do not swallow the battery; there is a chemical burn hazard Choking Hazard Warning The OC TAG, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children Medical Device Interference The OC TAG contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other medical devices. To ensure safety, maintain a safe distance between your medical device and the OC TAG. We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you suspect that the OC TAG is interfering with your pacemaker, defibrillator, or any other medical device, discontinue its use immediately. Important Handling Guidelines It's normal for the OC TAG to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth. Avoid applying	pressure with sharp objects on the rubber seal or the battery terminal contacts inside the device. Do not allow moisture to enter any openings or use aerosol sprays, solvents, or abrasive materials to clean the device. Legal notice Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
--	--	--	--	---	--	--

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

