




注意

① 本来の用途以外に使用しないでください。

② 本製品を使用して接続された機器の破損・損傷・故障およびデータの消失に製品・当社は一切の責任を負いません。あらかじめご了承ください。

③ 本製品は充電時に必ず充電ケーブルを接続してください。充電ケーブルが抜かれたままに使用しないでください。充電ケーブルを接続したままに充電ケーブルを抜くと、充電ケーブルが破損する場合があります。

④ デバイスの予期せぬアップデートの理由により、各種ワイヤレス充電が使用できない場合があります。

⑤ ワイヤレス充電時は本製品およびスマートフォンが熱くなります。異常に熱い感じがした際、直ちに本製品とスマートフォンを取り外し使用を中止してください。

⑥ 製品本体から排出された液体が皮膚や衣服に付着した場合は、直ちに水道水などで洗い流すことで洗ってください。目に入った場合は流水で洗い流してください。目に入った場合、直ちに医師の診察を受けるください。

⑦ 本製品は水に仕様が適合していません。本製品を水につけたり濡らしたりしないでください。また濡れた手でネットワークケーブルに触れないでください。感電や故障の原因となります。

⑧ 本製品を使用する場合は、各自治体の指示に従って廃棄してください。

⑨ 製品に不具合や故障が生じた場合は、お問い合わせする必要があります。そのための説明書記載の内部と異なる場合があります。

⑩ 各デバイスでの充電時間はメーカー公称値と異なる場合があります。

⑪ 記載の社名、製品名などは各社の商標、商標登録です。

①ワイヤレス充電ポイント ②USB-C入出力ポート
 ③ 残量表示LED/モード表示LED
 ④ 残量表示/モード切替ボタン

本体上側面のボタンを押すと、バッテリー残量の数値(%)が表示されます。
 例: 75%

充電時は%の上に **L** マークが表示されます。
 ※本製品や接続デバイスが過充電防止に連動した場合など、出力が低い時には **L** マークが表示されません。
 ※充電時の電圧によって **L** マークが表示されない場合がありますが、いずれも仕様に依って正常な動作です。

●製品とスマホ
 充電ケーブル
 ●充電ケースや
 スマホ充電器
 ●ワイヤレス充電

7.使用方法

充電

スマートフォンへの充電



ワイヤレス充電ポイント

製品をスマートフォンのワイヤレス充電
できる位置に、ワイヤレス充電が開始されます。
できない場合は、ボタンを1回押してください。

スマートフォンが電力による装置充電を確信し、スマートフォンから本製品が
電力を確保して電力を供給するまで待機します。

カバーの厚みや材質によっては電力による装置が不安定な場合がありますが
必ずしも保証されません。

本製品は本製品とスマートフォンが発熱します。

1-2. 小型デバイスなどへのワイヤレス充電



ワイヤレス充電ポイント

本製品


本製品のワイヤレス充電ポイントと、小型
デバイスのワイヤレス充電ポイントの充
電位置を合わせる。

- 小型デバイスのワイヤレス充電ポイントは、機種によ
り異なります。
- 充電時間は小型デバイスの性能やバッテリー容量
によって異なります。
- すべて的小型デバイスに対して、動作を確保するもの
ではありません。

[illegible]

2.有線充電

2-1.スマートフォンへの充電



上図のように本製品とスマートフォンを付属のUSB-Cケーブルに接続すると、スマートフォンへの充電が始まります。

※スマートフォンへの充電が始まらない場合は、ボタンを1回押してください。

ワイヤレス充電

5秒長押ししてモードへの切り替え

- ※「低電流モード」は、
 - ・充電開始からの約15分間ケーブル接続が確立しない場合
 - ・ボタンを2回押すと充電が停止します
- ※小型デバイスの場合、充電が停止します

10

ワイヤレス充電（低電流モード）

2-3.同時充電（ワイヤレス充電+有線）

ワイヤレス充電を行う際は、ボタンを5秒長押しし、充電モード切替を行います。その後、「有線・無線充電切替」メニューが表示されます。

※「有線・無線充電切替モード」は、充電モード切替メニューから設定できます。

※同時充電時にはワイヤレス充電は最大5W、有線充電は最大10Wで充電されます。

3-2. バススルー充電について

本製品のバッテリーなどのデバイスを
をご確認ください。

iPhoneやAndroid
のために約80%付
よって名称が異なる
手順は以下の

【iPhone】「バッテリー」
「iPhoneの「設定」
「バッテリー」を

【Android】「バッテリー」
「設定」アプリをタ
のチェックをし
※機種によってま
ンのメニューバー

本製品の充電中にスマートフォンをワイヤレスポイントに重ねると、スマートフォンへの充電も開始されます（バススルー充電）。バススルー充電時はバッテリー残量の数値(%)が10時間、以下のようなLED表示「P1」2時間が交互に表示されます。

※通常のワイヤレス充電よりも充電時間が長くなる場合があります。

本製品は完全バススルー充電に対応したモバイルバッテリーです。スマートフォンとモバイルバッテリーを別回路で充電することで、本製品の充電回数減らし、バッテリー寿命への負荷を軽減します。

フォンの充電設定 残量が残っているにも関わらず、スマートフォンを満充電できない場合は、スマートフォンの充電設定を確認してください。 Androidスマートフォンは、バッテリーの劣化を軽減するために充電が停止するバッテリー保護の設定（機種により異なります）があります。バッテリー保護の設定を解除する必要があります。 「バッテリーの最適化」の解除方法 アプリをタップ「バッテリー」をタップ「充電」をタップ「バッテリーの最適化」のチェックを外します。 スマートフォンバッテリー保護の設定解除方法 「バッテリー」をタップ「バッテリーの最適化」をタップします。 価格や操作方法が異なります。詳しくはスマートフォンページをご確認ください。	5.出力モード切替 5-1.出力モード切替について 充電するデバイスやシーンに合わせてモード切替デバイスに合わせた最適な出力で充電を行います。 例: ・ワイヤレス(無線)で素早く充電したい時 →ハイパフォーマンスモード ・ワイヤレスイヤホンなど小型デバイスを充電したい時 →低電流モード 各モードの特徴につきましては、17-18ページご確認ください。 出力モード切替の操作につきましては、19-22ページについてをご確認ください。
--	--

5-2.各モードについて

本製品で設定できるモードは5つです。それぞれのモードについて、「使用シーンの例」と「特徴」を順に紹介します。

【セーフティモード】

- ・使用シーンの例
スマートフォンをワイヤレス充電する際の発熱が気になる時。
- ・特徴
最大7.5Wのワイヤレス出力でデバイスを充電します。
※スマートフォンのバッテリー残量によって出力は変動します。

【ハイパフォーマンスモード】

- ・使用シーンの例
スマートフォンのバッテリー残量がわずかで、すぐにワイヤレスで充電したい時。
- ・特徴
最大25Wのワイヤレス出力でデバイスを充電します。
※スマートフォンのバッテリー残量や発熱状況によって出力は変動します。

5-3. 出力モード切

初期設定は出力モード
モード切替一覧に付
※初期設定は「ハイバテ

1. バッテリー残量を
ボタンで1回押して残
- LED表示でずり点
3. 使用したいモードに
モード切替操作中は
設定したいモードで
定します。
4. デバイスを接続する
モード切替を完了し
て充電を初めてく
※充電が開始されな

【低電流モード】

- ・使用シーンの例
ワイヤレスイヤホンなどの小型デバイスを充電したい時。
- ・特徴
有線接続で小型デバイスを充電します。
※低電流モードを設定せずに充電を開始すると、数分後に小型デバイス
への出力が停止する場合があります。

【有線充電切替モード】

- ・使用シーンの例
ワイヤレス充電よりも素早く充電したい時や、ワイヤレス充電の発熱が
気になる時。
- ・特徴
最大35Wの有線出力でデバイスを充電します。

【有線+無線充電切替モード】

- ・使用シーンの例
スマートフォンとワイヤレスイヤホンなどの小型デバイス
を同時に充電したい時。
- ・特徴
最大50Wワイヤレス充電と最大15W(5V=3A)の有線充電、
合計20W出力で2つのデバイスを同時に充電します。

替の操作について

切替の操作は以下の手順で行います。
まずは、20-22ページをご確認ください。
ウォーマンモード「25W」です。

表示する。
液晶表示LEDを点灯させます。

手えるようにする。
減速するまで、ボタンを5秒長押しします。

切り替えて決定する。
ボタンを1回押すたびにモードが切り替わります。
ボタンを2秒長押しすると、モード切替の設定が確

液晶表示

ボタン長押し
5秒

モード

75
91.75%

18
全

※ワイヤレス(無線)、または有線でデバイスを充電している
と、モード切替の直前に設定していたモードが表示されます。

ド切替
ボタン押し
1回
18%
点滅
点灯状態でボタンを長押しする
。

セーフティー
モード
187
点滅
決定
ボタン長押し
2秒
187
点灯
キャンセル

ハイパフォーマンス
モード
25
点滅
決定
ボタン長押し
2秒
25
点灯
キャンセル

低消費電力
モード
11
点滅
決定
ボタン長押し
2秒
11
点灯

※LED表示が「点滅している状態」で秒間ボタン操作を行わない場合、出力モード切替
※出力モード切替をキャンセルした場合は、前期設定の「ハイパフォーマンスモード」(25)

この度は株式会社CICの
商品に初期不良などの
実施させていただきます。
正しくご使用いただき、
交換対応を実施させてさ

納品書兼保証書も
保証書の代わりとす

※商品保証は原則、交換
返品・返金は承っており

以下の場合保証を要し

1. 使用上の取り扱い間違い
2. 使用者による任意
3. 火災・水害などに

界はキャンセルされて、バッテリー残量表示に戻ります。
N) もしくは変更前の設定に戻ります。

8.製品保証

本製品をご購入いただき誠にありがとうございます。
 不具合がある場合、初期不良品として交換対応を
 します。
 保証期間内に発生した故障の場合も
 いただきます。

しくは、販売店にシートが
 なりますので大切に保管してください。

対応とさせていただきます。
 事項のをご承知ください。

施したにかねますので、ご了承ください。

不注意による事故(落下や水没など)。
 の内部改造による故障。
 による故障。

■ 製品お問い合わせ窓口

<https://connectinternationalone.co.jp/contact>



QRお問い合わせフォームより
 下記メールアドレスよりお問い合わせ

メールアドレス customer@connectinternationalone.co.jp

保証書【CIO-MB35W1C-10K-S2W25】
 販売店名

保証期間：1年
 お買い上げ年月日： 年 月

contact/customer/

たは
い合わせください。

tion.alone.co.jp

CIO 公式 LINE アカウント

フォローしてね!

メルマガ01 LINEでカスタマーサポート

故障時や使い方が分からない場合など、チャットだからスムーズにLINEで簡単に問合せOK! 是非お気軽にご利用ください。

メルマガ02 LINE限定クーポン

Amazonや楽天市場等でも利用いただける超お得なクーポンをLINEでいち早く公開! SALEや新商品の情報も盛りだくさんです!

販売店名

COUPON

&

SALE

お得なクーポン
セール情報

QRコードでLINEの友達を追加

QRコードをスマートフォンでスキャンしてください。



CIO 公式 YouTube アカウント

チャンネル登録してね！

メッセージ01

市場未公開情報ゲット！

開発中の商品情報や開発秘話などをいち早く公開！
市場未公開の商品情報はCIO社員が詳しく解説します！

メッセージ02

欲しい商品が見つかる！

新しくスマホやPCを買ったけどどんな充電器、製品が最適なんだろう...
CIOの製品の特長を分かりやすく解説！あなたに合うベストな製品が見つかる！

QRコードでYouTubeのチャンネル登録

QRコードをスマートフォンでスキャンしてください。



CIO-MB35W1C-10K-S2W25

SMARTCOBY SLIMII
Wireless2.2 Pro 10K

U A L

CIO Co., Ltd.

Founded in 2017 in Osaka, Japan, CIO Co., Ltd. is a manufacturing and sales company focused on dealing with the latest gadgets and smartphone accessories. With the concept of "delivering the latest, most exciting gadgets", the company offers its products through its e-commerce site and physical stores.

We always pay attention to the latest technology and continuously strive to develop products that increase the level of convenience for users. We offer high quality products in accordance with Japanese standards, but at the same time, we offer high cost performance as only an overseas manufacturer can.

It is our pleasure to provide convenient gadgets to our customers.

2

1.Introduction

Thank you for your purchase.
Please read the user manual carefully before use and use it correctly.

Contents

1. Introduction 3

2. Safety Precautions 4-6

3. Package Contents 7

4. Product Overview 7

5. Compatible Models / Devices 7

6. Part Names and Descriptions 8

7. How to Use 9-24

7-1. Charging with a Wireless Charger 9-11

7-2. Charge via Cable 12-14

7-3. Charging the Product 15-16

7-4. Charging Settings for Smartphones 17

7-5. Output Ports and Accessories 18-24

8. Product Warranty 25-26

3

2.Safety Precautions

Warning This is content that could lead to death or serious injury.

Caution There is a possibility of serious injury or damage to property.

Warning

If you notice any abnormalities such as unusual odor, swelling, or abnormal heat generation, or if foreign matter has entered the product, or if liquid is leaking from inside the product, stop using it immediately.

Do not disassemble or modify this product. Doing so may cause fire, electric shock, or malfunction.

Do not use, store, or leave this product in direct sunlight, near heating appliances, inside a vehicle, or in other high-temperature environments.

Do not allow water or other liquids to enter the product. Doing so may cause fire, electric shock, or malfunction.

Do not drop or subject the product to strong impact. This may cause fire, electric shock, or malfunction.

When using the USB charging port of this product, fully insert the USB power plug into the port.

Insufficient insertion or poor contact may cause fire, electric shock, or malfunction.

If you are using medical electronic devices such as implantable cardiac pacemakers, consult your physician before using this product, as it contains magnets.

Keep this product out of reach of children, and do not place it where infants or young children can access it.

4

Caution

Do not use this product for purposes other than its intended use.

Damage, malfunction, or data loss of devices connected to this product is not covered by warranty. Please understand this in advance.

This product contains magnets. Keep it away from credit cards, magnetic cards, hard disk drives, and other magnetic storage media to avoid damage.

Depending on the device specifications or software updates, wireless charging may not be available for certain devices.

During wireless charging, this product and the smartphone may become warm.

If you notice abnormal heat, discontinue use immediately.

If liquid such as beverages or water comes into contact with the product or smartphone, immediately rinse with clean water.

If it falls into water, do not retrieve it by hand—turn off the water source before removal.

Do not allow metal objects such as coins or hairpins to adhere to this product.

Doing so may cause heat generation or malfunction.

When removing this product, hold it firmly and remove it slowly to avoid damage.

Product specifications and appearance are subject to change without notice.

The contents of this manual may differ from the actual product.

The charging time shown is for reference only and may differ from the manufacturer's official specifications.

Company names and product names mentioned are trademarks or registered trademarks of their respective owners.

When disposing of this product, we recommend using CIO's battery withdraw service. (https://connectinternational.co.jp/mypage/collectservice/)

5

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio-frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement(The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and
- (2)This device must accept any interference received, including interference that may cause undesired operation.

When disposing of this product, we recommend using CIO's battery withdraw service. (https://connectinternational.co.jp/ciopbcollect/)

6

3. Package Contents

■Main Unit ■Instruction Manual

■USB-C to USB-C Cable

4. Product Overview

Product Name: SMARTCOBY SLIMII Wireless2.2 Pro 10K

Model Number: CIO-MB35W1C-10K-S2W25

Battery Capacity: 5000mAh / 7.1V / 35.5Wh

Battery Cells: 5000mAh × 2 cells (Total 10000mAh)

Rated Capacity: 6050mAh (5V=3A)

USB-C Input: 5V=3A / 9V=3A / 12V=2.5A / 15V=2A / 20V=1.5A(Max 30W)

USB-C Output: 5V=3A / 9V=3A / 12V=2.91A / 15V=2.33A / 20V=1.75A(Max 35W) / PPS 5-11V=3A [Max 33W]

Qi 2.2 Wireless Output: Max 25W

Total Output (USB-C + Wireless): 15W (5V=3A)+5W

Dimensions: Approx. 101 × 70 × 14.6 mm

Weight: Approx. 188 g

Cycle Life: Approx. 300 cycles

Charging Time: Approx. 160 minutes

*Charging time may vary depending on usage environment.

5. Compatible Models / Devices

Qi 2.2 (25W)

USB Power Delivery 3.0

7

6. Part Names and Descriptions

① Wireless Charging Area

② USB-C Input / Output Port

③ Battery Level Display LED / Mode Indicator LED

④ Battery Level Check / Mode Switch Button

When you press the button on the side of the main unit, the remaining battery level is displayed as a percentage.
Example: 75%

During charging or discharging, a % icon is displayed next to the percentage (%) value.

*When the product or the connected device is nearly fully charged, when the output power is low, the % icon is not displayed.

*Depending on the usage environment, the % icon may not be displayed, however, this is normal operation in accordance with the product specifications.

8

7. How to Use

1. Charging with a Wireless Charger

1-1. Charging Qi2-Compatible Smartphones

As shown in the illustration above, align this product with the wireless charging point of your smartphone to start wireless charging. If charging does not start, press the button once.

Notes

●Make sure that the built-in magnets of this product and your smartphone are properly aligned.

●Adjust the position until charging starts.

●Depending on the smartphone model or case used, the device may become unstable.

●In such cases, remove the case or use an Apple-certified MagSafe charging.

●During wireless charging, both this product and the smartphone may become warm.

9

1-2. Wireless Charging for Small Devices

Align the wireless charging point of the small device with the wireless charging area of this product to start charging.

Notes

●The location of the wireless charging point varies depending on the device.

●Charging time varies depending on the specifications of the small device, battery capacity, and remaining battery level at the start of charging.

●Operation is not guaranteed for all small devices.

10

1-3. About Simultaneous Charging

As shown in the illustration above, if wireless charging and wired charging are started at the same time for a smartphone, wireless charging will be automatically turned off, and wired charging will be given priority.

11

2. Charge via Cable

2-1. Charging a Smartphone

As shown in the illustration above, connect this product and your smartphone using the included USB-C cable to start charging the smartphone.

*If the smartphone does not start charging, press the button once.

12

2-2. Charging Small Devices(Low Power Mode)

When charging small devices such as wireless earphones, first press and hold the button for 5 seconds to enable Output Mode Switching, then switch the output to Low Power Mode.

*For details on how to switch to Low Power Mode, please refer to page 21-24.

*Low Power Mode

- Charging will automatically stop after 2 hours.
- Charging will stop if the USB-C cable is removed.
- Charging will stop when the button is pressed twice.

*Depending on the battery condition of the small device, charging may stop approximately 2 hours before the battery is fully charged.

13

2-3. Simultaneous Charging (Wireless Charging + Wired Charging)

When performing simultaneous charging, press and hold the button for 5 seconds to enable output mode switching; then switch to Wired + Wireless Charging Mode (HY).

*For details on how to switch to Wired + Wireless Charging Mode (HY), please refer to page 21-24.

*During simultaneous charging, the wireless charging output is up to 5 W, and the wired charging output is up to 15 W (5V=3A).

14

3. Charging the Product

3-1. Charging the Product

When the product is connected to a USB charger using the included USB-C cable, the product starts charging. During charging, a charging icon is displayed above the percentage (%).

Notes

●The USB charger is not included. Please prepare one separately.

●To perform fast charging at up to 30W, a USB charger that supports an output of 30W or higher is required.

15

3-2. Pass-Through Function(Wireless)

When a smartphone is placed on the wireless charging area, the numeric battery level (%) is displayed for 10 seconds, after which the LED display shown below (PTT) is alternately displayed for 2 seconds.

This product is a mobile battery that supports full pass-through charging.

By charging the smartphone and the mobile battery via separate circuits, the numeric charge/discharge cycles of the product is reduced, thereby alleviating the load on the battery cells.

16

4. Charging Settings for Smartphones

[iPhone: How to Disable Optimized Battery Charging]

Tap Settings on your iPhone.

Tap Battery.

Tap Charging.

Turn off Optimized Battery Charging.

[Android Smartphone: How to Disable Battery Protection]

Tap Settings on your smartphone.

Tap Battery.

Turn off Battery Optimization (or a similarly named feature).

The feature name and operation method vary depending on the model.

For details, please refer to the smartphone manufacturer's official website.

17

5. Output Ports and Accessories

5-1. About Output Ports and Accessories

By switching modes according to the device being charged and the usage scenario, this product automatically provides the optimal output for each device.

Examples:

- When you want to charge quickly via wireless charging → High Performance Mode
- When you want to charge small devices such as wireless earphones → Low Power Mode

*Output may vary depending on the remaining battery level of the smartphone.

For details on the features of each mode, please refer to "About Each Mode" on pages 19-20.

For instructions on how to switch output modes, please refer to "How to Switch Output Modes" on pages 21-24.

18

5-2. About each mode

This product offers five selectable modes.

Usage Example: This mode is described below with examples of usage scenarios followed by its features.

Charges devices with a maximum wired output of 35W.

[Safety Mode]

- Usage Example: When you are concerned about heat generation while charging your smartphone.
- Features: Charges devices using wireless output up to 7.5W.
- Output may vary depending on the remaining battery level of the smartphone.

[High Performance Mode]

- Usage Example: When you want to charge your smartphone quickly, even if the remaining battery level of this product is low.
- Features: Charges devices using wireless output up to 25W.
- Output may vary depending on the remaining battery level of the smartphone and its thermal condition.

[Low Power Mode]

- Usage Example: When you want to charge small devices such as wireless earphones.
- Features: Charges small devices with a wired connection.
- If charging is started without enabling Low Current Mode, output to small devices may stop after a few minutes.

19

5-3. How to Switch Output Ports and Accessories

Output mode switching is performed using the following steps.

For a list of output modes, see pages 22-24.

*The default setting is High Performance Mode (25 W).

1. Display the remaining battery level

Press the button once to turn on the battery level LED indicator.

2. Enable output mode switching

Press and hold the button for 5 seconds until all LED indicators start flashing.

3. Select and confirm the desired mode

While in output mode switching operation, each press of the button switches to the next mode.

Press and hold the button for 2 seconds on the desired mode to confirm the selection.

4. Connect the device

After completing the output mode switching, connect the device wirelessly or using a cable to begin charging.

*If the smartphone does not start charging, press the button once.

*If no button operation is performed for 5 seconds while the LED display is flashing, the output mode switching operation is canceled and the display returns to the remaining battery level.

*If output mode switching is canceled, the setting returns to the default "High Performance Mode (25 W)" or the previously selected mode.

20

8.Product Warranty

Thank you for purchasing CIO product. If the product has any defects such as initial malfunction, please contact us before reviewing. We will replace it as an initial malfunction product.

In case of malfunction occurred within the warranty period or correct use, we will also replace it.

Invoice/warranty or dealer's receipt will become warranty so please keep it. The product will be guaranteed for replacement with it.

Please note that we do not accept returns or refunds.

Please note that the warranty cannot be provided in the following cases:

- 1. Accident due to careless handling while using it. (e.g. dropping, submerging and so on.)
- 2. Failure due to fire or water damage.
- 3. Failure due to any internal modification by the user.

Support Information

Email address: customer@connectinternational.co.jp

One Year Warranty [CIO-MB35W1C-10K-S2W25]

Dealer's Name

The date of purchase:

25

CIO Co., Ltd.

Stay Updated with All the Latest News!

We will be posting information about our new crowdfunding project, new products, and special discounts.

26