

Air Clips 2




Please refer to this manual before using the product


TABLE OF CONTENTS

• Package Contents and Features	01
• Specifications	02
• Power and Pairing	03
• Reset	04
• Charging	05
• Controls	06
• Warranty	08
• Safety	09

PACKAGE CONTENTS



Noise Air Clips 2 x 1



Charging Case



USB Type-C charging Cable x 1

User Manual x 1

'How to wear' Card x 1

Thank you Card x 1

SPECIFICATIONS

- Air Clips 2 weight: 6g (each)
- Charging case weight: 33g
- Driver size: 12mm
- Supported profile: A2DP, HFP, AVRCP
- Bluetooth version: 5.3
- Earbuds Charging time: Up to 90 mins
- Charging case charging time: Up to 90 mins
- Working voltage: 5V
- Standby time: Up to 500 hours
- Bluetooth range: 10m
- Playtime: 6.5 hours at 60% volume
- Total playtime with charging case: 40 hours
- Waterproof rating: IPX5
- Charging port: Type-C

POWER ON/OFF

- The clips will automatically turn on when taken out from the charging case.
- The clips will automatically turn off once placed inside the charging case and the lid is closed.

PAIRING

- When you take the Air Clips 2 out from the charging case, it automatically initiates the pairing mode.
- Select 'Add Device' and select Noise Air Clips 2 from the list of devices.
- Your Air Clips 2 are now paired with your device and ready to use.

Note: Your Air Clips 2 will automatically connect to the last paired device as soon as you take them out of the charging case.

DUAL DEVICE PAIRING

Follow these steps to connect two devices with Noise Air Clips 2:

- Pair Air Clips 2 with Device 1
- Power off the Bluetooth on Device 1.
- Pair Air Clips 2 with Device 2.
- Now power on the Bluetooth of Device 1.
- Noise Air Clips 2 is now paired with both devices.

If it does not connect automatically with Device 1, try connecting manually.

RESET

- Make sure your earbuds are fully charged.
- On your paired devices, delete/remove Noise Air Clips 2 from the list of paired devices in the bluetooth menu.
- Insert both earbuds into the charging case and long press the charging case button for 7 seconds.
- The orange LED on the charging case will start blinking, to indicate earbuds have been reset.

IMPORTANT NOTE - (WHEN NEW PRODUCT RECEIVED)

Air Clips 2 has a Mylar (protective film) on the charging pins that must be removed and should place the Air Clips back in the charging case, to Power them on.

ENSURING THE AIR CLIPS FIT CORRECTLY

- Put on the air clips 2 on your auricle, push it down like the above picture and adjust to fit yourself.
- Adjust its angle and make the sound hole towards your earhole.
- Improper wear might bring bad call and playing experience.



CHARGING

Before using your Air Clips 2 for the first time, fully charge them by using the Type-C cable provided.

Clips

Place both clips inside the case to charge them.

Case

Charge the case via a Type-C charging cable, preferably from any PC or laptop as compared to a USB charger.

Indication (on case)

- **Blinking white LED (Only once) = Opening and closing the lid**
- **Blinking Orange LED = Charging**
- **No LED = Fully Charged**

CONTROLS



Play/Pause

Triple tap the right Air Clip



Tap thrice



Previous Song

Long press the left Air Clip for 3 seconds



Long press,
3 seconds



Next Song

Long press the right Air Clip for 3 seconds



Long press,
3 seconds



Volume Up

Double tap the right Air Clip



Tap twice



Volume Down

Double tap the left Air Clip



Tap twice



Answer Call/End Call
Double tap either clip



• •
Tap twice



• •
Tap twice



Gaming Mode
Four tap left clip



• • • •
Tap Four times



Reject Call
Long press either clip
for 3 seconds



—
Long press,
3 seconds



—
Long press,
3 seconds



Voice Assistant
Triple tap left Air Clip



• • •
Tap thrice

WARRANTY

The warranty covers your Noise product, including accessories, against manufacturing defects (if any) for 1 year from the date of purchase.

Things that are not covered in the warranty are listed below:

- Unauthorised tampering, modifications or repairs of the product.
- Physical damage of the product on the account of abuse, handling, storage, installation or testing including any use that is not by the product manual or documentation or any other instruction provided along with the Noise product.

For further information on product replacement/refund-related queries, please refer to the terms and conditions mentioned in our online return policy section on **www.gonoise.com**.

REGISTER YOUR WARRANTY

www.gonoise.com/pages/warranty-registration

✓ SUPPORT AND SERVICE

🕒 1 YEAR LIMITED WARRANTY



SCAN ME

CUSTOMER QUERY

For any assistance, please reach out to us at support.gonoise.in

SAFETY FOR YOU AND YOUR AIR CLIPS 2

Follow these tips to get the best out of your new Air Clips 2:



Do not expose the earbuds to liquids, moisture, or humidity as they have electronics and batteries inside.



Do not try to disassemble your earbuds. There are no user-serviceable parts inside it.



Do not use abrasive cleaning solvents to clean your new earbuds. Wipe them down with a slightly damp cloth if and when necessary.



Avoid dropping the earbuds and keeping them away from sharp objects such as keys in your pockets.



Remove and clean the earbud tips regularly to ensure that you always enjoy the best sound possible.



Only charge your earbuds from 5V/1A ports such as phones and laptops or PC chargers.



Do not expose the earbuds to extremely high or low temperatures as this may damage the battery or even deform the plastic parts.



Avoid listening to music at a high volume or you may permanently damage your hearing.



Do not throw the earbuds in a fire to dispose them. The internal battery may explode.



Pay attention to your surroundings and never wear any earphones while riding, driving, or walking in traffic.

