

User Manual

1. Product Introduction

Thank you for purchasing our **[AI Voice Interactive Reborn Doll]**. This product is a sound module designed for **Reborn Doll**.

Product Model: [LTRB001LNWA8-TCW]

Power Supply: [DC 3.7V(Rechargeable Polymer Lithium Battery)]

FCC ID: [2BVUX-KSRBJX001AD]

2. Instructions for Use

1. Charge the Battery (Before First Use):

- Connect the module to a **5V DC USB power source** (e.g., a phone charger or power bank) using the provided USB cable.
- The indicator light will turn **red** during charging.
- When fully charged, the indicator light will turn **green** or turn off (refer to the actual product indicator behavior).
- Charging time: approximately **2–3 hours** (depending on battery capacity).

2. Power On:

- Slide the switch at the bottom of the module to the **"ON"** position.
- The module will emit a **"Dong"** sound, indicating it has powered on.
- The indicator light on the front will turn **green**, confirming the module is ready.

3. App Connection (First-Time Setup):

- Open the corresponding mobile App on your smartphone.
- Follow the in-app instructions to connect the module to your Wi-Fi network.
- Once connected, the module is ready for normal interaction.

4. Volume Control:

- Use the **Volume +** and **Volume -** buttons located on the right side of the module to adjust the sound level.

5. Pause / Resume Interaction:

- Press the **light-touch button** on the front of the module to pause the current interaction.
 - The module will enter a listening state, waiting for your voice input.
 - Speak to the module to resume interaction.
-

3. FCC Statements

3.1 FCC Compliance Statement (Part 15.19)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
-

3.2 FCC Interference Statement (Class B Digital Device)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
-

3.3 Caution (Part 15.21)

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

3.4 RF Exposure Statement

This equipment has been tested at a minimum distance of **5 mm** between the radiator and your body and complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

4. FCC ID Information

FCC ID: [2BVUX-KSRBJX001AD]

5. Troubleshooting

Problem	Solution
The module does not power on when sliding the switch to "ON".	1. Connect the module to a USB power source and check if it is charging. 2. If the battery is fully drained, charge for at least 30 minutes before trying again. 3. Make sure the switch is fully slid to the "ON" position.
The module cannot connect to the App / Wi-Fi.	1. Ensure your smartphone's Bluetooth and Wi-Fi are turned on. 2. Make sure the module is within range of your Wi-Fi router. 3. Restart the App and try again. 4. Reset the module by sliding the switch to "OFF" and then back to "ON".
No sound or low volume.	1. Press the Volume + button on the right side to increase the volume. 2. Check if the module is in mute or pause mode (press the front button to resume). 3. Charge the module as low battery may cause weak sound.
The module does not respond when pressing the front button.	1. Make sure the module is powered on (green light on the front).

Problem	Solution
	2. Short press the front button to pause or resume interaction. 3. If unresponsive, restart the module by sliding the switch to "OFF" and then back to "ON".
The indicator light does not turn green after power on.	1. Ensure the battery is charged (connect to USB power and charge for 30 minutes if needed). 2. Slide the switch to "OFF" and then back to "ON" to restart. 3. If the issue persists, contact customer support.
The battery drains quickly or does not hold charge.	1. Fully charge the module and observe the usage time. 2. If the issue continues, the battery may need replacement. Contact customer support.

6. Contact Information

Manufacturer: Hong Kong Lattel Supply Chain Management Co., Limited

Address: FLAT/RM 1406A, 14/F, THE BELGIAN BANK BUILDING, NOS.

721-725 NATHAN ROAD, MONGKOK, KL

Tel: +86 13005777930