

Manual

Product Specifications

1. Working Voltage: DC 3.7V
2. Charging Voltage: DC 5V/1A
3. Frequency Range: 2402 - 2480 MHz
4. Charging Time: Approximately 2 hours
5. Playback Time: 100% volume, lights on 6H, lights off 46H, lights off with ANC on 31H, lights on with ANC on 5H
6. Bluetooth Version: V5.4
7. Audio Decoding Format: AAC/SBC
8. Microphone Sensitivity: -42±3DB
9. Working Range: Approximately 10-15 meters

Product Operation

For first-time use, fully charge the headset battery. To charge, insert the USB charging cable into the charging port and connect to a power source. The indicator light will illuminate during charging and turn off when charging is complete (approximately 2 hours).

When the headset battery level is below 3.3V, a voice prompt will sound; please charge the headset promptly.

Power On/Off

1. Power On: Press and hold the power button for 3 seconds. The blue light will illuminate for 1 second and then turn off, followed by alternating red and blue flashing lights, indicating readiness for Bluetooth connection.
2. Power Off: Press and hold the power button for 3 seconds. The red indicator light will flash twice and then turn off.

Bluetooth Usage

Bluetooth mode provides wireless music playback functionality.

In Bluetooth mode, the indicator light will show blue and red lights. Turn on the Bluetooth function on your mobile phone and search for the device name SW128.

Select to connect. After successful connection, you can play music and make phone calls.

Bluetooth Mode

1. Answering Calls: When a call comes in, single-click the multi-function button to answer.
2. Ending Calls: Press and hold the multi-function button to end the call.
3. Rejecting Calls: When a call comes in, press and hold the multi-function button (power button) to reject the call.
3. Press and hold the (+) or (-) buttons to select the desired song.
4. Single-click the multi-function button (power button) once to play/pause music; press again to resume playback.
5. Click the (+) or (-) volume buttons to adjust the volume.
6. Voice Assistant: Triple-click the multi-function button (power button) (if your phone

supports this function).

7. Redial Last Number: Double-click the function button to automatically redial the last dialed number.

ANC Mode

1. Click the ANC button; the green indicator light will stay on, entering noise cancellation mode. Click the ANC button again to exit noise cancellation mode.

LED Mode

1. Click the LED button to enter LED mode. Click the LED button again to exit LED mode.

Wired Headphone Function

Insert the 3.5mm audio cable into the audio jack, and then plug the other end of the audio cable into your computer or other music device to use it as wired headphones. When using wired headphones, the MP3 and Bluetooth functions will not work, and you cannot adjust the volume through the headphones.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.