







105G双铜，双面印刷，印四色，风琴折，成品尺寸：70*95MM

 M13S PRO 蓝牙音箱 Bluetooth Speaker ブルートゥーススピーカー	产品配件  音箱x1  使用说明书x1  Type-C 充电线x1  保修卡x1	使用说明   ●音量—/下一曲 ●电源开/关机 接听来电/结束通话/拒接来电 音乐播放/暂停 ●音量+ /上一曲 ●Type C 充电线 ●充电指示灯 ●TF卡插卡处 ●炫光指示灯 开机：在关机状态下，长按  键3秒开机，炫光指示灯为冰蓝色并且快闪，有提示音。 关机：在开机状态下，长按  3秒关机，炫光指示灯熄灭/有提示音。 蓝牙配对：打开蓝牙设备在列表中找到Sanag M13S Pro，点击连接，炫光指示灯冰蓝灯长亮。 接听来电：当电话来电时，短按  键接听电话 结束通话：短按  键挂断电话 拒接来电：当电话来电时长按  键2秒拒接来电。 播放 / 暂停：单击  键，音乐在暂停/播放切换。播放过程中，炫光指示灯跟随音乐节奏闪烁。 	低电压：当音箱电池电压过低时，音箱会低电压报警，炫光指示灯为红色快闪。 充电：插DC 5V电源充电，充电时红灯常亮。 充满电：充电指示灯熄灭。 音量+：单击音箱+键，音量加。最大音量时，有提示音。 音量-：单击音箱-键，音量减。 上一曲：长按+键2秒。 下一曲：长按-键2秒。 TF卡模式：插入TF卡，音箱默认切换到TF卡模式。双击  键切换至TF卡模式或蓝牙模式。 炫光指示灯的模式切换 连接手机蓝牙后有三种模式：三击  键在不同模式之前切换 2.1 渐变变色模式：连接手机蓝牙后，音乐声响起，灯光在多种颜色之间慢慢渐变。 2.2 听音模式：连接手机蓝牙后，音乐声响起，灯光随音乐声的大小显示不同的亮度。 2.3 无指示灯模式：连接手机蓝牙后，音乐声响起，灯光熄灭，不显示。 规格参数 <table> <tr><td>电池容量：</td><td>1800mAh</td></tr> <tr><td>充电电压：</td><td>5V === 1A</td></tr> <tr><td>喇叭：</td><td>4Q 5W</td></tr> <tr><td>频率响应：</td><td>60Hz-20KHz</td></tr> <tr><td>蓝牙版本：</td><td>V 5.1</td></tr> <tr><td>充电方式：</td><td>TYPE-C接口充电</td></tr> <tr><td>防水：</td><td>IPX7</td></tr> <tr><td>产品尺寸：</td><td>100X77X42.5mm</td></tr> <tr><td>连接范围：</td><td>>10M</td></tr> <tr><td>重量：</td><td>216G</td></tr> </table>	电池容量：	1800mAh	充电电压：	5V === 1A	喇叭：	4Q 5W	频率响应：	60Hz-20KHz	蓝牙版本：	V 5.1	充电方式：	TYPE-C接口充电	防水：	IPX7	产品尺寸：	100X77X42.5mm	连接范围：	>10M	重量：	216G	常见问题与事项 无法打开扬声器： 检查扬声器是否没有电源，如果没有电源，请先充电。 无法与设备连接： 检查扬声器是否与第三个设备连接，如果是，请先断开连接，如果仍然无法连接，请重新启动并重试。 注意事项 ●避免儿童接触 ●切勿敲击扬声器 ●不要充电太久，以免损坏电池	
电池容量：	1800mAh																								
充电电压：	5V === 1A																								
喇叭：	4Q 5W																								
频率响应：	60Hz-20KHz																								
蓝牙版本：	V 5.1																								
充电方式：	TYPE-C接口充电																								
防水：	IPX7																								
产品尺寸：	100X77X42.5mm																								
连接范围：	>10M																								
重量：	216G																								
	Product accessories  Speaker x1  user's manual x1  Type-C Charging Cable x1  Warranty card x1	Instructions for use   ●Volume—/Next track ●Power on/off Answer call/end call/reject call Music play/pause ●Volume + / previous song ●Type C. Charging Cable ●Charging indicator ●TF card slot ●Glow indicator Power on：In the off state, long press the  key for 3 seconds to start the machine. The glow indicator is ice blue and flashes quickly, with a prompt tone. Power off：In the power on state, long press  3 seconds to shut down, and the glare indicator light goes out; There is a prompt tone. Bluetooth pairing：Open the Bluetooth device, find the sanag M13S Pro in the list, and click Connect. Glare indicator The ice blue light is on for a long time. Answer the call：When the phone calls, briefly press the  key to answer the call End the call：Short press the  key to hang up	Reject the call：When the phone calls, long press the  key for 2 seconds to reject the call. Play / Pause：Click the  key to switch the music between pause / play. During playback, the glare indicator light follows The rhythm of the music flickers. Low voltage：when the battery voltage of the speaker is too low, the speaker will give a low power alarm. The glare indicator is red flash. Charging：plug in DC 5V power supply for charging, and the red light is always on during charging. Fully charged：the charging indicator light is green. Volume +：click the speaker + key to increase the volume. At the maximum volume, there is a prompt tone. Volume —：click the speaker key to decrease the volume. Previous song：long press the — key for 2 seconds. Next song：long press the — key for 2 seconds. TF card mode：Insert the TF card, and the speaker will switch to the TF card mode by default. Double click the  key to switch to TF card mode or Bluetooth mode. Mode switching of glare indicator There are three modes after connecting the Bluetooth of the mobile phone: Press the  key three times to switch between different modes 2.1 Gradient mode: after connecting the Bluetooth of the mobile phone, the music sounds and the light slowly fades between various colors. 2.2 listening mode: after connecting the Bluetooth of the mobile phone, the music sounds, and the lights display different brightness according to the size of the music. 2.3 no indicator mode: after connecting the Bluetooth of the mobile phone, the music sounds, the light goes out and does not display.	Specifications <table> <tr><td>Battery capacity:</td><td>1800mAh</td></tr> <tr><td>Charging voltage:</td><td>5V === 1A</td></tr> <tr><td>Trumpet:</td><td>4Q 5W</td></tr> <tr><td>Frequency response:</td><td>60Hz-20KHz</td></tr> <tr><td>Bluetooth version:</td><td>V 5.1</td></tr> <tr><td>Charging method:</td><td>TYPE-C interface charging</td></tr> <tr><td>Water proof:</td><td>IPX7</td></tr> <tr><td>Product Size:</td><td>100X77X42.5mm</td></tr> <tr><td>Connection range:</td><td>>10M</td></tr> <tr><td>Weight:</td><td>216G</td></tr> </table> Frequently Asked Questions and Matters Unable to turn on speaker: Check if the speaker has no power, if there is no power, please charge it first. Unable to connect with device: Check if the speaker is connected to the third device, if so, disconnect it first Connect, if you still can't connect, reboot and try again. Precautions ●Keep out of reach of children ●Do not hit the speaker ●Do not charge for too long, so as not to damage the battery	Battery capacity:	1800mAh	Charging voltage:	5V === 1A	Trumpet:	4Q 5W	Frequency response:	60Hz-20KHz	Bluetooth version:	V 5.1	Charging method:	TYPE-C interface charging	Water proof:	IPX7	Product Size:	100X77X42.5mm	Connection range:	>10M	Weight:	216G	Precautions ● Please fully charge the product before using it for the first time. ● Do not dismantle or repair or modify this product for any reason, otherwise it may cause fire, electronic breakdown or even Completely damage the product. ● If charging is completed, please disconnect the charger from the device, and unplug the charger.Do not exceed 12 hours. ● Please do not dispose of the old battery in the old household garbage. Improper disposal of the battery may damage the battery In case of fire or explosion, please dispose of this product, battery and other accessories in accordance with local regulations. ● The battery must not be disassembled, impacted, squeezed or thrown into fire.If it is severely swollen, do not continue to use it. ● Do not repair this product yourself. ● If consumers use a power adapter to charge, they should purchase a matching power adapter to obtain CCC certification and meet the standard power adapter. ● Batteries must not be exposed to excessive heat.
Battery capacity:	1800mAh																								
Charging voltage:	5V === 1A																								
Trumpet:	4Q 5W																								
Frequency response:	60Hz-20KHz																								
Bluetooth version:	V 5.1																								
Charging method:	TYPE-C interface charging																								
Water proof:	IPX7																								
Product Size:	100X77X42.5mm																								
Connection range:	>10M																								
Weight:	216G																								
	製品付属品  スピーカーx1  マニュアルx1  Type-C 充電ケーブルx1  保証書x1	使用説明書																							