

Tapo Robot Vacuum Replacement Kit

Replacement Instructions

To maintain optimal performance, maintain the robot vacuum according to the following guidelines.

Part	Maintenance Frequency	Replacement Frequency†
Main Brush	Every 2 weeks	6-12 months
Side Brush	Once a month	3-6 months
Filter	Once a week	3-6 months

†Replacement frequency may vary depending on the actual situation. Parts should be replaced if visible wear appears.