


折叠尺寸：65*95
展开尺寸：325*95

80g书写纸
四色印刷

正面



BL135
Ultra-thin Bluetooth
Earphone




使用说明书

AN INSTRUCTION MANUAL

项目	基本参数
蓝牙版本	5.3
通讯距离	10M/33 英尺（取决于手机功能）
耳机音乐时长	4-5小时
耳机通话时长	4小时
耳机盒续航时间	12小时
充电接口	Type-C
耳机充电时间	1 小时
耳机盒充电时间	2 小时
耳机供电	内置锂电池 3.7V/25mAh
电池盒子供电	内置锂电池 3.7V/250mAh
特点	私模专利TWS

按键功能操作



操作指令

配对名称: BL135	
项目	耳机操作方法
开机	充电仓开盖，取出耳机，耳机开机
关机	放入充电仓关机，3分钟无连接自动关机
左右耳机配对	从仓内将左右耳机取出，靠近一起，左右耳机自动配对
和手机连接	手机上开启蓝牙，搜索蓝牙设备“BL135”，首次需手动连接该设备，连接“BL135”成功后，戴上耳机有提示音
副耳连接手机	/
回拨电话	/
接听	来电 触摸2下主/副耳接听（左右耳都可以）
挂断电话	触摸2下（左右耳都可以）
拒接电话	触摸3下拒接
三方通话	/
和手机断开连接	手动在手机上取消配对和手机断开连接

IOS电量显示	有显示
回连	自动回连
低电报警	/
自动关机	开机3 分钟无连接设备，自动关机
耳机充电	耳机放入充电仓后，耳机红灯亮起，开始充电
充电仓充电	红灯慢闪
充满电	红灯长亮
音乐暂停/播放	触摸右耳2下
上一曲	触摸左耳3下
下一曲	触摸右耳3下
音量-	
音量+	
唤醒 语音助手	触摸左耳2下

注：因安卓系统手机系统蓝牙模块兼容性问题，部分手机上述少量功能可能不可用。

产品保修卡

客户姓名 _____ 联系电话 _____

产品名称 _____

购买日期 _____

地 址 _____

编 号 _____

保修说明

1. 需要维修服务时, 请出示此卡
2. 在正常使用状态下出现的质问题, 非外观破坏造成的损坏本公司向用户提供自
品购买之日起六个月的 质保期
3. 属下列赔偿保修失, 提供维修服务, 但收取相应的费用
 - ①人为损坏, 如因为使用不当, 造成损坏
 - ②外观不正常磨损、摔伤、异物进入, 受潮
 - ③产品上的密封标签被涂改或撕毁
 - ④私自拆机, 自行维修, 改装, 经本公司维修部门或非授权机构维修的
 - ⑤因不可抗力造成的损坏, 如地震、火灾、水灾、战争等
 - ⑥超过质保期的

品牌名: **FONENG**[®]
 公司: 深圳市比方创展科技有限公司
 地址: 广东省深圳市龙华区大浪街道华繁路110号嘉安达大厦2305
 服务热线: 0755-36947220




背面

Product parameter specifications

Project	Basic parameters
Bluetooth version	5.3
Communication distance	10M/33ft (depending on phone capabilities)
Headphone music duration	4-5 hours
Headset talk time	4 hours
Headset case life	12 hours
Charging port	Type-C
Headphone charging time	1 hours
Earphone case charging time	2 hours
Headphone power	Built-in lithium battery 3.7V/25mAh
The battery box is powered	Built-in lithium battery 3.7V/250mAh
Peculiarity	Private model patents TWS

Key function operation



① Light ② Charging port ③ Light ④ Where fingerprints touch

Operation instructions

Pairing name:BL135	
Project	Headset operation method
Boot	Open the charging case, take out the headphones, and turn on the earphones
Shutdown	Put in the charging case to turn off the computer, 3 minutes without connection automatic shutdown
Pair the left and right headphones	Remove the left and right ear earphones from the warehouse, bring them closer together, and the left and right earphones will be automatically paired
Connect with your phone	Turn on Bluetooth on your phone, search for Bluetooth device "BL135", and manually connect it for the first time after connecting the device and connecting "BL135" successfully, there is a prompt sound when you put on the headphones
The secondary ear is connected to the mobile phone	/
Call back	/
Answer	Incoming call touch 2 times primary/secondary ear answer (left and right ears are available)

Hang up	Touch 2 times (left and right ears are acceptable)
Reject the call	Touch 3 times to reject
Three-way call	/
Disconnect from the phone	Manually unpair and disconnect the phone from the phone
iOS power display	There is a display
Backlink	Automatic backconnect
Low power alarm	/
Automatic shutdown	Power on for 3 minutes without connecting devices, automatic shutdown

Headphone charging	After the earbuds are placed in the charging case, the red light of the earbuds lights up and charging begins
Charging in the charging case	The red light flashes slowly
Fully charged	The red light is solid
Music paused/played	Touch the right ear 2 times
Previous song	Touch the left ear 3 times
Next song	Touch the right ear 3 times
Volume-	
Volume +	
Wake up the voice assistant	Touch the left ear 2 times

Note: Due to the compatibility of the Bluetooth module of the Android system mobile phone system, the above few functions may not be available in some mobile phones.

Product Warranty Card

Customer name _____ Contact number _____

Product name _____

Date of purchase _____

Address _____

Numbering _____

Warranty Description

1. Please present this card when warranty service is required.
2. Quality problems in normal use, damage caused by non-cosmetic damage, the company provides users with self-product purchase A warranty period of six months from the date of the date.
3. The subordinate warranty is invalid, and maintenance services are provided, but the corresponding fees are charged.
 - (1) Man-made damage, such as damage caused by improper use.
 - (2) Abnormal appearance, wear, fall, foreign body entry, moisture.
 - (3) The sealed label on the product has been altered or torn.
 - (4) Disassemble the machine without permission, repair and modify it by itself, and repair by non-company maintenance departments or non-authorized institutions.
 - (5) Damage caused by force majeure, such as earthquakes, fires, floods, wars, etc.
 - (6) The warranty period has expired.

Producer: Shenzhen Be-fund Technology Co., Ltd
Address: 2305, Hua fan Road 110, Tong sheng community, Da lang Street,
Long hua District, Shenzhen
Website: szfoneng.com
Tel: 86-755-36947220

