

Operation Manual

G6/SW006/X3/XF/X12/XS/G7

.....

Before using this product, please read this manual carefully and follow the instructions to operate the product correctly.

◆ Safety precautions

1. Please read this instruction carefully and keep it properly.
2. Please use the accessories specified by the manufacturer.
3. Please install according to the connection instructions in the manual.
4. it is recommended to use this product in -10°C - 45°C environment.
5. do not put the product and accessories near the fire source or any overheating environment.
6. do not touch the product and accessories with water, do not use the product near the water, do not immerse the product in any liquid, to avoid the product and accessories by water droplets or splashing.
7. Do not open or disassemble or repair the battery module by yourself. If the battery is improperly replaced, there will be explosion risk.
8. This product is charged by the external power adapter (DC5V power supply). After charging, please unplug the power supply or power socket in time to disconnect the power grid.
9. When users do not use the product temporarily, please turn the power switch of the product to the critical state to avoid the loss of battery power.
10. In inflammable and explosive areas, please close the product and follow the relevant labeling instructions to avoid causing explosion or fire.
11. If the battery is not replaced properly, it can only be replaced with the same type or equivalent type of battery.
12. the battery shall not be exposed to sunlight, fire or similar overheating environment.
13. The altitude and climatic conditions applicable to this product are determined by the power supply equipment selected.

This product is sold without a power adapter. If you use a power adapter to charge, you should purchase a power adapter that has obtained the CCC certification.
This product contains rechargeable batteries.

◆ Packing list



Loudspeaker



wireless microphone



Type-C charge



Lanyard



Specification


◆ Specification parameter

Bluetooth Core	5.0
Frequency response	150Hz-20KHz
SNR	$\geq 75\text{dB}$
Distortion	2-5%
Charger specification	5V-1A
Battery	18650 Rechargeable Battery
Operating temperature	-10°C -45°C
Bluetooth range	10m (no object)

Note: 1. The above parameters are based on the experimental data of the department.

2, with the actual use of different conditions, the parameters will change.

◆ Function introduction



- 1、Menu (M)
- 2、Prev/Echo-
- 3、Play/Pause
- 4、Next/Echo+
- 5、Power/Volume knob
- 6、AUX jack
- 7、Type-c jack
- 8、MIC jack
- 9、USB Flash Drive jack
- 10、Micro TF jack
- 11、Charging indicator

◆ Instructions for use

Function

1、Menu (M)

Tap to switch between Bluetooth mode and microphone mode; If there is a U disk /TF card, long press to record mode.

2、Prev/Echo-

Short press the previous song; Long press reverberation reduction (sound amplification mode takes effect).

3、Play/Pause

Press while playing music to implement the play/pause function.

4、Next/Echo+

Short press the next song; Press and hold reverberation Plus (sound amplification mode takes effect).

5、Power/Volume knob

Press and hold the switch for 3 seconds; The encoder knob rotates indefinitely, U16 hears the "ding" sound, which means the highest volume, U01 means the least sound.

7、Type-c jack

Use a Type-c charging cable to charge. A 5V1A charging head is recommended.

8、MIC jack

In the standby state, insert the plug end of the attached microphone into the microphone jack, and put the other end on the head to enter the amplification mode.

9、USB Flash Drive jack

USB disk inside store MP3\WMA format files, plug in can be played directly.

10、Micro TF jack

TF card surface store MP3\WMA format files, plug in can be played directly.

11、Charging indicator

The charging red light goes on and the full red light goes off.

Mode

1. Bluetooth pairing

① After startup, press the function key (M) to start Bluetooth mode. The display is blinking BLUE.

② Bluetooth name: G6

③ Open the Bluetooth pairing of the phone, select the device name: G6, and click Connect. After the connection is successful, the BLUE is steady on.

2. ECHO

When using microphone amplification, long press the previous song or the next song to adjust the amount of reverberation.

3. Microphone recording

1, Plug in the U disk /TF card, plug in the microphone.

2, long press the M key, prompting to start recording.

3, After the recording is finished, press the M key to play the recording.

4, If you need to record more than one recording, repeat steps 2 and 3.

When playing a recording, you can select the previous one and press the Play key to delete the current recording.

4. Bluetooth recording

Record music played by Bluetooth to the memory card.

1, Plug in the U disk /TF card and connect the phone to Bluetooth.

2, when playing mobile phone songs, long press the M key to start recording.

3, Press the M key to end recording and continue playing music.

4, If you need to record more than one piece of music, repeat steps 2 and 3.

5. Single cycle

When playing music, double click the play button to set the single cycle; Double-click again to resume all playback.

◆Precautions for use

1. in order to achieve the best effect of microphone amplification, please place the microphone head in front of the mouth 1-2cm to the microphone head pronunciation, if there is a loud, can be appropriate to reduce the volume or the distance between the machine and the head slightly apart, to prevent mutual interference;
2. If the product needs to be fixed on the wall or ceiling, please ensure that it is fixed in place to prevent the product from falling due to insufficient fixed strength
3. please do not dismantle the machine, refit or repair, in order to prevent personal injury,
4. use the volume is too high, may cause hearing damage, please adjust the volume to a safe level.
5. try to avoid frequent plug and plug microphone jack, so as not to cause loose socket and poor contact, do not insert the microphone and sound source wrong.
6. in order to ensure the life of the lithium battery, it is recommended to charge after use, frequent charging will accelerate the aging of the battery chip, long time when not used, should be charged every two months.
7. because the magnetic horn is strong, can not put the machine and bank card with magnetic things together, so as not to cause the loss of magnetic and unnecessary trouble.
8. All the accessories of this product are designed according to the working needs of this machine. If you need to replace the accessories, try to use the original accessories of our company to achieve the best working condition.
9. This product may become slightly hot during charging and normal use, which is a normal phenomenon.
10. Please use antistatic soft cloth to clean and wipe the product. Please turn off the power switch and disconnect all external connections when cleaning the product. Do not wipe with chemical substances (such as alcohol, benzene and other chemical lotion or scrub cleaning agent);
11. Please do not fall, throw or step on the product. Please do not disassemble the product without permission, otherwise you cannot enjoy the company's free warranty service.

◆Product warranty instructions

In order to let you better enjoy our company's services, please read the following details, the company's product warranty service is provided by the authorized technical service center. The warranty period and the "Three Guarantees" period of validity of this product are from the date of sale, and within the "three Guarantees" period of validity. If the product fails under normal conditions, it can be repaired, replaced or returned according to the provisions of "Three Guarantees". During the warranty period, the product can enjoy free maintenance service in the authorized technical service center in accordance with the content of this warranty clause (the random accessories are not within the scope of warranty).

The warranty period of this product is one year

During the warranty period (including the validity period of "Three Guarantees"), paid maintenance service will be implemented under the following circumstances, while the "three guarantees" service will not be enjoyed:

1. The original valid warranty card and valid invoice cannot be presented
2. The date of purchase, the name of the sales unit (valid with seal) and other items are not completely filled in or the warranty card is altered.
3. Failure and damage caused by irresistible natural disasters.
4. Failure and damage caused in the process of transportation and unloading.
5. Human failure caused by failure to operate according to the operation methods and precautions written in the Product Instruction Manual.
6. Failure caused by disassembly, maintenance and modification of products without authorization of the Company.

When warranty is required, please send the machine together with this warranty card (original) and purchase certificate (copy) to the authorized technical service center. The freight shall be borne by the user.

Product warranty card

Please fill in this card and keep it when you purchase the product.

User profile

Name	
Gender	
Address	
Zip code	
Phone	
Place of purchase	
Date of purchase	
Specification	
Order number	
Dealer's signature	
User signature	

Note:

Some features and functions of the product and accessories described in this note are for reference only. Huizhou Shuwen Electronics Co., Ltd. reserves the right to modify any information in this manual at any time without any prior notice and without any liability.

Unsecured statement:

Except as required by applicable law, no warranty of any kind, express or implied, is given by the Company regarding the contents of this Manual.

To the extent permitted by law, the Company shall not, under any circumstances, indemnify any special, incidental, indirect or secondary damages, nor shall it indemnify any profit, data, goodwill or anticipated loss arising from the use of the relevant contents of this Manual.

Import and export control:

To export, or import the products described in this product manual, you must comply with applicable import and export control laws and regulations.

Huizhou Zhongshuo Industrial Co., Ltd.



706B, Bomeitang, Huicheng District, Huizhou, Guangdong

The pictures and text shown in this package have been checked in detail. If there is any printing error, our company will not bear the consequences. The product in kind shall prevail.

The selected trademark has been registered and is protected by intellectual property rights. No counterfeiting shall be allowed without permission. Offenders shall be prosecuted.

The Company reserves the right to correct and improve the products without prior notice. To the extent permitted by laws and regulations, Huizhou Shuwen Electronic Co., Ltd. reserves the right of final interpretation.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.