


User Manual



Indicator Lights

Indicator A (Bluetooth Mode Indicator):

After powering on, the blue light flashes when Bluetooth is unconnected; it stays steady blue after successful pairing, and flashes slowly blue during music playback.

Indicator B (TF Card Mode Indicator):

It lights up solid green under TF card mode, and remains green while playing recorded audio files.

Indicator C (Recording Mode Indicator):

Solid green light is on during recording, and turns off once recording finishes.

Button & Interface Instructions

1. Power / Play Button

Long press to power the speaker on or off; short press to play or pause audio.

2. Mode Button (M Button)

Short press to switch among Bluetooth Mode, TF Card Mode (supports TF card up to 32GB) and AUX Mode. When a dual-head 3.5mm audio cable is plugged into audio output devices such as computers, the unit will automatically switch to AUX Mode with a prompt tone, allowing it to work as an external speaker.

Note: Corresponding modes cannot be selected if no TF card or AUX audio cable is inserted.

Long press the M button to turn the vocal cancel function on or off.

3. Record Button

Short press once to start recording via the microphone; short press again to save the recording. After saving, long press this button to play back saved recordings. If multiple recordings are stored, use track skip buttons to switch between previous and next recordings.

- The recording function only works with a TF card inserted (all recordings are saved to the TF card). This button will not respond without a TF card.
- Music playback and recording cannot run simultaneously under TF Card Mode. Music will pause automatically during recording and resume when recording ends.
- Playing recordings under Bluetooth Mode will terminate the Bluetooth connection. Press the M button to switch back to Bluetooth Mode and reconnect your device.

4. Volume Knob

Turn counterclockwise to lower volume; turn clockwise to raise volume.

5. Sound Effect Key

Short press to play celebratory horn sound.

6. Sound Effect Key

Short press to play applause and cheer sound.

7. Sound Effect Key

Short press to play tense and funny sound effect.

8. Light Key

Short press to cycle different light effects; long press to turn lights on or off. The lighting effects activate automatically every time the speaker powers on, regardless of the light status before last shutdown.

9. Previous Track Key

Short press to play the previous track.

10. Next Track Key

Short press to play the next track.

11. Built-in Music Key

Short press to play preloaded instrumental tracks; short press repeatedly to switch to the next track in loop (3 built-in instrumental tracks in total).

- This function deactivates and the button does not work once Bluetooth is connected successfully.
- This button only supports play and track switching, without pause or stop functions.
- While playing built-in instrumental music, short press the Power/Play button to pause or resume playback; short press Previous/Next Track keys to switch tracks.

12. AUX Audio Input Jack

Automatically switches to AUX IN mode when a 3.5mm audio cable is plugged in.

13. TF Card Slot

Automatically switches to TF Card Mode when a TF card stored with MP3 audio files is inserted.

14. Speaker Type-C 5V Charging Port

15. Speaker Charging Indicator

Glow red while charging; the red light goes out once fully charged.

16. Microphone Power Button

Long press for 3 seconds to turn the microphone on or off. The blue indicator below stays lit when the mic is on and turns off when the mic is off. Short press to mute or unmute the microphone.

17. Mic Volume + Key

Short press to increase microphone volume; a "beep" alert sounds when maximum volume is reached. Double press to boost microphone reverb.

18. Mic Volume - Key

Short press to decrease microphone volume; a "beep" alert sounds when minimum volume is reached. Double press to reduce microphone reverb.

19. Microphone Voice Changer Key

Short press to cycle through built-in mic sound effects (4 voice-changing effects available). Long press to enable or disable vocal cancel function.

FCC Warning:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.