

XOI

规格参数

适用系统: 视频/阅读/自拍遥控器
支持iOS 14.8/Android 8.0以上
版本: 5.3
发射频率: 2.4-2.4835GHz
配对名称: X01
通讯距离: 10m
电池容量: 50mAh

触屏中间区域



长按:变焦缩小
单击:右翻页

长按:音量减
双击:下一曲

- 单击:拍照
- 双击:切换前后摄像头
- 长按:长按屏幕鼠标

关于苹果手机

1.确保手机iOS软件为14.8以上

2.辅助触控功能缩放功能必须打开

OS14.8以上版本需设置方可使用。1.设置如下:设置→辅助功能→触控→辅助触控→打开,出现圆点即可。2.设置如下:设置→辅助功能设置→缩放→缩放打开→3指轻点二下屏幕恢复。即可使用

设置如下:



注:ISO系统,如遇到无法正常使用,请重新关闭缩放功能重新打开.



3.以上2项如果确认OK，还是不能正常使用请把手机关机再开机一次。

4.打开辅助触控后，会出现2个点大的圆圈是可以移动的，不刷视频时30秒消失，安卓和鸿蒙连接上会有个圆点或箭头。

合格证

型号: _____

检验员: 

出厂日期:

XOI

Transmission frequency: 2.4-2.4835GHz
Communication distance: 10m

Applicable system: video/reading/selfie remote control
Support iOS 14.8/Android 8.0 and above Transmission frequency: 2.4-2.4835GHz
Version: 5.3 Communication distance: 10m



The middle area of the touchscreen
 Swipe up, down, left or right to turn page
 Single click: Confirm
 Double click: Like
 Triple click: Automatically like
 Long press: Zoom out
 Click: Turn right page

Long press: Volume down
Double click: Next song

Click: Take a photo
Double click: Switch between front and rear cameras
Long press: Long press the mouse position on the screen

- Click: Take a photo
- Double click: Switch between front and rear cameras
- Long press: Long press the mouse position on the screen

The operation is as follows (mobile phone model: iPhone X, iOS 14.8): Search for the device in the phone's Bluetooth settings. The name of the Bluetooth device is: X01.

After successfully pairing with the phone's Bluetooth, enter the short video APP. For details, refer to the function keys.

The charging indicator flashes red. After the battery is fully charged, it remains constantly illuminated in white.


If no operation is performed for more than 15 minutes after connection, the device will automatically shut down.

When using an iPhone, please note a few things:


1. Ensure that the iOS software of the mobile phone is updated to the latest version.
2. Auxiliary touch function must be tuned on.

Versions OS14.8 and above require Settings before use. The operation steps are as follows: Settings → Accessibility → Touch →> AssistiveTouch. When a dot appears, it's done. 2. Settings are as follows: Settings → Accessibility → Zoom → Zoom On → Tap the screen twice to restore.

The Settings for use are as follows:



Note: If the ISO system fails to function properly, please turn off the Zoom functions and then turn them on again.



3. If the above two items confirm ok but still cannot be used normally, please turn off the phone and turn it on again.

4. After turning on the auxiliary touch, two dots will appear. The large circles can be moved. They disappear after 30 seconds when not watching videos. There will be a dot or arrow on the connection between Android and HarmonyOS.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.