


Bookshelf Speaker

Ingenuity Creation & Brilliant Sound Quality


Quick Start

(SR32-01)



Please read all instructions before use for the best performance of this product. Save these instructions for future reference.

Box Contents



Bookshelf Speaker



Remote Control



Quick Start



Main and auxiliary
engine connection cable




Stereo 3.5mm to
3.5mm audio cable



Power Adapter

LED Indicators and Button Introduction



LED Indicators
Active Speaker


Standby
(Red)

Bluetooth
(Blue)


AUX
(Yellow)

USB-C
(Purple)

Know Your Remote



	Power button		Mute/Unmute
	Volume up		Volume down
	Previous track		Next track
	Play/pause	 	Increase or decrease treble
 	Increase or decrease bass		Music mode
	Movie mode		Dialogue mode
	Bluetooth mode		AUX mode
	USB-C mode (Sound card)		



01. Short press to reduce the volume, long press to switch to the previous song; AUX mode: Short press/long press to reduce the volume

02. Press and hold on/off, short press pause/play (short press to mute in AUX mode), double press to switch mode **BT / AUX / USB_C sound card**

03. Short press to increase the volume, long press to switch to the next track; AUX mode: Short press/long press is used to increase the volume

04. Bass output port

05. AUX input port

06. USB_C sound card


07. Speaker audio output

08. Power switch

09. AC power supply

10. Speaker audio input


Connection Diagram



- a** Bluetooth
- b** Audio cable (not supplied)
- c** USB-C cable (not supplied)
- d** 3.5mm to 3.5mm audio cable (supplied)
- e** Main and auxiliary engine connection cable (supplied)
- f** AC power cord (supplied)

Connecting with a TV

Active Speaker



- A** Method 1. Connecting using a 3.5mm to 3.5mm audio cable.
Select AUX mode.


Setting “PCM” on your TV

When all cables are connected properly, and LED indicator

lights properly, if there is no sound from tv or Soundbar, please setting your tv as below:

1. Press "Menu" on the TV's remote control.
2. Press the arrow keys on the remote to scroll to "Audio Settings."
3. Press "OK" on the remote control.
4. Scroll to "Advanced Audio" and press "OK". Some televisions may not have an "Advanced Audio" menu and may list various audio settings instead.
5. Scroll to "Audio Output Mode" or "Digital Audio Output Mode" and press "OK".
6. Scroll until "PCM" is displayed as the current audio output.
7. Press "OK" to save the settings.

Connecting a Bluetooth Device



- a. Press the "BT" button on the remote control or double-tap the "⏻" button on top of the active speaker, and then the LED indicator will flash blue.
- b. Turn on Bluetooth on the Bluetooth device.
- c. Select "SR32-01" and connect it. When your Bluetooth device is connected, the LED indicator blinks blue slowly.
- d. Play music files from the device, connected via Bluetooth, through the bookshelf speaker.

Specifications

Power output:	L/R: 60W
Signal to noise ratio dB(A):	L/R: ≥85dB (A)
Input sensitivity:	AUX: R/L: 650±50mV
Frequency response:	45HZ-20KHZ
Mid-woofer:	3 inch
Tweeter unit:	Φ20mm silk dome tweeter

Troubleshooting

No sound

- Check if the power indicator light is ON.
- Try to turn up the volume using either the master volume control or remote control.
- Ensure the audio cables are firmly connected and the input is set correctly on the speakers.
- Check if there is signal output from the audio source.

Cannot connect via Bluetooth

- Make sure the speaker is switched to Bluetooth input, in other audio input mode Bluetooth can not be paired or connected. Disconnect from any Bluetooth device by press and hold the volume dial in Bluetooth mode, then try again.
- Effective Bluetooth transmission range is 10 meters, please make sure operation is within the range.
- Try another Bluetooth device for connection.

The SR32-01 Bookshelf Speaker does not turn on

- Check if mains power is connected. or if the wall outlet is switched on.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Thanks for reading!