


# COOLCUBE MINI

## PORTABLE DESKTOP FAN




**USER MANUAL**

### PRODUCT OVERVIEW

Model: Cool Cube Mini  
Material: ABS + PP  
Rated Power: 5W  
Charging Voltage: DC 5V – 1A  
Battery Capacity: 2000mAh  
Wind Speed Settings: 3 Levels

### COMPONENTS

1. Fan Cover
2. Fan Blade
3. Type-C Charging Port
4. Power Button
5. Power Indicator Light



### OPERATING INSTRUCTIONS

- **1. Power On :**
  - Press the power button once. The fan will start on low-speed mode, and the white indicator light will turn on.
- **2. Adjusting Speed :**
  - Press again to switch to medium speed.
  - Press a third time to switch to high speed.
  - Press a fourth time to power off the fan.
- **3. Charging :**
  - Connect the Type-C cable to a power source.
  - The indicator light will illuminate while charging.
  - Ensure the battery is fully charged before first use.

### CHARGING INDICATOR

- All three speeds are indicated by a blue LED light
- Charging status is also shown via the indicator light.

### USAGE MODES

- Desktop Fan: Place it on a flat surface for standard use.
- Wall-mounted Fan: Can be mounted on smooth, dry surfaces. Ensure the surface is clean and secure before installation.

### SAFETY PRECAUTIONS

- Do not insert fingers or foreign objects into the fan grille.
- Children should use this product only under adult supervision.
- Do not disassemble or modify the fan.
- Avoid contact with liquids, metals, or other objects that may damage the internal components.
- Always unplug the device by holding the plug, not the cable.
- Disconnect the fan from power when not in use for extended periods.

### BEFORE FIRST USE

- Charge the fan fully before operation.
- Ensure the input power supply matches the product's rated voltage.
- If using as a wall fan, only install on properly cleaned glass walls.