

User Manual



Bluetooth Headband Headphone

1. Safety instructions

■ Storage and use

Do not store or use this device in extreme temperatures.
Do not store or use this device in wet or damp environments.
Do not expose this device to dust, oil or smoke.
Do not drop or strike this device.
When transporting this device store securely to avoid impact damage
Do not scratch this device with sharp objects.

1

■ Maintenance

Please remove the bluetooth headphones from this device before washing, this can be done through the earphone access slot (see chapter 4. Part Names and Functions).

Refer to the product care label for washing instructions.




2. Main Features

- Wireless Headset for Bluetooth Devices
- Hands-Free Calls with Integrated Microphone
- Built-in Rechargeable Battery
- Type C USB Charging Port
- Range: up to 10m (Class II)
- Working time: up to 8 hours
- Bluetooth Version 5.4
- Siri

2

3 Accessories




User manual



USB charging cable

4. Part Names and Functions



3

1. Volume down/previous track
2. Enter (Power ON OFF/pause/phone answer/hang up/re-dial)
3. Volume up/next track
4. Earphone access

5. Operations

5.1 Switch On/Off

To switch the device on, press and hold the Enter button until hear "Power On".

To switch the device off, press and hold the Enter button for 5 seconds, until hear "Power off".

5.2 Bluetooth connections

To pair to a device, turn the music headband off, then press and hold the Enter button for seconds to enter pairing mode. While in pairing mode, hear "Pairing" voice. If required, the password for pairing is: 0000.

4

-For Mobile Phones

- 1) Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed)
- 2) Select "music headband" from the available devices and confirm connection.
- 3) Hear "Pairing" voice to indicate a successful connection.

Noted: Accessing Bluetooth settings on mobile phones varies for each phone, to find the information for your phone, please refer to its user manual.

-For computers

- 1) Enable the Bluetooth function on your computer.
- 2) Select "Devices and Printers" from the Control Panel and click "Add a device" to start scanning for new devices.
- 3) Select "music headband" from the available devices, the system will install the driver automatically.

Noted: For Windows XP and Vista, a third-party Bluetooth driver is needed (not included).

5

- 4) Hear "Connected" voice to indicate a successful connection.
- 5) To output sound from your computer to the music headband, select "Sound" from the Control Panel, then select the "music headband" and click "Set Default". All sound from your computer will now play from the music headband.

Noted: When switched on, the music headband will automatically reconnect to the last paired Bluetooth device if it is in range.

5.3 Remote Control

The music headband is able to control the music playing on either a mobile phone or a computer with a Bluetooth connection.

Press "||" to pause or resume playing music.

Short press "◀" or "▶" to decrease or increase the volume.

When maximum volume is reached a chime is heard.

Press and hold "◀" or "▶" to go to the previous or next track.

Triple click "||" for Siri.

6

Noted: Music playing control is only compatible with devices that support A2DP. Please refer to your device's user manual for its A2DP compatibility.

5.4 Hands-free Calling

While connected to your mobile phone, the music headband will act as a hands-free system for calls.

Press "||" to pick up or hang up a call.

Press "||" twice to re-dial the last phone number.

6 Charging

Connect the music headband to a powered USB port by using the provided USB charging cable. While charging, the power LED will light red. And go off when the battery is fully charged.



USB Port

7

7 Specification

Bluetooth	V5.4
Operating Range of Bluetooth	Up to 10m
Operating Range of microphone	51m
Battery	Li-ion 3.7v/150mAh
Charging time	2 hours
Stand-by time	About 100 hours
Continuous working time	About 8 hours
Bluetooth name	music headband

8. Troubleshooting

Problem	Solution
Won't turn on.	Please charge the music headband.
Can't find the music headband.	Confirm the music headband is in pairing status and within 10 meters from the device.
Can't install the driver for music headband on a computer.	Update the driver of the Bluetooth module on your computer.

8

The sound quality is intermittent in Bluetooth mode.	Disable the Wi-Fi on your source device.
No sound.	Check the volume on both the source device and the music headband.
The earphones do not align with my ears.	Wear the headband so that the left side earphone is where you want it, then carefully move the right earphone within the headband where it needs to go by gently pressing and squeezing along an edge of the earphone.

9

FCC ID: R5B-H12

FCC Compliance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

15.105 Information to the user.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Exposure Warning Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.

10