


1HORA

WIRELESS SPEAKER

BOC060



USER MANUAL

PRODUCT SPECIFICATIONS:


- Model: BOC060
- Bluetooth Version: 5.1
- Support: L2CAP / A2DP / AVRCP, receive AUDIO signal and control the AUDIO device.
- Supports HSP / HFP (hands-free), built in microphone for hands-free calls
- Connection Distance: 10M approx
- SNR: $\geq 90\text{dB}$
- Battery: 2400mAh 3.7V 8.88Wh
- Playingtime: 4H
- Charging Time: 4-5H
- Speaker Size: $\Phi 45\text{mm}$
- Power: $4\Omega/5\text{W} \times 2$ RMS
- Frequency: 120HZ-20KHZ
- Input: $5\text{V} \sim 1\text{A}$
- Size: $\Phi 65.5 \times 181.4\text{mm}$
- Weight: 418g

PRODUCT FEATURES:

1. Advanced bluetooth chip and circuit design techniques, compatible with all wireless devices.
2. FM function, you can search automatically broadcast radio stations.
3. With HI-FI speaker, to ensure clear and bright sound.
4. Support TF card and USB card, play audio with MP3 mode.

5. The distance range is about 10 meters.
6. With built-in AUX line, you can directly connect the external devices, such as, tablet PC/TV/cell phone.
7. It will turn off automatically if you disconnect Bluetooth for 5 minutes.
8. Support dual speaker output, allowing you to connect two speakers simultaneously and enjoy a more immersive music experience.

KEY AND SLOT FUNCTIONS:



- ① Type C Charging: Use the Type C cable for charging.
- ② TF slot: It can decode and play MP3 audio when TF card is put into the slot.
- ③ USB slot: You can play MP3 format audio when you put the USB card into the slot.
- ④ AUX Line-in Slot: Use JACK 3.5mm input through external devices.

- ⑤ Long press to turn on / off. When playing music (USB card/ TF card/ Bluetooth), short press to "play / pause". In TF mode, short press to search station automatically, press again to stop searching. In Bluetooth mode with paired device, when receive a call, short press to answer the call, short press again to end the phone. Press twice to refuse calls.
- ⑥ Press "-" key once: Volume down. Long press "-" key: Return to the previous song.
- ⑦ Press "+" key once: Volume up. Long press "+" key: Skip to the next song.
- ⑧ When playing music (USB card /TF card / Bluetooth / Line-in / FM), short press to switch modes.
- ⑨ Light mode switch: When the music starts to play, the certain pattern of the lights will follow the rhythm of the music; to change the light pattern you need to press the button to get the "breathing light"; To turn off the horn light you need to press button again.

Keep both 2 speakers in Bluetooth mode without pairing with the phone. Press and hold the "M" button on each speaker for 3 seconds until you hear a "beep" sound indicating they have entered TWS pairing mode. Once you hear the prompt again, it means the two speakers have successfully paired in TWS mode.

NOTE: In FM mode, to get better radio stations, suggest to insert the 3.5mm Aux wire or charging cable to get FM scan automatically, then choose the stations you like.

RESET: Long press ON/OFF for 10 seconds to reset.

WARRANTY STATEMENT:

The warranty period for this product is 12 months after purchase.

If you have any questions, please contact a customer service representative for assistance.