

# EASY INSTRUCTIONS

## Smart Electrician Digital Timer

SKU# 368-1819

### STEP 1: SET THE CURRENT TIME

1. Press the DAY/TIME button
2. Press + or – until the current day of the week is displayed. Press ENTER.
3. Press + or – until the current hour is displayed. **THIS IS IN MILITARY TIME**, so 1:00 PM is 13:00, 4:00 PM is 16:00, etc. Press ENTER.
4. Press + or – until the current minute is displayed. Press ENTER.
5. Press + or – until the current second is displayed (OPTIONAL). Press ENTER.
6. Press DAY/TIME to return to the main/home screen where the current day and time should be showing.

### STEP 2: PROGRAM YOUR TIMER FOR THE TIMES YOU WANT IT TO TURN ON AND OFF EACH DAY

1. Press the DAY/TIME and ENTER buttons **at the same time**. The screen should say 1 ON. This means we're telling it what time we want the timer to turn on. Press ENTER.
2. Press + or – until the days of the week that you want your timer to operate are highlighted. You can select one day of the week, every other day, weekdays, weekends, or all 7 days of the week. Press ENTER.
3. Press + or – until the hour that you want your timer to turn on each day is highlighted. **THIS IS IN MILITARY TIME**. Press ENTER.
4. Press + or – until the minute that you want your timer to turn on each day is highlighted. Press ENTER.
5. Now the screen should say 1 OFF- this means we're telling the timer what time we want the timer to turn OFF each day. Press ENTER.
6. Press + or – until the days of the week you want your timer to turn off are highlighted. Press ENTER.
7. Press + or – until the hour you want your timer to turn off are highlighted. **THIS IS IN MILITARY TIME**. You can have the timer turn off after midnight of the next day- just select the correct time to turn off and it will know what to do. Press ENTER.

8. Press + or – until the minute you want your timer to turn off are highlighted. Press ENTER.
9. Now the screen should say 2 ON. If you want to have your timer come on and off at multiple times each day, you would need to set a 2<sup>nd</sup> program. For example, you want the timer to come on at 1 PM and off at 2 PM, on at 3 PM and off at 4 PM, you would have set 1ON and 1OFF settings for the 1PM to 2PM program, and can use 2 ON and 2 OFF for the 2 PM to 3 PM program, and so on. You can have up to 16 different programs, on different days of the week if you wish. If you just need the 1 program set, you can press DAY/TIME to return to the home screen, which should show the current time and day of the week.

### STEP 3: MAKE SURE YOUR TIMER IS SET TO RUN THE PROGRAM

1. Press the MANUAL button until the home screen says “AUTO”. This means the timer is ON and will run your program(s) automatically. You don’t need to do anything else.
2. If for example, your timer/device is off right now but you want to turn it on outside of your regularly timed hours, you can press the MANUAL button to turn the power on to your device.
3. If the timer and your device are currently turned on, and you want to turn them off earlier than the scheduled time, you can press the MANUAL button to turn the power off.
4. When you’re done, just make sure to press the MANUAL button until the home screen say “AUTO” and the timer will automatically run the program(s) you have set.

**IF YOU HAVE ANY QUESTIONS PLEASE GIVE US A CALL!**

**(877) 898-3958**

We are open for calls from 9AM – 5 PM Central Time, Monday-Friday excluding US Holidays. If we don’t answer, please leave a voicemail! We are very responsive and will get back you as soon as we can!