



SCOSCHE
FOUNDIT™ WALLET+
LTWAL2



OVERVIEW
APERÇU / DESCRIPCIÓN GENERAL



Card Storage

The Foundit Wallet can store up to 4 cards in its reader pocket, 2 cards in the interior slots plus 1 more under the window pocket inside for a total of 7 cards. The window pocket is designed to store a driver's license or other ID card for presentation without the need for removal (Fig. 1, Pg. 2).

Apple Users

To add FOUNDIT™ WALLET+ to your Find My® network:

- Ensure Bluetooth Location Services are enabled.
- To enable discovery, press the button on the Foundit Wallet (Fig. 2, pg. 2). A confirmation sound will play.
- Open the Find My app on your Apple device.
- Select "Items" at the bottom of the screen, then "+" to add other items.
- Select it and assign a name to your item (this can be changed anytime).
- Select an icon that will represent the Foundit Wallet+ on the map screen (the icon can be changed anytime).
- Select finish.

- The Foundit Wallet+ can now be located using the Find My app.
- Select FOUNDIT™ WALLET+ in the Find My® App to:
- See last known location on the map or current location if nearby.
- Find by playing a sound once it is in range.
- Check battery status.
- Share location with others.
- Change the device name.

visit scosche.com/ind

IF FOUNDIT™ WALLET+ IS NOT DISCOVERABLE ON YOUR DEVICE
DURING SETUP, TRY THE FOLLOWING:

1. Use the Reset procedure.
2. Restart your Device.

(refer to page 4 for details)

Charging the Battery

The Foundit Wallet+ can be recharged using any Qi-compatible wireless charger. Place the charging symbol on the back of the housing (Fig. 3, Pg. 2) against the charging surface. An orange light indicates charging; a green light indicates charging is complete (Fig. 4, Pg. 2). The light will turn off when the battery is fully charged. The light will not affect charging. If the charging indicator light is not on simply adjust the position of the Wallet on the charger until the light turns on.

Android™ Users

To add FOUNDIT™ WALLET+ to the Find Hub App:

- If Find Hub is not pre-installed on your device, download the app on Google Play.
- Ensure Bluetooth and Location Services are enabled.
- To enable discovery, press the button on the Foundit Wallet+ (Fig. 2, pg. 2). A confirmation sound will play.

- The Foundit Wallet+ will automatically pop up on your device screen.
- Follow the prompts to add to your Find Hub items list.

The Foundit Wallet+ can now be located using the Find Hub app.

Select FOUNDIT™ WALLET+ in the Find Hub app to:

- See last known location on the map or current location if nearby.
- Find by using the haptic feature or playing a sound if it is in range.
- Share location with others.
- Check battery status.
- Change the device name.

visit android.com/ind

IF FOUNDIT™ WALLET+ IS NOT DISCOVERABLE ON YOUR DEVICE
DURING SETUP, TRY THE FOLLOWING:

1. Use the Reset procedure.
2. Restart your Device.

(see below)

Turn off or Reset Procedure

To turn off/disabled without resetting:

- Press and hold the button for 15 seconds until a confirmation sound is heard (Fig. 2, Pg. 2). Foundit Wallet+ is now disabled and cannot be found until the button is pressed again to re-enable it.

To reset to original factory settings:

- Short press the button once, then press and hold for 5 seconds until you hear 4 steady beeps (Fig. 2, Pg. 2). Foundit Wallet+ is now reset to original factory settings.

- Remove from your wallet and add to the Find My app (Apple device) or the Find Hub app (Android device).

- The Foundit Wallet+ is reset to its original state. It can no longer be found and can now be paired with any device.

Rangement pour les cartes

l'outil Foundit Wallet+ peut ranger jusqu'à 4 cartes dans sa pochette extérieure, 2 cartes dans les fentes intérieures et 1 carte de plus sous la pochette intérieure. l'indicateur, pour un total de 7 cartes. La pochette intérieure est conçue pour ranger une permis de conduire ou une carte d'identité afin de faciliter sa présentation sans devoir la sortir (Fig. 1, page 2).

Utilisateurs Apple

Pour ajouter le chargeur FOUNDIT™ WALLET+ à votre réseau Find My® :

- Assurez que les services Bluetooth et les services de localisation sont activés et autorisés à deux niveaux.
- Pour activer Discovery appuyez sur le bouton de Foundit Wallet+ (Fig. 2, page 2). Un son de confirmation va émettre.

- Lancer l'appli Find My+ sur votre appareil Apple.

- Sélectionner les 4 items (préfixe) au bas de l'écran, puis "+" puis «Ajouter d'autres items».

- Le Foundit Wallet+ devrait apparaître sur votre écran.

- Sélectionner l'article, et lui assigner un nom (ce nom pourra être modifié en tout temps).

- Sélectionner une icône, celle représentera votre localisateur sur la page de la carte (peut être modifiée en tout temps).

- Sélectionner «Finir l'ajout».

- Le Foundit Wallet+ peut maintenant être localisé en utilisant votre appli Find My.

- Sélectionner FOUNDIT™ WALLET+ dans l'appli Find My® pour :

- Voir la dernière emplacement connu sur la carte, ou un emplacement sauvegardé à l'avance.
- Faire résonner ou utiliser la fonction haptique pour trouver l'objet si c'est possible.
- Partager l'emplacement avec les autres.
- Vérifier l'état de la pile.
- Changer le nom de l'appareil.

OU

- Visiter l'adresse scosche.com/ind

SI LE CHARGEUR FOUNDIT™ WALLET+ N'EST PAS DÉCOUVERT PAR VOTRE APPAREIL
LORS DE LA CONFIGURATION, ESSAYEZ CE QUI SUIT :

1. Réinitialiser la procédure de mise à jour.
2. Redémarrer votre appareil.

(référer à la page 5 pour plus de détails)