


INSTRUCTION MANUAL

(Please read these instructions carefully before using it)


Brief introduction to the functions of the remote control car




If the remote control car can't walk in a straight line, you can adjust the front left and right fine-tuning steering levers at the bottom of the car to the balance position to make the car return to a straight line.

Fitting :

- ① USB charging wire X1
- ② 7.4V BATTERY X1




WARNING:
Please take out the battery if not used for a long time.



When the car is blocked or stuck and unable to move, it will automatically cut off the power to protect the motor and the battery. In this case, you need to turn off the power switch of the car and then turn it on again to restore the power supply. Similarly, if the car has not been operated for a long time (about 5 minutes), it will also automatically cut off the power to save electricity. At this time, you just need to turn off the power switch of the car and then turn it on again to restore the power supply.


Assembly of the transmitter battery

- 1 Remove the battery lid




- 2 Load 3 AA-size alkaline batteries as shown in the illustration. Caution: install batteries with correct polarity.

3x"AA"Size Batteries for transmitter(Not Included)




- 3 Replace the lid as shown.




- Use the batteries of same brand
- Do not mix old and new batteries in use.
- Remove the batteries from the transmitter when not in use. Do not use leaky batteries.

- Please fully charge the battery pack before each use.
- This product is not a toy, but a full-scale model car.
- Children under ages 14 are not advised to operate this product unless they are closely supervised by adults.

Transmitter function introduction



1. **Power Switch(On/Off):** Slide it to switch on or off power.
2. **Steering Wheel:** Left and right steering control.
3. **Throttle Trigger:** Pull to accelerate and push to reverse.
4. **Power Indicator light:** It flashes rapidly during binding. After binding, it stops flashing and stays on solid.
5. **Speed Adjustment:** Press button "1" "2" "3" to adjust speed freely.
6. Turn on/off the light; switch the light between steady-on and flashing modes.



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.