



ST-P20

I. Download and Install the APP

1. Quickly download and install by scanning the QR code.



HiEasy APP


2. Search for "HiEasy" in the mobile app store to download and install.



1/19

II. Account Registration and Login


1. Open the APP, click "Register with Mobile/Email" and follow the prompts to register an account. Mobile numbers and emails can both be used for registration.
2. For existing accounts, directly enter the account and password to log in.



2/19

III. WiFi Camera Connection Methods

Before adding a WiFi camera, ensure that your mobile phone is connected to WiFi and Bluetooth is turned on. Place the camera close to the router and power it on.




Preparations before addition

3/19


Bluetooth Pairing:

1. After the camera powers on and you hear the broadcast "Waitign to be added", open the APP and start adding the camera. If you hear an error broadcast, press and hold the reset button for 5 seconds to restart the camera.
2. Enter the WiFi password as prompted and wait. When the camera broadcasts "Device added successfully", the addition is complete. This process takes 60 - 120 seconds.



4/19


3. After successful addition, set the camera name and click to complete. You can then view the added camera on the home page.



5/19

QR Code Pairing:


Open the APP and scan the QR code on the camera as prompted.




6/19

AP Hotspot Pairing:

1. Open the APP and select AP hotspot pairing as prompted.
2. Connect to the hotspot directly from your mobile phone for local area network viewing., Hotspot password: 01234567.




7/19




8/19

VII. Alarm Push

1. After the device is added successfully, click "Alarm" and follow the prompts to operate.
2. Alarm messages can be used to view videos and pictures, which are saved for 7 days by default.




9/19



10/19


View recorded videos. Recordings can be retrieved from the TF card or cloud storage. Cloud storage can be purchased within the APP for more secure recording.



11/19

X. Sharing Function


1. Click the share icon on the home page to share the camera with family and friends for viewing. (Requires account registration).
2. Enter the sharing settings to set sharing permissions, with multiple sharing methods available.



12/19

XI. Recording Storage


1. Continuous Recording: 24 - hour continuous recording throughout the day.
2. Alarm - Triggered Recording: Records only after an alarm is triggered, which can save storage space on the memory card and make the recording last longer.
3. Video Clarity: Higher clarity results in shorter video storage time.
4. Formatting the Storage Card: New cards need to be formatted before first use. Existing recordings will be cleared when formatting.



13/19

XII. Alarm Management


1. Human - Shape Detection Alarm: When turned off, it will not detect people entering and will not send alarm messages. High sensitivity detects at a longer distance, and low sensitivity reduces false alarms.
2. Motion Detection Alarm: Used to detect the movement of objects other than people. Off by default.
3. Detection Area: Set the area for human - shape detection.
4. Sound and Light Alarm: Set different alarm sounds and modes.
5. Crying Detection: Detects the crying of infants and toddlers to monitor the baby.



14/19

XIII. Night Vision Modes

1. Smart Dual - Light: In night vision black - and - white mode, when a person is detected, the white - light floodlight turns on and the image becomes color. It reverts to black - and - white after the person leaves.
2. Smart Full - Color: In night vision color mode, the white - light floodlight turns on automatically.
3. Smart Infrared: In night vision black - and - white mode, the infrared fill - light turns on.



15/19

Warranty Card

Product	Model		
Purchase Date	Distributor		
Fault Reason			
Fault Handling			
Customer Name	Email		
Phone	Email		
Address			

16/19

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

17/19