



产品说明书

前言

感谢您购买MAIWO（麦沃）产品，为了您能够更好的使用本产品，请您在正式使用本产品前，仔细阅读使用本手册所提及的操作要点及注意事项。

MAIWO（麦沃）为深圳市凯祥源科技有限公司注册商标。

声明事项

深圳市凯祥源科技有限公司只对产品本身存在的问题负有保修和维修责任，对于用户操作所引起的数据资料删改或丢失，不负任何责任，也不对因此造成的其它间接损失负责。鉴于数据资料的价值不可估量，正式操作本产品之前，重要资料请自行备份。


注意事项

如果您使用的是新的硬盘，需要将硬盘初始化并格式化后才能正常出盘。具体参考新硬盘初始化、分区与格式化教程。

产品参数

产品名称：

MAIWO K3016P2双盘位 AHCI&M.2-NVMe固态硬盘底座



产品名称	MAIWO K3016P2双盘位 AHCI&M.2-NVMe固态硬盘底座
支持硬盘	M.2 NVMe协议 SSD/AHCI SSD (注意: AHCI需要进行转接成M.2接口可连接本产品使用, 推荐MAIWO KT065转接板搭配使用, KT065适用Macbook Air/Pro 2013 2014 2015 2016 2017等版本AHCI SSD转接, 详见说明书)
产品盘位	双盘位
外部接口	Type-C
产品材质	ABS高强度工程塑料
产品功能	一拖一硬盘脱机对拷; 数据传输
产品尺寸	78.5X76.5X19.1MM
操作系统	WindowsXP/7/8/10/11、Mac OS、Linux
指示灯状态	电源灯: 蓝色 (读写克隆常亮) 克隆进度灯: 蓝色 (克隆时闪烁, 克隆完成常亮) 硬盘显示灯: 白色 (读写克隆闪烁, 待机常亮, 硬盘提示异常会出现红灯闪烁)

①

操作指南


一、产品读写功能：

1.1. 硬盘接口插好，电源插好连接在 DC IN 接口，数据线连接在 PC 端口（另一端接好电脑接口）。

注：只有 Source 插口可以插转接后的 AHCI 硬盘。



1.2. 按一下电源开关，对应的硬盘显示灯白色亮起（如硬盘识别有异常，对应的盘位灯会亮红色闪烁）。




注：如果是旧硬盘，那么在“计算机”里可以发现新增的硬盘，并可以正常读写；如果是新硬盘，需要先进行初始化、分区和格式化后，才能使用。

②

操作指南


二、新硬盘初始化、分区与格式化教程：

2.1. 硬盘初始化: 鼠标右键点击“计算机”，查看“管理 - 磁盘管理”发现新磁盘，将其初始化；



注：硬盘初始化有MBR和GPT两种格式选择，如果您的硬盘小于或等于2T，请选择MBR格式，大于2T请选择GPT格式。

2.2. 分区格式化: 新硬盘初始化后将会变成“磁盘1”，用鼠标右键点击“磁盘1”，然后点击“新建简单卷”进行分区，根据提示操作，可选择所需要分区的大小，并勾选格式化选项，可以依次建立多个分区，直到完成。




③

操作指南

三、硬盘克隆：

3.1. 硬盘接口插好（注意：Source 插有数据的母盘。Target 插需要拷贝的目标盘。Target 盘实际容量要大于或者等于 Source 盘，否则不能进行克隆），只需将电源连接在 DC IN 接口，不需要接数据线。

注：只有 Source 插口可以插转接后的 AHCI 硬盘。



注：Target 盘实际容量≥Source 盘容量

④


操作指南

四、硬盘克隆：

4.1. 按一下电源开关，对应的硬盘显示灯白色亮起（如硬盘识别有异常，对应的盘位灯亮红色闪烁）。

4.2. 硬盘灯正常亮起后，长按右下角克隆按键 3-5 秒后 25%-100% 蓝色灯开始闪烁，紧接着再按一下克隆按键，25%-100% 蓝色灯开始依次循环闪烁（硬盘显示灯也是闪烁状态），克隆开始。

4.3. 克隆进度到 25% 灯常亮起，依次进度到 50%-75%-100% 全部常亮后，硬盘显示灯也常亮，克隆完成。关掉电源后再取下硬盘。



LED显示进度25%-50%-75-100%

⑤


关于保修

- A、本产品执行国家三包政策：如有质量问题，7天包退，15天包换，1年保修。起始时间以客户收到产品的日期起计算。
- B、电源线、USB线等配件不在保修范围内，如损坏需有偿更换。
- C、天灾造成损坏不在保修范围内，可以提供有偿维修服务。
- D、消费者使用不当，造成产品故障，可以提供有偿保修服务。

如果您在操作过程中遇到问题，请拨打我们的客服热线4000-666-205，我们的技术人员将为您提供技术支持。

保 修 卡			
产品品牌	MAIWO	型 号	K3016P2
购买日期		保修期限	
用户姓名		联系电话	
客户地址			
技术支持 客服热线	4000-666-205		
销 售 商			

⑥




K3016P2 2Bay AHCI&M.2 NVMe SSD Docking Station Duplicator

Specification

Product Name:

MAIWO K3016P2 2Bay AHCI&M.2 NVMe SSD Docking Station Duplicator



Specification

Product Name:

MAIWO K3016P2 2Bay AHCI&M.2 NVMe SSD Docking Station Duplicator


Brand	MAIWO
Product name	MAIWO K3016P2 2 Bay M.2 NVMe SSD Docking Station
Support SSD	M.2 NVMe SSD/AHCI SSD(AHCI Should Change to M.2 Interface,Recommended for Use with MAIWO KT065 Transfer Card, KT065 Support Macbook Air/Pro 2013 2014 2015 2016 2017 AHCI SSD,More Details in Specification)
Interface	Type-C
Material	ABS Plastic
Main Function	M.2/AHCI SSD Write/Read/Clone
Product Size	78.5*76.5*19.1mm
Systems	WindowsXP/7/8/10/11、 Mac OS、 Linux、 etc
Indicator status	- Power Indicator: Blue, steady on when reading/writing/clone - Clone Progress Indicator: Blue(blinking during clone, steady on after clone) - SSD Indicator: White (blinking when reading/writing clones, steady on when standby, and blinking red when the hard disk is abnormal)

Quick Installation Guide


1. Read & Function:

1.1. Insert your SSD,plug the power into DC IN port,connect the data cable to PC port,and connect the other end to your device.

PS: Only the source port can plug into the converted AHCI hard disk.



1.2. Press the power button,the corresponding white disk indicator light on,If a SSD is abnormal, the disk indicator blinks red.





If your M.2 hard drive is an already used hard drive, please find the new hard drive in computer and you can start normal use. If your SSD is new, you need to initialize, partition, and create a new partition before you can use it.

Quick Installation Guide

2. New hard drive format:


2.1. View "Computer-Manager - Disk Management" to find the new disk.



Quick Installation Guide


2. New hard drive format:

2.2. Right click the "Disk1", then click "New Simple Volume".



2.3. According to the instruction, choose the size of partition, then click "Next" to finish.

2.4. Then you can find the new hard disk in the "Computer", it's ready to be use.




Operation Guide

3. SSD Clone:

3.1. Insert SSD into corresponding port,Back up the data of your subdrive before cloning, because cloning overwrites the original content of the subdrive.Target disk storage should ≥ source disk storage,connect to power supply, no need to connect to USB C cable.

PS: Only the Source port can plug into the converted AHCI disk.



PS: Target disk storage should ≥source disk storage

Operation Guide

4. SSD Clone:

4.1. Press the power switch,the corresponding white light on, (If a SSD is abnormal, the disk indicator blinks red.)

4.2. When SSD slot light on, hold the clone button for 5 Seconds,then the 25%-100% clone progress indicator light began to flicker, press the clone button again, 25%-100% blue clone progress indicator light began to flicker in a cycle. (SSD Slot light will flicker too), clone began

4.3. When the 25% clone progress indicator light is on,in order to 25%-50%-75%-100%. When all the clone progress light is on, SSD slot light is on,clone succeeded.Turn off the power and remove the SSD.

