nonser

Phone setup


View full video setup tutorial at:

https://www.nonser.net

WiFi Extender Mode

Step 1

Plug the Extender into a power outlet near your existing Wi-Fi Router. And then wait until the Power LED turns flashing slowly.



FAQS and SUPPORTS

Q1 How do I reset the Extender?

A1: Press the "Reset" button about 5 seconds. When the LED indicator changes from flash quickly to solid on to flash slowly then you setup the extender again.

Q2 How far should the Extender be from the router?

A2: Plug in the extender about halfway between your router and the Wi-Fi dead zone. The location you choose must be within the range of your router.

Q3 Does the Extender increase my internet speed?

A3: No, it increases the range of your Wi-Fi Network. Sometimes, the WiFi speed may reduce due to external influences, such as microwave oven or thick wall.

Q4 What to do when an Extended Signal cannot connect to the Internet or obtain an IP Address?

A4: Please log in to the router's admin interface and change the wireless encryption mode to WPA-PSK/WPA2-PSK.

Kindly Remind:

▲Do not attempt to disassemble, repair, or modify the device.

▲The socket-outlet shall be installed near the equipment and shall be easily accessible.

▲Keep the device away from water, fire, humidity or hot environments.


▲If the product encounters any problems during use, please feel free to contact us with email: techhelp0024@gmail.com.

Suggestions

Before configuring the extender, please go into the router settings and change the wireless channel (2.4G/5G) from Auto to Fixed mode, which helps maintain the signal stability of the extender. If there is an issue with the extended network, reset the WiFi Extender to factory settings and set it up again.


Step 2

Go to your Phone settings. Open Wi-Fi, and turn it ON. Search for the network name "WiFi pro_xxxxxx" or "WiFi 5G pro_xxxxxx" and click on it to connect and LOGIN. (If it does not jump to the settings login page, please go to the browser and enter 192.168.11.1 to the settings login page)



Step 3

Click "WiFi Extender Mode" to the next step. And then wait for available networks.




Step 4

Click on the name of the existing Wi-Fi Network you want to extend. (If the WiFi you want does not appear, please scroll to the end and click "Manual Setup" to add it)



Step 5

Type the same password as your router. Click the " NEXT" button, and then click the "Finish" button; Wait 40s and the WiFi list will appear.



Step 6

Finally, select the WiFi(with -EXT) that has been extended to connect and then complete the settings.

Action	Indication	Status
Plug in about for 30s	LED fixed turns flash slowly	Turn on
	LED flash slowly turns fixed	Extension successful
Press Reset button about for 5s	LED flash quickly turns fixed turns flash slowly	Reset successfully
Connect the network cable	LED solid on	Ethernet Port
WPS button	LED fast blinking	WPS enable

nonser

Phone setup


View full video setup tutorial at:

https://www.nonser.net

AP Mode Settings

Step 1

Note: Please complete the configuration on your mobile phone before plugging in the network cable.



Click "AP Mode Settings" to the next step.


Step 2

Please set the 2.4G/5G SSID name and password according to your personal preferences



Step 3

Click the "Finish" button. Wait 40 seconds and the WiFi list will appear.



Step 4

Finally, Select the new WiFi name to connect and then complete the settings.