



成品尺寸：50X80mm

Wirelss Speaker



MODEL:E12

Diagram



1

2

3

4

5

1


2

3

4

5

Power ON/OFF



ON 2S


OFF 3S

Power on: Press and hold MFB for 2 seconds, with blue light flashing until you hear the voice "Power on".

Power off: Press and hold MFB for 3 seconds, until you hear the voice "Power off".

How to Pair


Step1:



Hold on (3s) Pairing Mode

1. Press and hold MFB for 2 seconds until power on, and wait about 4 seconds to enter the pairing mode, with blue light flash and the voice "Pairing" heard.

Step2:




Bluetooth E12 Connected

< 1m (3.3ft)

2. Turn on Bluetooth function on the cellphone, search "E12" and click to pair. The voice "Connected" will be heard after the successful connection.

Volume Control/Music Control



Hold on 4s Disconnect


Click Once

Hold on 1~2s

Click Once

Hold on 1~2s

Play/ Pause/Answer a Call/ Hang up a Call/ Reject a Call/ Siri



Click Once


Hold On (1-2S)

Double Click

Hold On (5S)

Factory Reset

Charge the Speaker




Red light on

Red light off

Output : 5V 1A

TWS Mode Connect

Step1:



OR

A


B

Triple Click

After you triple-click the MFB button, Simply triple-tap one of the speakers, you will hear the voice "tws mode". Please wait for the device to automatically connect. After connected, you will hear the voice "tws mode connected".

Notice: If speaker is already connected to a device and you wish to use TWS mode, you must triple-click that speaker to pair it with another unit in TWS mode.


Step2:



Bluetooth E12 Connected

< 1m (3.3ft)

TWS Mode Disconnect



A

B

Triple Click

In tws mode, you can triple-tap one of the speaker, when you hear "tws mode disconnected", it means exit tws mode.


Note

1. In TWS mode, turned off one speaker, the other one will be turned off too.

2. In TWS mode, when reboot the speakers, the speakers will be automatically connected to the tws mode.

3. When disconnected tws mode, can triple click one of the speaker to reconnected tws mode

RGB light



Click Once

Hold On 2S

Mode 1 Mode 2 Mode 3 Mode 4 ON OFF

Warranty&Service

Start with your purchase of our products, we promise that the headphone has a one-year warranty service. Whether you have any questions about the product or any problems with the product, we will try our best to provide the solution for you.

Please feel free to contact us and we will reply within 24 hours! The following two ways:

1. Customer Service Email : Keransean.customer.service@hotmail.com

2. Amazon Official Mail.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirements. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or in conjunction with any other antenna or transmitter.

The device can be used in portable exposure conditions without restriction.

! WARNINGS/WARNUNCEN/ADVERTENCIAS/AVERTISSEMENTS/AVVISI

1. Stop using the product if it's damaged.

2. Keep the product away from fire and heat sources.

M