

Product Introduction

Product Name : Sing-E-ZQS

Trade Name : Sing-E

Thank you for purchasing our speaker. This speaker is suitable for various devices and provides clear, high-quality sound. It is suitable for home, office, and outdoor use. Please read this manual before use to ensure correct and safe operation.

Packaging List

Speaker x1

Power Charging Cable x1

User Manual x1

Product button introduction:

: Music mode (TF card, U disk, Wireless, FM), short press to switch function mode; Two speakers are turning on at the same time. Wireless and not connected to the phone, long press one of the speakers M key 2-3S hears a prompt tone and one of the key lights does not work. Blinking: The TWS connection is successful, and then the phone can be connected.

: Pause/play: Music mode (TF card, LINE IN, Usb flash drive, Wireless), tap to "Play/Pause".

: In Music mode, tap "Next" Long press to "Volume Plus".

: In Music mode, tap "Previous" Long press to "Volume Down".

Bluetooth connection:

Press and hold the power button for 2-3 seconds, and the indicator light will light up and a prompt sound will be heard. Turn on the Bluetooth function on your phone, find the speaker connection, click on pairing, and once paired successfully, you can play music or answer calls through the Bluetooth speaker.

Matters Needing Attention:

1. Avoid humid environments: Do not place Bluetooth speakers in damp places to avoid affecting their performance and lifespan.
2. Stay away from strong magnetic fields: Avoid placing Bluetooth speakers with objects with strong magnetic fields to prevent interference with their normal operation.
3. Maintain device distance: During use, ensure that the distance between the Bluetooth speaker and the device is within an effective range, usually around 10 meters, to avoid signal interruption.
4. Regularly clean the speaker: Pay attention to keeping the speaker clean and avoiding dust accumulation, which can affect sound quality and service life.
5. Proper storage: When not using Bluetooth speakers for a long time, they should be properly placed and the power should be turned off to save power and extend their lifespan.
6. Avoid high temperature environments: Avoid using Bluetooth speakers in high temperature environments to avoid affecting their performance and lifespan.
7. Handle with care: When using, handle with care to avoid rough handling and damage to the speaker.
8. Proper storage: When not in use, place the speaker in a dry and safe place to avoid falling or colliding.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.