

**PRODUCT PARAMETERS**

Product Name: Wireless headphone  
 Model : TS-12M  
 FCC ID : 2A8K3-TS-12M  
 Connected Name : TS-12M  
 Wireless Version : V5.4  
 Charging Type : Type - C  
 Use Time : 6-8h  
 Rated input power : 5V/0.2A  
 Battery Capacity : 400mAh  
 Charging Time : 1.5 - 2h  
 Rated voltage : DC 3.7V  
 Effective Distance : 10m

**PRODUCT ACCESSORIES :**

\* Note: The pictures in this manual are for illustrative purposes only. There may be deviations from the actual product, please refer to the actual product.

**HOW TO CONNECT**

1. Power on: push the "ON OFF" until the indicator light flashes and the headset prompts "POWER ON".
2. Connecting: turn on the mobile phone wireless connection, search for the headset wireless name "TS-12M", and click to connect.
3. After connecting: the headset prompts "CONNECTED".
4. Power off: push the "ON OFF" until the red light off and the headset prompts "POWER OFF".

**SAFETY NOTICE**

1. Please turn down the volume to avoid hearing damage.
2. Please charge the headset at least once every two months.
3. The product shelf life is one year.

**FCC WARNING**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

\*RF warning for Portable device:


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**INSTRUCTIONS**

- ON OFF** Push: Turn On or Turn Off
- ||** Press Once: Play or Pause  
Press Twice: Redial Last Number  
Long Press: Turn On or Turn Off Lights
- ▶▶** Press Once: Follow Song  
Long Press: Volume Up
- ◀◀** Press Once: Previous Song  
Long Press: Volume Down



MANUAL\*1



CHARGING CABLE\*1