

PYLE

PyleUSA.com



PBMSPG122

Wireless BT Portable Speaker Radio System


USER MANUAL

Please take the time to read this manual carefully before you begin using your new device. Any content revision of the manual won't declare again, and we are not responsible for consequence caused by fault or oversight of this manual.

FEATURES:

- Compact Boom Box Stereo Style
- Portable Travel-Friendly Speaker Design
- Digital Streaming FM Radio
- Built-in Rechargeable Battery
- MP3 Digital Audio File Playback
- Ported Enclosure for Extended Bass
- Full Range Stereo Sound Reproduction
- Rugged & Durable 'Super Tube' Speaker Housing

INSTRUCTION:



1. On/Off / Volume /EQ Knob
2. USB Port
3. LED Display
4. Microphone Socket
5. Guitar Socket
6. Mic Volume Knob
7. Aux-In Socket
8. Mode (Wireless BT, USB disk, FM and AUX-In Mode)
9. Previous Track and Rewind
10. Play/Pause
11. Next track and Fast Forward
12. Charging Socket

Music playing:

1. Press and hold Power button for 2-3 seconds to turn the speaker "ON"
2. Plug the USB disk into the USB socket. The audio files on the USB stick will start to play automatically.
3. Under playing mode, short press PREV or NEXT to select songs you like, long press to fast forward or rewind the song.
4. Turn the VOL knob to increase and decrease the volume.
5. Press PLAY/PAUSE to play or pause the music.
6. Please turn the Power button to "OFF" if not in use.

Wireless BT Streaming:

1. Turn **ON** the speaker. The LED screen will display bt and beeps twice and blinks quickly.
2. Activate Wireless BT of your mobile phone and search for device name "PyleUSA" then connect it. The **BT** on the screen stops blinking and beeps three times once connected successfully. If your device requests a password, enter "0000"
3. Play the music from your mobile phone and enjoy.
4. Press PREV or NEXT button on the devices or on Mobile phones to select songs you like.
5. Press Play/pause button on your devices or on Mobile phones to play/stop the music
6. Use the "Volume" Knob to increase and decrease the volume or adjust the mobile phones' volume.

FM Radio:

1. Under FM radio state, the audio cable provided is the antenna. Please insert the audio cable to get the best FM signal before using.
2. Turn the power button to "ON" without USB Card inserted. Then press the "MODE" button to switch to FM. (The order of the mode is Wireless BT, USB, FM and AUX-IN)
3. Under playing mode, short press "Play/pause" button to auto search the FM Channel and store it automatically.
4. Press PREV or NEXT button to change the stored FM channel.

AUX-IN:

For other compatible music devices or your MP3/MP4 players, use the supplied audio line cable to connect from the device's "Line Out" to the "AUX-IN" of this device. Then press the "MODE" button to switch to AUX-IN mode. Enjoy...

When using an external device, all functions will be controlled by the external device except the volume adjusting.

Microphone or Guitar (not included) Input:

- This product has Microphone input. Plug the 6.5MM microphone or guitar into the Mic hole/guitar hole then you can use.
- The volume can be adjusted using the "MIC-Vol" knobs.
(Please note that, this function cannot be use under FM radio state)

EQ function:

This unit offers 6 different kinds of sound effect, the order of the Equalizer is Normal, Rock, Pop, Classic, Jazz, and Country.

Remark: EQ button can control the audio from USB, BT & FM mode. The Audio from Aux-in can't be controlled by this button.

How to charge:

1. The charger is not included in the accessories. Please use the universal 5V/1A charger to charge this device. Put the provided charging cable into the charging jack, connect the other end to the charger, the charging indicator beside the LED screen will keep blinking. (When playing music during charging, please put the volume to middle, because for some music with heavy bass, the charger may can not afford the high current temporarily under the maximum volume)
2. Charge time should be 6-8 hours. When charging full, the indicator light will switch off.
3. To prolong the life of battery, **DO NOT CHARGE CONTINUOUSLY FOR LONGER THAN 8 HOURS.**



Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com



WARNING:

This product can expose you to a chemical or group of chemicals, which may include "Cadmium (Cd)" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.

PYLE

PyleUSA.com



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE