


单面尺寸：80x90mm， 展开尺寸：400x90mm， 要求：四色双面印刷， 105g铜板纸

SONIRD

WIRELESS EARPHONE

SONIRD Earbuds A3

Product Instruction Manual



Thank you for choosing this smart product. Please read this manual carefully before use.

I. Instructions for Use


Please read the manual thoroughly before using the product.

Notes / Precautions


Please read and follow the precautions below before operating this product to ensure optimal performance and prevent hazards or improper use.

- Do not place heavy objects on the product.
- Operate the product within an ambient temperature of -20°C to 60°C.
- Listening at high volume while driving may cause distraction and lead to traffic accidents.
- Do not disassemble or modify the product and accessories without permission.
- Do not use the product in dusty, humid or dirty areas to prevent internal circuit malfunctions.
- Keep the product away from heat sources and open flames, such as electric heaters, microwave ovens, stoves, water heaters, candles and other high-temperature appliances.
- Keep it away from Wireless devices, Wi-Fi devices, 2.4GHz computer peripherals, cordless phones, microwave ovens, refrigerators and other electronic devices to avoid signal interference or disconnection.
- Store the product and accessories in a cool, ventilated area out of direct sunlight.
- If the product is left unused for a long time, regularly place and remove earbuds from the charging case and charge it with the cable to prolong battery service life.
- This product is not edible. Keep it out of the reach of children to prevent accidents.


II. Product List



Earphone x 1



Charging Cable x 1



Charging Case x 1



User Manual x 1



Lx2





Mx2



Sx2

III. Product Diagram

① Charging Case


② Earbuds

IV. Product Specifications

Product Name	In-ear Wireless Earphones
Model No	A3(B1)
Wireless Version	V6.0
Communication Distance	About 10 Meters
Charging Case Battery Capacity	400mAh
Earbud Battery Capacity	30mAh
Charging Case Dimensions	60.4x23.8x45.2mm
Earbud Dimensions	25.8x17.1x31mm
Net Weight	34.1g
Rated Input	5V --- 1A
Charging Port	Type-C

V. Operation Instructions


① Turn on your phone's Wireless, search for the device named "SONIRD Earbuds A3" in Wireless settings and tap to pair.



② **Pairing Instructions**


- After the left and right earbuds connect to each other, the primary earbud will automatically enter normal pairing mode.
- Turn off Wireless on your phone, and the primary earbud will automatically enter normal pairing mode.
- When you open the case to power on the earbuds: if there is an existing connection record and the device is within range, the earbuds will reconnect automatically; if the device is out of range and reconnection fails, the earbuds will switch to pairing standby mode.
- When out of connection range, the earbuds will keep attempting reconnection for 3 minutes. They will power off automatically if no connection is established within this period.
- If not connected to any device, the earbuds will stop reconnection attempts and power off automatically after 3 minutes; they will also power off automatically when placed back into the charging case.

VI. Touch Control Instructions



- Volume Control**
Single tap the right earbud to increase volume, single tap the left earbud to decrease volume.
- Play/Pause**
Double-tap the function button on left/right earbud
- Track Switch**
Triple-tap right earbud for next track
triple-tap left earbud for previous track
- Voice Assistant**
Long press the left earbud for 2 seconds to activate voice assistant
- ANC Mode Switch**
Long press the right earbud for 2 seconds to activate ANC Mode Switch

VII. Charging Instructions



① The single digit of the digital tube flashes, and the battery percentage increases gradually.

② When fully charged, the digital tube displays 100%.

VIII. Usage Tips

① Wireless adopts 2.4GHz radio waves. Since many devices such as Wi-Fi also use this frequency band, the earbuds may experience intermittent audio due to signal interference, which is normal. If the issue persists, move away from the area or reconnect the earbuds.

② After powering on, the earbuds will automatically connect to the last paired phone. To pair with a new device, turn off Wireless on the original phone, then enable Wireless on the new phone to search for the earbuds.

③ Place the earbuds into the charging case when not in use; they will power off and charge automatically. Without the charging case, manually disconnect Wireless, and the earbuds will shut down after about 3 minutes.

④ If you feel the sound quality is poor, lacking bass, or the earbuds fit loosely, adjust their position to align the sound outlets closely with your ear canals.

⑤ If the earbuds fail to power on or charge, clean dirt off the charging contacts. Also check the power level of the charging case. Charge the case every 15 days if it is left unused for a long time.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

深圳新音科技有限公司

项目

B1说明书(SONIRD)

工艺

四色印刷、105铜板纸

日期

2026.07.01

颜色

四色印刷

M

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.