

STRICH

Looper&Drum Machine

Mac Software Manual


1.Open below




2.Open below



3.It shows below





4.Open system preferences, press "Security&Privacy"



5.Unlock to change

6.Unlock successfully then click "Open Anyway"



7.Click "Open"

8. It will be opened successfully then power on the looper and use type C cable to connect looper with mac.It will show "connected" then you can upload or download your phases.

