

✓ **INSTALLATION CHECKOFF LIST**

Doors

- ☐ Handles are secure and tight
- ☐ Door seals completely to cabinet on all sides
- ☐ Freezer door is level across the top

Leveling

- ☐ Refrigerator is level, side to side and tilted 1/4" (6mm) front to back
- ☐ Toe grille is properly attached to refrigerator
- ☐ Cabinet is setting solid on all corners

Electrical Power

- ☐ House power turned on
- ☐ Refrigerator plugged in

Ice Maker

- ☐ House water supply connected to refrigerator
- ☐ No water leaks present at all connections - recheck in 24 hours
- ☐ Ice Maker is turned ON.
- ☐ Ice & Water Dispenser operates correctly
- ☐ Front filter must be flush with filter housing (some models)

Final Checks

- ☐ Shipping material removed
- ☐ Fresh Food and Freezer controls set
- ☐ Crisper Humidity controls set
- ☐ Registration Card sent in


Refer to your *Owner's Use and Care Manual* for additional information about your refrigerator.

5 LEVELING AND ADJUSTING


All four corners of refrigerator must rest firmly on a solid floor. Your refrigerator has adjustable rollers to help level it and to adjust the doors.

To level cabinet or change door height:


1. Remove toe grille.
2. Use a screwdriver, 3/8" wrench, or nutdriver to adjust the rollers. To raise cabinet or door, turn screw clockwise. To lower cabinet or door, turn screw counterclockwise.



Toe Grille





Adjustable Front Roller (some models)




6

CONTROLS



When changing control settings, wait 24 hours before making additional adjustments.


7 ICEMAKER



Ensure icemaker to turned ON. Check to see that the Ice & Water Dispenser is operating correctly. (See Automatic Ice & Water Dispenser Features in *Use & Care Manual*.)

8

TO REMOVE DOORS (if necessary)



If you need to remove the doors to get your refrigerator in the house, please See *Door Removal Instructions* in your *Use & Care Manual*.


9

- ✓ See "Normal Operating Sights & Sounds" in the *Use & Care Manual* so you understand the sounds you may hear once your refrigerator is running.
- ✓ Please read entire *Use & Care Manual* to become aware of important safety instructions and to become familiar with your new refrigerator.
- ✓ Send in Registration card to register your refrigerator.
- ✓ Congratulations! You are ready to enjoy your new refrigerator.


IF YOU ARE DISSATISFIED WITH THE INSTALLATION, PLEASE CALL THE STORE YOU PURCHASED IT FROM.

P/N: 241811501

Tools Necessary:



1




HAND TRUCKING

- Load refrigerator from side of cabinet only.
- Do not run retaining straps over handles.
- Do not over-tighten retaining straps.
- Never use refrigerator handles to move the refrigerator.
- Remove tape from doors only after unit is in place.

2


SHIPPING MATERIAL




Remove Shipping material. (Features may vary per model.)

3

WATER SUPPLY



Connect water supply - check for water leaks. Turn icemaker OFF if water supply is not connected immediately. Connecting to a reverse osmosis system is not recommended.



4

INSTALLATION CLEARANCES

Allow the following clearances for ease of installation, proper air circulation, and plumbing and electrical connections:

- Sides & Top.....3/8"
- Back.....1"

NOTE

If you are installing your refrigerator beside a wall, leave 1/2" minimum between hinges and wall to allow for the door to swing open.

Consulte el *Manual de Uso y Cuidado* para obtener mayor información sobre su refrigerador.

Verificaciones Finales

☐ Se retiraron los materiales de embarque

☐ Se ajustaron los controles del refrigerador y del congelador

☐ Se ajustaron los controles de humedad del cajón de las verduras

☐ Se envió la Tarjeta de Registro

- Cargue el refrigerador por el lado del gabinete solamente.
- No pase las correas por encima de las manijas.
- No apriete demasiado las correas.
- Nunca use las manijas del refrigerador para moverlo.
- Retire la cinta de las puertas después que el refrigerador esté instalado en su lugar.

Retire los materiales de embarque.
(La características pueden variar según el modelo.)

**Asegúrese
de que la válvula
del agua esté abierta
y que no haya
fugas.**

Si instala el refrigerador junto a una pared, deje un espacio mínimo de 12,7 mm (1/2 pulg.) entre las bisagras y la pared para permitir que la puerta se pueda abrir.

Quando ajuste de controles, espere 24 horas para que la temperatura se estabilice antes de hacer cambios adicionales.

Asegúrese de que la máquina de hacer hielo esté **ACTIVADA**. Verifique para comprobar de que el dispensador de hielo y de agua esté funcionando correctamente. (Ver Características del Dispensador Automático de Hielo y Agua en el *Manual de Uso y Cuidado*.)

A close-up diagram of a hand using a utility knife to cut the outer jacket of a cable. A black arrow points to the right, indicating the direction of the cut.

Si es necesario retirar las puertas para poder entrar el refrigerador en la casa, por favor vea la sección *Instrucciones para el Desmontaje de las Puertas* en su Manual de Uso y Cuidado.

P/N: 241811501